



Manuals.plus /

› PRSCFUM /

› PRSCFUM S3 IPX7 Waterproof Portable Bluetooth Speaker User Manual

PRSCFUM S3

PRSCFUM S3 IPX7 Waterproof Portable Bluetooth Speaker User Manual

Model: S3

1. INTRODUCTION

Thank you for choosing the PRSCFUM S3 IPX7 Waterproof Portable Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your speaker. Please read it thoroughly before operation and retain it for future reference.



Image 1.1: PRSCFUM S3 Portable Bluetooth Speaker.

2. WHAT'S IN THE BOX

Verify that all items are present upon unboxing:

- 1 x S3 Bluetooth Speaker
- 1 x User Manual
- 1 x Type-C Charging Cable
- 1 x Suction Cup



Image 2.1: Package contents of the PRSCFUM S3 Bluetooth Speaker.

3. SETUP

3.1 Charging the Speaker

Before first use, fully charge the speaker using the provided Type-C charging cable. Connect the cable to the speaker's charging port and a compatible USB power source. The LED indicator will show charging status.

3.2 Powering On/Off

Press and hold the power button (usually marked with a power symbol) for a few seconds to turn the speaker on or off.

3.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "PRSCFUM S3" from the list. Once connected, the LED indicator will stop flashing.

The speaker features Bluetooth 5.3 for a stable and fast connection.

Bluetooth 5.3 & HD Stereo

One step pairing, range up to 33 feet



Image 3.1: Internal components highlighting Bluetooth 5.3 technology.

3.4 Attaching the Suction Cup

The included suction cup allows for easy attachment to smooth surfaces like glass or tiles. Ensure the surface is clean and dry for optimal adhesion. Press the suction cup firmly against the desired surface.

Strong Suction Cup

Enjoy a funny shower with music



IP7



Calling



Image 3.2: Speaker attached to a shower wall using the suction cup.

3.5 Setting the Time Display (Android Devices)

When connecting to an Android phone, the speaker may request SMS permission to accurately update its time display. You can grant or deny this permission. Denying it will not affect other speaker functions, but the time display may not be accurate.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls

The speaker features intuitive buttons for control:

- **Power Button:** Press and hold to turn on/off.
- **Play/Pause Button:** Press to play or pause music.
- **Volume Up (+):** Press to increase volume.
- **Volume Down (-):** Press to decrease volume.

- **Next Track:** Press and hold Volume Up (+) to skip to the next track.
- **Previous Track:** Press and hold Volume Down (-) to go to the previous track.
- **Mode Button (M):** Press to switch between Bluetooth, FM Radio (if available), or other modes.
- **Light Button:** Press to cycle through LED light modes.

4.2 True Wireless Stereo (TWS) Pairing

To achieve true wireless stereo sound, you can pair two S3 speakers together:

1. Ensure both S3 speakers are powered off.
2. Turn on both speakers. They will automatically enter pairing mode.
3. On one speaker, double-press the Mode (M) button. The speakers will attempt to connect to each other.
4. Once successfully paired, one speaker will act as the master and the other as the slave. Connect your device to the master speaker via Bluetooth.



Image 4.1: Two S3 speakers connected for True Wireless Stereo.

4.3 LED Light Modes

The speaker features various LED light modes, including music rhythm lights and color breathing lights. Press the Light button to cycle through the available options and select your preferred visual effect.



Image 4.2: Examples of the speaker's LED light modes.

4.4 Hands-Free Calling

When connected to your smartphone, the speaker can be used for hands-free calls. Press the Play/Pause button to answer or end a call.

4.5 Waterproof Usage (IPX7)

The S3 speaker is IPX7 waterproof, meaning it can withstand immersion in up to 1 meter of water for 30 minutes. This makes it suitable for use in showers, by the pool, or at the beach. Ensure the charging port cover is securely closed before exposing the speaker to water.

IP7 Waterproof

Withstand full immersion in
One meter of water and floating



Image 4.3: Speaker demonstrating IPX7 waterproof capability in a pool.

PRSCFUM

Portable Bluetooth Speakers
Enjoy Music Anywhere



Hanging Hole



LED Lights



Bluetooth 5.3



10H Playtime



IP7 Waterproof



Suction Cup



Image 4.4: Speaker in a bathroom setting, highlighting its waterproof design.

4.6 Portability

The speaker features a compact design and a hanging hole, making it easy to carry for outdoor activities like cycling, camping, or hiking.

Ultra Durable & Portable Size

Designed for different outdoor activities



8-10H Playtime



Image 4.5: Speaker attached to a bicycle, showcasing its portability.



Image 4.6: Speaker hanging from a backpack, illustrating its rugged design for travel.

5. MAINTENANCE

5.1 Cleaning

To clean the speaker, wipe it with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port cover is sealed if cleaning with water.

5.2 Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker regularly, even if not in use for extended periods. Store in a cool, dry place.




Image 5.1: Battery life and capacity information.

6. TROUBLESHOOTING

- **Speaker will not turn on:** Ensure the battery is charged. Connect the speaker to a power source using the Type-C cable and try again.
- **Cannot pair via Bluetooth:** Make sure the speaker is in pairing mode (flashing LED). Ensure Bluetooth is enabled on your device and it is within the 15-meter range. Try restarting both the speaker and your device.
- **No sound or low volume:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is not muted.
- **Buttons are difficult to read:** The buttons are designed for tactile use. Familiarize yourself with their positions and functions.
- **Time display is inaccurate:** If using an Android device, ensure SMS permission was granted for time synchronization.

Otherwise, the time display may not be accurate.

- **Suction cup not holding:** Ensure the surface is clean, dry, and smooth. Press firmly to remove air bubbles.

7. SPECIFICATIONS

Feature	Specification
Brand	PRSCFUM
Model Number	S3
Connectivity Technology	Bluetooth 5.3
Water Resistance Level	IPX7 (Waterproof)
Speaker Maximum Output Power	6 Watts
Audio Output Mode	Stereo
Battery Capacity	1100 mAh
Battery Average Life	8-10 Hours
Maximum Range	15 Meters
Control Method	Push Button
Material	Metal, Plastic
Item Dimensions (D x W x H)	5"D x 5"W x 5"H

Portable Size

3.62 inch




Image 7.1: Speaker dimensions.

8. WARRANTY & SUPPORT

8.1 Warranty Information

The PRSCFUM S3 speaker comes with a reasonless return and exchange service within 30 days of purchase. Additionally, 24-hour after-sales service is provided within 180 days.

8.2 Customer Support

For any questions, concerns, or support needs, please refer to the contact information provided with your purchase or visit the official PRSCFUM website.