

[Manuals.plus](#) /

› [slochi](#) /

› slochi 12-Inch Flush Mount LED Ceiling Light Fixture User Manual

slochi 12Inch-1Pack

slochi 12-Inch Flush Mount LED Ceiling Light Fixture User Manual

Model: 12Inch-1Pack | Brand: slochi

1. INTRODUCTION

Thank you for choosing the slochi 12-Inch Flush Mount LED Ceiling Light Fixture. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting product. Please read these instructions thoroughly before installation and retain them for future reference.




Image 1.1: slochi 12-Inch Flush Mount LED Ceiling Light installed in a modern living room setting, showcasing its sleek design and bright illumination.

2. KEY FEATURES

- **Ultra-Thin Design:** With a thickness of only 0.94 inches, this LED ceiling light fits perfectly in rooms with low ceilings, offering a modern and minimalist aesthetic.
- **Three Color Temperatures:** Easily switch between 3000K (warm white), 4000K (neutral white), and 6500K (daylight white) to suit your preference and room ambiance. The selection is made via a switch on the back of the product.
- **Strong Adaptability & Easy Installation:** Designed for both recessed and surface mounting, compatible with most standard junction boxes. Installation does not require professional electrical assistance.
- **Super Bright & Energy Efficient:** Equipped with 100 high-quality LEDs, providing 1600 lumens of light with only 15W power consumption, equivalent to a 100W traditional light bulb. Covers approximately 216 square feet.
- **Safe & Durable:** Features a high-quality fireproof plastic housing, short circuit protection, and CE certification. LEDs

have a service life of up to 25,000 hours.

- **No Flicker and Delay:** Built-in Light Guide Plate ensures comfortable, soft light, reducing eye fatigue.





Image 2.1: The built-in Light Guide Plate ensures soft, flicker-free illumination, enhancing visual comfort.

Ultra slim design

The thickness of this light is only **0.94 inch**, this excellent design makes it really Low Profile and Flush Mount



Compatible with the most junction boxes



Image 2.2: The ultra-slim design of the slochi ceiling light, measuring only 0.94 inches in thickness and 12 inches in diameter.

3. SAFETY INFORMATION

WARNING: RISK OF ELECTRIC SHOCK. DISCONNECT POWER AT THE FUSE OR CIRCUIT BREAKER BEFORE INSTALLING OR SERVICING.

- Read all instructions before installation.
- Ensure the main power supply is turned off before beginning any electrical work.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Use only the provided mounting hardware.
- Do not attempt to modify the fixture.
- Consult a qualified electrician if you are unsure about the installation process.

4. PACKAGE CONTENTS

Your slochi LED Ceiling Light Fixture package should include:

- slochi 12-Inch Flush Mount LED Ceiling Light Fixture
- Mounting Bracket
- Mounting Screws and Wall Anchors
- Wire Nuts
- User Manual (this document)


5. INSTALLATION INSTRUCTIONS

Follow these steps for a safe and easy installation:

1. **Prepare for Installation:** Turn off power at the circuit breaker. Ensure the power is completely off before proceeding.
2. **Remove Mounting Bracket:** Gently twist and unlock the mounting bracket from the back of the light fixture.
3. **Mount the Bracket:** Choose your ideal installation location. Secure the mounting bracket to the ceiling using the provided screws and wall anchors. Ensure it is firmly attached to a junction box or a sturdy surface.
4. **Connect Wiring:** Connect the wires from the ceiling to the light fixture's wires using the provided wire nuts. Typically, black (or brown) connects to black, and white (or blue) connects to white. If your ceiling wiring includes a ground wire, ensure it is properly secured according to local electrical codes.
5. **Attach Light Fixture:** Align the light fixture with the mounted bracket and rotate the lamp body clockwise to lock it into place.
6. **Restore Power:** Turn the power back on at the circuit breaker.




Easy to Installation



Step 1

Choose your ideal installation location



Step 2

Pass the wires through the lamp holder, Fix bracket on the ceiling or wall



Step 3

Connect the wires, put the wires into the box, Place the wiring ports in the appropriate locations.



Step 4

Rotate the lamp body clockwise to complete the installation.

Image 5.1: Step-by-step visual guide for installing the slochi LED ceiling light, from choosing a location to locking the fixture.

Installation Video Guide

Your browser does not support the video tag.

Video 5.1: An unboxing and installation overview of the slochi LED Ceiling Lamps, demonstrating the components and basic setup process.

6. OPERATING INSTRUCTIONS

Adjusting Color Temperature

Your slochi LED Ceiling Light Fixture features three adjustable color temperatures: 3000K (warm white), 4000K (neutral white), and 6500K (daylight white).

1. Before final installation, locate the small selector switch on the back of the light fixture.

- Slide the switch to select your desired color temperature (3000K, 4000K, or 6500K).
- Once the light is installed and powered on, it will illuminate at the selected color temperature.



Image 6.1: Diagram illustrating the selector switch on the back of the fixture for choosing between 3000K, 4000K, and 6500K color temperatures.

7. MAINTENANCE

The slochi LED Ceiling Light Fixture requires minimal maintenance.

- **Cleaning:** Ensure the power is off before cleaning. Wipe the fixture with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners, as they may damage the finish or electrical components.
- **Bulb Replacement:** This fixture uses integrated LED technology and does not require bulb replacement. The LEDs are designed for a long lifespan of up to 25,000 hours.

8. TROUBLESHOOTING

If you encounter issues with your slochi LED Ceiling Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power supply; Loose wiring; Faulty switch	Check circuit breaker; Verify wire connections; Test wall switch.
Light flickers	Loose wiring; Incompatible dimmer switch (if applicable)	Ensure all connections are secure; This fixture is not explicitly stated as dimmable, avoid using with dimmer switches unless specified.
Incorrect color temperature	Selector switch set incorrectly	Turn off power, remove fixture, adjust the color temperature selector switch on the back.

If the problem persists after trying these solutions, please contact slochi customer support.

9. SPECIFICATIONS

Attribute	Detail
Brand	slochi
Model	12Inch-1Pack
Color	Wood (Fixture housing color)
Material	Plastic
Style	Modern
Room Type	Home (Suitable for various indoor rooms)
Product Dimensions	1"L x 1"W x 1"H (Note: This appears to be a placeholder. Actual dimensions are 12-inch diameter, 0.94-inch thickness)
Specific Uses For Product	Home
Indoor/Outdoor Usage	Indoor
Power Source	AC
Item Weight	1.54 pounds
Batteries Included?	No
Batteries Required?	No
Input Voltage	110-120V 50/60Hz
Color Temperature	3000K - 4000K - 6500K (Adjustable)

Attribute	Detail
Working Temperature	-20°C to +45°C
Input Power	15W
CRI	>80
Lifespan	Up to 25,000 hours

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact slochi customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may visit the [slochi Store on Amazon](#).

© 2025 slochi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

