

Pecute 7-in-1 Dog Grooming Vacuum & Dryer

Pecute 7-in-1 Dog Grooming Vacuum & Dryer Instruction Manual

Model: 7-in-1 Dog Grooming Vacuum & Dryer

1. INTRODUCTION

Thank you for choosing the Pecute 7-in-1 Dog Grooming Vacuum & Dryer. This versatile device combines a pet grooming vacuum, dryer, and clipper into one unit, designed to simplify pet care at home or in a salon setting. It effectively manages pet shedding, provides gentle drying, and offers various grooming tools for a comprehensive experience. Please read this manual thoroughly before use to ensure proper operation and maintenance.


2. SAFETY INFORMATION

- Always ensure the device is unplugged before cleaning or performing maintenance.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children and pets when not in use.
- Only use the device with the specified voltage (110V-120V).
- Do not operate the device if the power cord or plug is damaged.
- Avoid blocking air vents during operation to prevent overheating.
- Use caution when using the clipper blades; they are sharp.

3. PRODUCT OVERVIEW AND COMPONENTS

The Pecute 7-in-1 system integrates grooming, drying, and vacuuming functions. Familiarize yourself with the main unit and its attachments.

All-in-1 Grooming & Cleaning Machine



Vacuum



Dryer




Grooming



Figure 3.1: The Pecute 7-in-1 Grooming & Cleaning Machine, showcasing the main unit, hose, and various attachments, with a dog and cat nearby.

Included Attachments:

7-in-1 Pet Grooming Kit



Electric Clipper



Grooming Brush



Vacuum Cleaner



Drying Accessories

Figure 3.2: Detailed view of the 7-in-1 Pet Grooming Kit components, including the electric clipper, grooming brush, vacuum cleaner nozzle, and various drying accessories.

- **Electric Clipper:** For trimming pet hair, includes 4 limit combs (3/9/16/24mm).
- **Grooming Brush:** For detangling and removing loose pet hair.
- **Drying Nozzles:** Three types (round, palm-shaped, flat) for various blow-drying needs.
- **Vacuum Cleaner Nozzle:** For removing residual fur from surfaces like sofas and carpets.
- **Roller:** For collecting fur from fabrics.
- **Hose:** 1.6M flexible hose with foam-cushioned grip.
- **Dust Cup:** 1.7L capacity for collecting hair.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Hose:** Attach the flexible hose to the main unit's intake port. Ensure it is securely fastened.

3. **Attach Dust Cup:** Ensure the 1.7L dust cup is correctly installed on the main unit.
4. **Select Attachment:** Choose the desired grooming or cleaning attachment and connect it to the end of the hose.
5. **Power Connection:** Plug the 2M power cord into a standard 110V-120V electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Control Panel Overview



Figure 5.1: The control panel features a rotary switch for wind speed and a temperature control dial, along with a one-click switch for modes.

- **Rotary Switch (Wind Speed):** Turn to adjust the suction power (for vacuuming) or airflow (for drying). Settings range from OFF to MAX.
- **Temperature Control:** Adjusts the drying temperature from 45°C-65°C (113°F-149°F).
- **One-click Switch:** Toggles between 'DRYER' and 'CLEANER' (vacuum) modes.

5.2 Grooming and Drying

1. **Power On:** Turn the Rotary Switch from OFF to your desired wind speed setting.
2. **Select Mode:** Use the One-click Switch to select 'DRYER' for drying or 'CLEANER' for vacuuming/grooming.
3. **Adjust Settings:** For drying, adjust the temperature using the Temperature Control dial. For both modes, adjust wind speed/suction as needed.
4. **Use Attachments:**
 - **Grooming Brush:** Gently brush your pet's coat to remove loose hair. The vacuum will collect shed hair directly into the dust cup.
 - **Electric Clipper:** Attach the desired limit comb (3/9/16/24mm) and carefully trim your pet's hair. The vacuum function helps collect trimmed hair.
 - **Drying Nozzles:** Use the appropriate nozzle to blow-dry your pet's fur after bathing. Adjust temperature and airflow for comfort.
5. **Surface Cleaning:** Switch to 'CLEANER' mode and use the vacuum cleaner nozzle or roller to remove pet hair from furniture, carpets, or clothing.

Pet Grooming Salon at Home




Figure 5.2: Demonstrating the use of the Pecute grooming kit for at-home pet care.

5.3 Noise Level and Pet Comfort

The device operates at approximately 55 dB, which is significantly quieter than standard vacuums and dryers, designed to reduce pet anxiety. Start with the lowest speed setting and gradually increase to allow your pet to acclimate.



Figure 5.3: Visual representation of the low noise level (55dB) of the Pecute grooming vacuum, designed for stress-free pet grooming.

6. MAINTENANCE

6.1 Emptying the Dust Cup

The 1.7L dust cup should be emptied regularly, especially after each grooming session, to maintain optimal suction performance.

1. Ensure the device is turned off and unplugged.
2. Carefully detach the dust cup from the main unit.

3. Open the dust cup and dispose of the collected pet hair into a waste bin.
4. Clean the interior of the dust cup and filter if necessary, using a damp cloth. Ensure it is completely dry before reattaching.
5. Reattach the dust cup securely to the main unit.



Figure 6.1: Demonstrating the easy emptying process of the 1.7L large capacity dust cup.

6.2 Cleaning Attachments

- After each use, remove any hair or debris from the grooming brush, clipper blades, and drying nozzles.
- The ceramic-titanium clipper blades are rust-proof. Use the provided lubrication oil bottles to oil the clipper blades regularly for optimal performance and longevity.
- Wipe down the exterior of the main unit and hose with a soft, damp cloth. Do not use harsh chemicals.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Not plugged in; power outlet issue; rotary switch is OFF.	Ensure power cord is securely plugged in. Test outlet with another device. Turn rotary switch to an ON position.
Low suction/airflow.	Dust cup full; filter clogged; hose/attachment blocked.	Empty dust cup. Clean filter. Check hose and attachments for blockages and clear them.
Clipper not cutting effectively.	Blades dull; blades not lubricated; hair buildup.	Clean blades thoroughly. Apply lubrication oil. Consider replacing blades if excessively dull.
Device overheating.	Blocked air vents; prolonged use.	Ensure air vents are clear. Turn off device and allow it to cool down before resuming use.

8. SPECIFICATIONS

Feature	Specification
Product Name	Pecute 7-in-1 Dog Grooming Vacuum & Dryer
Model	B0FNN52BXX
Suction Power	10000Pa
Airflow	1100W
Motor Speed	35000 RPM
Adjustable Temperature	45°C-65°C (113°F-149°F)
Noise Level	55 dB
Dust Cup Capacity	1.7L
Hose Length	1.6 meters
Power Cord Length	2 meters
Power Source	Corded Electric (110V-120V)
Item Weight	3.5 kg
Color	White

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included with your purchase or contact Pecute customer service directly through their official website or the retailer where the product was purchased. Please have your product model and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question