

[Manuals.plus](#) /

› [Best Choice Products](#) /

› Best Choice Products Set of 2 Adjustable Steel Mesh Zero Gravity Lounge Chair Recliners - Instruction Manual

## Best Choice Products SKY9361

# Best Choice Products Set of 2 Adjustable Steel Mesh Zero Gravity Lounge Chair Recliners - Instruction Manual

Brand: Best Choice Products | Model: SKY9361

## INTRODUCTION

---

Thank you for choosing the Best Choice Products Set of 2 Adjustable Steel Mesh Zero Gravity Lounge Chair Recliners. These chairs are designed to provide comfort and relaxation, whether used outdoors on a patio, by the pool, or in your backyard. This manual provides essential information for the proper setup, operation, and maintenance of your new lounge chairs.



Image: Two Best Choice Products Zero Gravity Lounge Chairs in Dove Gray, set up on a patio.

## SETUP AND ASSEMBLY

Your Zero Gravity Lounge Chairs come pre-assembled and are designed for quick and easy setup. No complex tools are required.

1. **Unfolding the Chair:** Gently pull the chair frame apart until it fully extends into the upright seating position. Ensure all legs are firmly on the ground.
2. **Attaching the Accessory Tray:** The detachable accessory tray can be installed on either side of the chair. Slide the tray over the leg hinge and push it down firmly until it locks into place. The tray features two cup holders, a phone holder, and a tablet holder.
3. **Adjusting the Headrest:** The padded headrest is removable and adjustable. Slide it up or down along the back of the chair to find your preferred comfort level.

33.5 - 44in.  
85 - 111.8 cm

32.5 - 61 in.  
82.6 - 154.9 cm

25 in.  
63.5 cm

38 in.  
96.5 cm

25 in.  
63.5 cm

Image: A Best Choice Products Zero Gravity Lounge Chair folded for compact storage.

## DETACHABLE HOLDING TRAY

Keep your favorite drinks and media devices close at hand for uninterrupted relaxation!



Tablet Rest



2 Cup Holders




Phone Mount

Image: Close-up view of the detachable accessory tray, showing two cup holders, a phone slot, and a tablet slot.

### OPERATING INSTRUCTIONS

The Zero Gravity Lounge Chair is designed for smooth and effortless reclining to achieve an ergonomic, weightless position.

- 1. Reclining:** To recline, gently push back on the armrests while allowing your body weight to shift. The chair will smoothly glide into various reclining positions.
- 2. Locking Position:** Once you find your desired reclining angle, locate the locking knobs on both armrests. Turn these knobs to the right to tighten and secure the chair in place. To unlock, turn the knobs to the left.
- 3. Returning to Upright:** To return to an upright position, loosen the locking knobs, then gently push forward on the armrests while shifting your weight forward.



## LIE BACK AND RELAX

Built with freely adjustable back and footrests so you can find and enjoy the perfect angle




Image: A diagram illustrating the reclining function of the chair, showing movement from an upright to a nearly flat 160-degree position.

### MAINTENANCE

- **Cleaning:** Wipe clean with a dry cloth. For stubborn stains, a mild soap solution can be used, followed by wiping with a clean, damp cloth and air drying.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 250 lbs (113 kg) to prevent damage to the chair and potential injury.
- **Storage:** When not in use, especially during inclement weather or off-season, fold the chairs for compact storage to prolong their lifespan.

# SUPERIOR SEATING

Turn any spot into your private oasis



*\*Navy color shown*

Image: Detailed view of the chair's weather-resistant textilene fabric and durable alloy steel frame.

## TROUBLESHOOTING

If you encounter any issues with your Zero Gravity Lounge Chair, please ensure all parts are correctly assembled and the locking mechanisms are properly engaged. For further assistance, please refer to the Warranty and Support section.

## SPECIFICATIONS

Feature	Detail
Brand	Best Choice Products
Model Number	SKY9361
Color	Dove Gray
Material	Metal (Frame), Textilene Fabric (Seat), Fiber batting/fill (polyester) (Pillow)

Product Dimensions (Open)	32.5"-61"(L) x 25"(W) x 33.5"-44"(H)
Product Dimensions (Folded)	38"(L) x 25"(W) x 6"(H)
Item Weight	32.6 Pounds
Maximum Weight Capacity	250 lbs
Reclining Position Count	2
Indoor Outdoor Usage	Outdoor
Included Components	Assembly Guide, Detachable Cup Holder Tray, Adjustable Headrest



Image: Detailed dimensions of the chair when fully open and when folded for storage.

## WARRANTY AND SUPPORT

**Manufacturer Warranty:** A 60-day warranty is provided. Returns are shipped back to a Best Choice Products return center at the customer's expense within 60 days of delivery. A pre-paid return shipping label will be provided if the return is a result of our error. The company reserves the discretion to decide if an item may be

returned. Unauthorized returns may not be accepted. Once your claim is processed and approved, please allow 5-7 business days for the request to be completed. If a replacement unit or parts are requested, fulfillment time is based on product availability.

**Return Policy:** This product has a 30-day refund/replacement return policy.

For further assistance or inquiries, please visit the Best Choice Products Help Center or contact customer support.