



[Manuals.plus](#) /

› [Madesa](#) /

› Madesa Vik 70cm 2-Door Wall-Mounted Display Cabinet Instruction Manual

Madesa G25832F9VKSU

Madesa Vik 70cm 2-Door Wall-Mounted Display Cabinet Instruction Manual

Model: G25832F9VKSU

INTRODUCTION

This manual provides comprehensive instructions for the assembly, installation, and maintenance of your Madesa Vik 70cm 2-Door Wall-Mounted Display Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This cabinet is designed to be wall-mounted and does not include feet.



Image: The Madesa Vik 70cm 2-Door Wall-Mounted Display Cabinet, showcasing its rustic and gray finish with clear glass doors.

SAFETY INFORMATION

- **Wall Mounting is Mandatory:** This cabinet is designed for wall installation only. It must be securely fixed to a suitable wall structure to prevent tipping and injury.
- **Professional Installation Recommended:** If you are unsure about wall mounting procedures or the suitability of your wall, consult a qualified professional.
- **Weight Limits:** Do not exceed the maximum weight capacity for each shelf. Overloading can compromise the cabinet's stability and structural integrity.
- **Children Safety:** Keep children away from the assembly area. Ensure all small parts and hardware are out of reach.
- **Glass Handling:** Exercise caution when handling glass components to avoid breakage and injury.
- **Ventilation:** Assemble in a well-ventilated area.



Image: Detail showing the wall fixation mechanism, emphasizing the mandatory wall attachment for stability.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact Madesa customer support.

- One (1) Madesa Vik 70cm 2-Door Wall-Mounted Display Cabinet structure
- Two (2) Glass Doors
- Assembly Hardware Kit (screws, dowels, hinges, handles, wall mounting brackets)
- Assembly Manual (this document)

TOOLS REQUIRED FOR ASSEMBLY

The following tools are typically required for assembling and installing the display cabinet:

- Phillips Head Screwdriver
- Hammer
- Drill (with appropriate drill bits for wall material)
- Level
- Measuring Tape
- Pencil

SPECIFICATIONS

Feature	Detail
Model Number	G25832F9VKSU
Dimensions (Height x Width x Depth)	141 cm x 70 cm x 31 cm
Weight	Approximately 26 kg
Material	Engineered Wood
Finish	Rustic (structure), Gray (doors) - Matte finish with soft-touch texture
Doors	2 Glass Doors with soft-close hinges
Handles	Aged gold point handles (metal)
Mounting Type	Wall-mounted (suspended)
Special Features	7-layer Polyester paint, American style design, chamfered fronts



Image: Diagram illustrating the product dimensions (141cm H x 70cm W x 31cm D) and internal shelf spacing with weight limits.

Diferenciais do Produto





Image: Diagram highlighting key features such as American-style doors, clear glass, aged gold handles, soft-close hinges, and the suspension profile.

SETUP AND ASSEMBLY INSTRUCTIONS

Follow the detailed assembly manual included in your package for step-by-step instructions. The general process involves:

- 1. Unpack and Identify Parts:** Carefully unpack all components and compare them against the parts list in the included assembly manual.
- 2. Assemble the Cabinet Structure:** Follow the instructions to assemble the main body of the cabinet using the provided hardware.
- 3. Install Shelves:** Insert the internal shelves into their designated positions. Note the weight limits per shelf as indicated in the dimensions diagram.
- 4. Attach Wall Mounting Brackets:** Secure the suspension kit and wall mounting brackets to the back of the cabinet as per the manual.
- 5. Prepare Wall for Mounting:**
 - Choose a suitable wall location, ensuring it can support the weight of the cabinet and its contents.

- Mark the desired height and position for the wall mounting rail/brackets using a level and measuring tape.
 - Drill pilot holes and insert appropriate wall anchors (not always included, may need to be purchased separately based on wall type).
 - Securely attach the wall mounting rail/brackets to the wall.
6. **Mount the Cabinet:** Carefully lift the cabinet and hook it onto the installed wall mounting rail/brackets. Ensure it is level and securely seated.
 7. **Install Doors:** Attach the glass doors using the soft-close hinges. Adjust the hinges as needed for proper alignment and smooth closing.
 8. **Attach Handles:** Secure the aged gold point handles to the doors.

Important Note: Madesa does not provide assembly services. It is the responsibility of the customer to ensure proper and safe assembly and installation.



Image: Close-up of the suspension kit, which includes the support profile for fixing the furniture to the wall.

OPERATING INSTRUCTIONS

The Madesa Vik display cabinet is designed for storing and displaying various items such as dinnerware, glassware, and decorative objects.

- **Opening and Closing Doors:** Gently pull the aged gold point handles to open the glass doors. The soft-close hinges ensure a smooth and quiet closing action. Avoid forcing the doors.
- **Shelf Capacity:** Refer to the dimensions diagram in the Specifications section for recommended weight limits per shelf. Distribute weight evenly to maintain stability.
- **Displaying Items:** Arrange items carefully on the shelves. Ensure that items are stable and do not obstruct the closing of the doors.

Dimensões do Produto



Profundidade: 31cm

Image: The display cabinet showcasing various items like jars, glasses, and decorative pieces on its shelves.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your Madesa Vik display cabinet.

- **Cleaning:**
 - For the wooden surfaces, wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
 - For glass doors, use a glass cleaner and a soft, lint-free cloth.
 - Dry all surfaces immediately after cleaning to prevent water marks.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.
- **Humidity Control:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.
- **Check Fasteners:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Avoid Overloading:** Do not place excessively heavy items on the shelves.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet feels unstable or wobbly.	Not securely mounted to the wall; loose wall anchors or fasteners.	Ensure the wall mounting brackets are firmly attached to the wall and the cabinet is properly seated. Check all internal fasteners. If necessary, consult a professional for wall mounting.
Doors do not close smoothly or are misaligned.	Hinges are not properly adjusted or are loose.	Adjust the screws on the soft-close hinges to align the doors. Refer to the assembly manual for hinge adjustment details. Tighten any loose hinge screws.
Glass is scratched or damaged.	Improper handling or cleaning.	Use only soft cloths and appropriate glass cleaner. For significant damage, contact Madesa for replacement parts.
Shelves sag or appear weak.	Overloaded shelves.	Reduce the weight on the shelves. Distribute items more evenly. Ensure shelf supports are correctly installed.

WARRANTY INFORMATION

Madesa products are manufactured with quality materials and craftsmanship. For specific warranty terms and conditions regarding manufacturing defects, please refer to the warranty documentation provided with your purchase or visit the official Madesa website. Keep your proof of purchase for warranty claims.

Note: Extended warranty plans mentioned during purchase are separate from the manufacturer's standard product warranty and are typically offered by third-party providers.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Madesa customer support:

- **Website:** www.madesa.com.br (Please check for an English version or international contact options)
- Refer to your purchase documentation for specific contact numbers or email addresses.

When contacting support, please have your model number (G25832F9VKSU) and proof of purchase readily available.

© 2026 Madesa. All rights reserved.
This manual is subject to change without notice.