Polibi 57.1" W Modern Chaise Lounge Sofa Bed

Polibi 57.1" W Modern Chaise Lounge Sofa Bed User Manual

Model: 57.1" W Modern Chaise Lounge Sofa Bed

1. INTRODUCTION

Thank you for choosing the Polibi 57.1" W Modern Chaise Lounge Sofa Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before use and retain them for future reference.

Image 1.1: The Polibi 57.1" W Modern Chaise Lounge Sofa Bed in Grey, illuminated by its RGB LED strip.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.

- Do not exceed the maximum weight capacity of 660 lbs (approximately 299 kg).

- Keep small parts and packaging materials away from children to prevent choking hazards.

- Avoid placing the sofa bed near heat sources or in direct sunlight to prevent material degradation.

- Use only the provided power adapter for the LED light strip. Do not use damaged cords or plugs.

- Unplug the LED light strip power adapter before cleaning or if not in use for extended periods.

3. PACKAGE CONTENTS

Your Polibi Chaise Lounge Sofa Bed arrives in a single box. Carefully unpack all items and verify against the list below. If any parts are missing or damaged, please contact customer support.

- Chaise Lounge Sofa Bed Frame (main body)

- Adjustable Backrest Mechanism

- Seat Cushion (integrated)

- Armrests (2)

- Decorative Pillows (2)

- Legs (4)

- RGB LED Light Strip

- LED Controller and Power Adapter

- Assembly Hardware (screws, washers, Allen wrench)

- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required. All necessary tools and instructions are included. It is recommended to assemble the sofa bed with two people.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.

2. **Attach Legs:** Locate the four legs and the corresponding mounting points on the underside of the sofa bed frame. Securely attach each leg using the provided screws and Allen wrench. Ensure they are tightened firmly.

3. **Connect LED Light Strip:** The LED light strip is pre-installed. Connect the LED controller to the light strip and then connect the power adapter to the controller. Ensure all connections are snug.

4. **Position Sofa Bed:** Carefully lift and place the assembled sofa bed in its desired location.

Image 4.1: Detail of the sofa bed's robust leg, indicating secure attachment.

5. OPERATING INSTRUCTIONS

5.1 Adjustable 6-Position Backrest

The chaise lounge features an adjustable backrest with six distinct positions, allowing you to customize your comfort for various activities such as reading, lounging, or napping.

- To adjust the backrest, gently push the backrest forward until you hear a click.

- Continue pushing forward to release the current position.

- Slowly recline the backrest to your desired angle. The mechanism will lock into one of the six preset positions: 90°, 105°, 120°, 135°, 150°, and 180° (fully flat).

- Ensure the backrest is securely locked into position before applying full weight.

Image 5.1: Side profile of the chaise lounge, illustrating the adjustable backrest feature.

5.2 RGB LED Light Strip Operation

The integrated RGB LED light strip offers over 60,000 color options and various dynamic modes, controllable via a mobile application. This feature enhances the ambiance of your living space.

1. **Power On:** Plug the LED light strip power adapter into a standard electrical outlet.

2. **Download App:** Scan the QR code provided with the LED controller or search for 'LotusLamp X' in your mobile device's app store (iOS App Store or Google Play Store).

3. **Connect via Bluetooth:** Open the 'LotusLamp X' app. Ensure your device's Bluetooth is enabled. The app should automatically detect and connect to the LED controller.

4. **Control Lights:** Use the app interface to select colors, adjust brightness, choose lighting effects, set timers, or sync the lights with music.

Your browser does not support the video tag.

Video 5.2: Demonstration of the LED light strip connection and app control, along with the adjustable backrest feature.

6. Maintenance

Proper care will extend the life and appearance of your sofa bed.

- **Regular Cleaning:** Vacuum the chenille upholstery regularly using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for upholstery, testing on an inconspicuous area first.
- **Removable Components:** The backrest and cushion are removable for easier cleaning. Follow care instructions on the fabric tags if available.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or strong detergents, as these can damage the fabric and finish.
- **Legs:** Periodically check and tighten the legs to ensure stability.

Image 6.1: Detailed view of the plush chenille fabric upholstery.

7. Troubleshooting

If you encounter any issues with your Polibi Chaise Lounge Sofa Bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED lights not turning on.	Power adapter not connected, loose connection, app not connected.	Ensure power adapter is securely plugged into outlet and controller. Check app connection via Bluetooth.
Backrest not adjusting or locking.	Mechanism obstruction, improper operation.	Ensure no obstructions. Push backrest fully forward to reset mechanism before reclining to desired position.
Sofa bed feels unstable.	Loose legs or frame connections.	Check and tighten all leg and frame assembly screws.

8. SPECIFICATIONS

Key dimensions and material information for your Polibi Chaise Lounge Sofa Bed:

| Feature	Detail
Product Dimensions (D x W x H)	57.1"D x 63.8"W x 36.2"H
Seat Height	17.7 Inches
Item Weight	102.96 Pounds
Weight Capacity	660 lbs
Material	Chenille Fabric, Eucalyptus Wood, Plywood, Foam
Backrest Positions	6 (90°, 105°, 120°, 135°, 150°, 180°)
Special Features	Adjustable 6-Position Backrest, RGB LED Light Strip
Assembly Required	Yes

Image 8.1: Detailed dimension diagram of the sofa bed.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact Polibi directly through their official channels. You can visit the Polibi Store on Amazon for more information.

Related Documents - **57.1" W Modern Chaise Lounge Sofa Bed**

Polibi MB-826SASS-G 82.6-inch L-Shape Sectional Sofa Assembly Instructions
Step-by-step assembly guide for the Polibi MB-826SASS-G 82.6-inch L-Shape 3-Seater Reversible Sectional Sofa. Includes a detailed parts list and clear instructions for each stage of assembly.

	[Assembly Instructions for Queen Size Upholstered Wood Platform Bed with Headboard and 2 Drawers](#) Step-by-step assembly instructions for a gray queen size upholstered wood platform bed with a headboard and two drawers. Includes safety warnings, part lists, hardware lists, and assembly steps.
	[Polibi Loft Bed Assembly Instructions (WF301849/301850)](#) Detailed assembly instructions for the Polibi Loft Bed, model numbers WF301849 and WF301850. Includes safety warnings, parts list, hardware list, and step-by-step guidance for building the metal house bunk bed with slide and staircase.
	[Assembly Instructions for WF197908/WF197909 Bunk Bed](#) Detailed assembly instructions for the WF197908/WF197909 bunk bed, including part lists, hardware details, and step-by-step guidance. Learn how to assemble your bunk bed safely and correctly.
	[House Bed Assembly Instructions WF286771](#) Assembly instructions for the House Bed, SKU Code WF286771. Includes part list, hardware list, and step-by-step assembly guide.
	[Polibi Bed Warranty Policy - RS519-8972AAK & HARI-232AAM	The Home Depot](#) This document outlines the 6-month warranty policy for Polibi furniture, including specific models like the RS519-8972AAK Murphy Bed and HARI-232AAM Canopy Platform Bed. It details the process for handling manufacturing defects and lists common exclusions such as accidental damage, unauthorized modifications, and purchases made outside The Home Depot Marketplace.