

[Manuals.plus](#) /

› [Ankilo](#) /

› Ankilo Bluetooth 5.3 Adapter for Airplane, TV, 3.5mm Audio Splitter

Ankilo CP317X1

Ankilo Bluetooth 5.3 Adapter (Model CP317X1) Instruction Manual

Brand: Ankilo | Model: CP317X1

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your Ankilo Bluetooth 5.3 Adapter, model CP317X1. This device functions as a 2-in-1 Bluetooth transmitter, allowing you to connect non-Bluetooth audio sources to Bluetooth headphones or speakers. Please read this manual thoroughly before operating the device.




Figure 1: Ankilo Bluetooth 5.3 Adapter overview with key components labeled.

SETUP AND PAIRING

Follow these steps to set up and pair your Ankilo Bluetooth adapter with your audio devices.

1. **Power On:** Press and hold the multifunction button (airplane icon) for 3 seconds to turn on the device. Indicator Light 1 will illuminate.
2. **Initial Pairing:** The adapter will automatically search for nearby Bluetooth headphones or speakers. Ensure your Bluetooth audio device is in pairing mode.
3. **Connect to Audio Source:** Insert the 3.5mm AUX plug into the AUX port of the adapter. Connect the other end of the AUX cable to your non-Bluetooth audio source (e.g., airplane entertainment system, TV, computer).
4. **Successful Connection:** After a successful connection to an audio device, Indicator Light 1 will remain steadily on, and Indicator Light 2 will turn off.
5. **Pairing a Second Device (Dual Connection):** To connect a second Bluetooth audio device, click the multifunction

button. The adapter will search for another device. Once connected, both Indicator Light 1 and Indicator Light 2 will turn on simultaneously.




Figure 2: Step-by-step guide for setting up and pairing the adapter.

OPERATING INSTRUCTIONS

Transmitter Mode (TX)

The Ankilo Bluetooth adapter operates exclusively in transmitter mode. It converts audio signals from non-Bluetooth devices into Bluetooth signals, allowing wireless transmission to Bluetooth headphones or speakers.

- **Single Device Connection:** Connect the adapter to your audio source via the 3.5mm AUX port. Pair your Bluetooth headphones or speaker. Audio will be transmitted wirelessly.
- **Dual Device Connection:** After connecting the first device, press the multifunction button to search for and pair a second Bluetooth device. Both devices will receive audio simultaneously. This is ideal for sharing audio with another person.
- **Power Off:** Press and hold the multifunction button for 3 seconds to turn off the device.



Figure 3: Using the adapter in an airplane environment to transmit audio to wireless headphones.

Battery and Charging

The adapter features a built-in rechargeable battery.

- **Charging:** Use the provided USB-C cable to charge the adapter. Connect the USB-C end to the adapter's charging interface and the other end to a USB power source.
- **Charging Time:** A full charge takes approximately 1 hour.
- **Battery Life:** A full charge provides up to 16 hours of continuous operation.

Lange Akkulaufzeit



16 Hour
Musik abspielen

240 mAh
Akkukapazität

1 Hour
Vollständig geladen

Type-C
Ladegerät

Figure 4: Battery life and charging details.

MAINTENANCE

To ensure the longevity and optimal performance of your Ankilo Bluetooth adapter, follow these maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Use the provided storage bag for protection during travel.
- **Charging:** Charge the device regularly, even if not in frequent use, to maintain battery health. Avoid overcharging or completely draining the battery for extended periods.
- **Handling:** Handle the device with care. Avoid dropping it or subjecting it to strong impacts.

TROUBLESHOOTING

If you encounter issues with your Ankilo Bluetooth adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the adapter using the provided USB-C cable.
Cannot pair with Bluetooth headphones/speakers.	- Headphones/speakers not in pairing mode. - Adapter too far from the audio device. - Interference from other devices.	- Ensure your audio device is in pairing mode. - Place the adapter and audio device closer together (within 10 meters). - Turn off other Bluetooth devices temporarily. - Restart both the adapter and the audio device.
No audio or poor audio quality.	- Incorrect AUX connection. - Volume too low on source or receiving device. - Adapter battery low.	- Ensure the 3.5mm AUX cable is securely connected to both the adapter and the audio source. - Adjust volume levels on both the source device and your Bluetooth headphones/speakers. - Charge the adapter.
Cannot connect a second device.	Second device not in pairing mode or already connected to another source.	Ensure the second Bluetooth device is in pairing mode and not connected to any other device. Press the multifunction button on the adapter to initiate search for the second device.

SPECIFICATIONS

Model Number	CP317X1
Brand	Ankilo
Bluetooth Version	5.3
Connectivity Technology	AUX, Bluetooth
Power Source	Battery Powered
Battery Type	1 Lithium Metal Battery (Rechargeable)
Battery Capacity	240 mAh
Charging Time	Approx. 1 hour (via USB-C)
Operating Time	Up to 16 hours
Material	Acrylonitrile Butadiene Styrene (ABS)
Dimensions (L x W x H)	20mm x 30mm x 50mm
Color	Black

Wireless Communication Standard	2.4 GHz Radio Frequency
Compatible Devices	Headphones, Computers, Smart TVs, Airplane Entertainment Systems
Special Feature	Connects two devices simultaneously
Control Method	Push Button
Box Contents	Bluetooth Transmitter Receiver, 1 Type-C Data Cable, 1 AUX Audio Cable, 1 Metal AUX Plug, 1 User Manual, 1 Storage Bag

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included in your product packaging or contact Ankilo customer service through your retailer. Keep your purchase receipt for warranty claims. For further assistance, please visit the official Ankilo website or contact your point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question