

CHOEZON MBC13

CHOEZON Bathroom Wall Cabinet Instruction Manual

Model: MBC13

1. INTRODUCTION

Thank you for choosing the CHOEZON Bathroom Wall Cabinet, Model MBC13. This cabinet is designed to provide versatile storage solutions for various rooms, including bathrooms, living rooms, and kitchens. It features both open and hidden storage compartments, adjustable shelves, and a convenient towel bar. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.



Image 1.1: The CHOEZON Bathroom Wall Cabinet (Model MBC13) installed in a bathroom setting, showcasing its storage capabilities above a sink.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all connections are securely fastened before use. Periodically check and re-tighten fasteners as needed.
- Do not overload the cabinet. Refer to the specifications section for weight limits.
- Mount the cabinet to a sturdy wall using appropriate hardware for your wall type. If unsure, consult a

professional.

- Avoid placing hot items directly on the cabinet surface.
- Clean with a soft, damp cloth. Avoid harsh chemicals that may damage the finish.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Cabinet Panels (various sizes)
- Adjustable Shelves (2)
- Towel Bar (1)
- Door Handles (2)
- Assembly Hardware (screws, dowels, cam locks, shelf pins, wall anchors, etc.)
- Instruction Manual (this document)

4. TOOLS REQUIRED FOR ASSEMBLY

- Phillips Head Screwdriver
- Hammer (for dowels)
- Drill (for wall mounting)
- Level
- Measuring Tape
- Pencil

5. SETUP AND ASSEMBLY INSTRUCTIONS

Follow the numbered steps carefully. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches.

5.1. Cabinet Dimensions and Overview




Image 5.1: Detailed dimensions of the cabinet (31.5"W x 7.9"D x 32.5"H) and adjustable shelf positions. Familiarize yourself with the cabinet's overall dimensions and the various components before starting. The diagram above illustrates the key measurements and the adjustable nature of the internal shelves.

5.2. Assembling the Main Frame

1. Identify all side panels, top, and bottom panels.
2. Attach cam locks and dowels to the designated holes on the panels as per the included assembly diagram.
3. Connect the side panels to the bottom panel, ensuring a snug fit. Secure with cam screws.
4. Insert the back panel into the grooves, if applicable, and secure.
5. Attach the top panel, securing it with cam screws.

5.3. Installing Shelves and Doors

1. Insert shelf pins into the desired holes for the adjustable shelves. The cabinet features multiple pre-drilled holes for customization.
2. Place the adjustable shelves onto the pins.
3. Attach the hinges to the cabinet doors and then to the main cabinet frame. Ensure doors open and close smoothly.
4. Install the door handles onto the cabinet doors.



Image 5.2: Key features including sturdy door locks, adjustable shelves, metal handles, and the towel bar.

5.4. Attaching the Towel Bar

1. Locate the pre-drilled holes on the underside of the cabinet for the towel bar.
2. Align the towel bar brackets with these holes and secure them using the provided screws.
3. Ensure the towel bar is firmly attached and level.

5.5. Wall Mounting

1. Determine the desired mounting height and location on your wall. Use a level and pencil to mark the positions for the mounting hardware.
2. Drill pilot holes into the wall at the marked locations. Use appropriate drill bits and wall anchors for your wall type (e.g., drywall, concrete).
3. Attach the wall mounting brackets to the wall using the provided screws and anchors.
4. Carefully lift the assembled cabinet and hook it onto the wall mounting brackets. Ensure it is securely seated and level.
5. For added stability, some models may include additional screws to secure the cabinet directly to the wall through internal bracing.



Image 5.3: Example installation of the cabinet above a toilet.

6. OPERATING INSTRUCTIONS

6.1. Utilizing Storage Compartments

The CHOEZON Wall Cabinet features a combination of open and concealed storage spaces. The left side offers three open shelves, ideal for frequently used items or decorative displays. The right side features two doors that open to reveal a hidden compartment with an adjustable shelf, suitable for items you wish to keep out of sight.



Image 6.1: Overview of the cabinet's six storage compartments.

6.2. Adjusting Shelves

The internal shelf within the concealed compartment is adjustable. To change its height, carefully remove

any items from the shelf. Lift the shelf slightly and remove the four shelf pins. Reinsert the pins into the desired set of holes, ensuring they are level, and then place the shelf back onto the pins.

6.3. Using the Towel Bar

The integrated towel bar at the bottom of the cabinet is designed to hold hand towels or small cloths, keeping them easily accessible.

7. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild soap solution and immediately dry with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Moisture:** In humid environments like bathrooms, ensure good ventilation to prevent moisture buildup, which can affect engineered wood products.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet feels wobbly after assembly.	Loose fasteners or improper wall mounting.	Ensure all cam screws and dowels are fully tightened. Verify wall mounting brackets are securely fastened to a stud or appropriate wall anchors.
Doors do not align or close properly.	Hinges are not adjusted correctly or cabinet is not level.	Adjust the screws on the hinges to align the doors. Ensure the cabinet is mounted level on the wall.
Missing parts.	Packaging error.	Contact CHOEZON customer support with your purchase details and a list of missing parts.

9. SPECIFICATIONS

Feature	Detail
Model Number	MBC13
Brand	CHOEZON
Material	Engineered Wood, Metal
Dimensions (D x W x H)	7.9" x 31.5" x 32.5" (20cm x 80cm x 82.5cm)
Mounting Type	Wall-mounted
Number of Doors	1 (double door appearance)
Number of Adjustable Shelves	2
Included Components	Shelves, Towel Bar

Feature	Detail
Assembly Required	Yes

10. PRODUCT VIDEO

Watch this official product video for a visual overview of the CHOEZON Bathroom Wall Cabinet.

Your browser does not support the video tag.

Video 10.1: An official video from CHOEZON DIRECT showcasing the Bathroom Wall Cabinet and its features.

11. WARRANTY AND SUPPORT

CHOEZON products are manufactured with quality and customer satisfaction in mind. For specific warranty information, please refer to the documentation included with your purchase or visit the official CHOEZON website. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact CHOEZON customer support through the retailer where you purchased the product or via the contact information provided on the CHOEZON brand store page.

For more CHOEZON products and support, visit the [CHOEZON Store on Amazon](#).