

Tangxi Tangxit4oak5i3gz-12

Tangxi Smart Glasses User Manual

Model: Tangxit4oak5i3gz-12

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Tangxi Smart Glasses. Please read this manual thoroughly before operating the device and retain it for future reference. These smart glasses integrate sun protection, anti-blue light filtering, open-ear audio, and smart touch controls for a versatile user experience.

2. SAFETY INFORMATION

- Do not expose the glasses to extreme temperatures or direct sunlight for extended periods.
- Avoid contact with water or other liquids to prevent damage to electronic components.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep out of reach of children.
- Use only the provided charging cable.
- Ensure the glasses are clean before wearing to maintain clear vision.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Tangxi Smart Glasses
- 1 x USB Charging Cable
- 1 x Cleaning Cloth
- 1 x Storage Bag
- 1 x User Manual (this document)



Image: Contents of the Tangxi Smart Glasses package.

4. PRODUCT OVERVIEW

The Tangxi Smart Glasses are designed for comfort and functionality. They feature integrated speakers and microphones for open-ear audio, touch controls on the temples, and advanced lenses.



Image: Front view of the Tangxi Smart Glasses.

Tri color selection

Multi color selection of smart life portable assistant



Image: Multiple color options for the smart glasses.

5.1 Charging the Glasses

Before initial use, fully charge your Tangxi Smart Glasses. A full charge takes approximately 1 hour.

1. Connect the provided USB charging cable to the magnetic charging port on the glasses.
2. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, wall adapter).
3. The indicator light will show charging status (refer to LED indicator section for details).

Magnetic charging

Fast charging



Image: Magnetic charging connection.

5.2 Powering On/Off

- **Power On:** Simultaneously press and hold the touch sensors on both the left and right temples for 3 seconds.
- **Power Off:** Press and hold the touch sensor on either the left or right temple for 5 seconds.

5.3 Bluetooth Pairing

To connect your Tangxi Smart Glasses to a device (smartphone, tablet, etc.):

1. Ensure the glasses are powered on and in pairing mode (indicator light will flash, refer to LED indicator section).
2. On your device, enable Bluetooth and search for available devices.
3. Select "Tangxi Smart Glasses" (or similar name) from the list.
4. Once connected, the indicator light will change (refer to LED indicator section). The effective range for connection is approximately 10 meters (32.81 feet).

6. OPERATING INSTRUCTIONS

6.1 Smart Touch Controls

The temples of the glasses are equipped with touch sensors for various functions:

Action	Command
Power On	Simultaneously press left and right for 3 seconds.
Shutdown	Long press for 5 seconds (left/right).
Play/Pause Music	Touch twice (left/right).
Previous Song	Click (left).
Next Song	Click (right).
Answer/Hang Up Call	Touch twice (left/right).
Refuse Call	Long press for 3 seconds (left/side).
Voice Assistant	Touch three times (left).
Volume Increase	Long press for 1.5 seconds (left).
Volume Decrease	Click (right).
Remote Control Photography	Touch three times (right).

Smart Touch Control

The mirror legs are equipped with touch sensors, which can be easily touched to answer calls
Various commands such as music playback, game connection, and microphone connection












 Power on Simultaneously press left and right for 3 seconds (left/right)	 Shutdown Long press for 5 seconds (left/right)	 Remote control photography Touch three times (right)
 Pause/Play Touch twice (left/right)	 Voice assistant Touch three times (left)	 Volume increase Long press for 1.5 seconds (left)
 Previous song Click (left)	 Next song Click (right)	 Volume down Click (right)
 Answer/hang up the phone Touch twice (left/right)	 Refuse to answer phone calls Long press for 3 seconds (left/side)	

Image: Detailed Smart Touch Control functions.

6.2 Lens Features

The Tangxi Smart Glasses are equipped with specialized lenses:

- **Sun Protection:** Lenses provide protection against harmful UV rays.
- **Anti-Blue Light Filter:** Reduces blue light exposure from digital screens.
- **Intelligent Color Changing (Photochromic):** Lenses automatically adjust their tint based on UV light exposure, becoming darker in bright sunlight and clearer indoors.

Intelligent color changing lenses

Change when exposed to light



Image: Demonstration of intelligent color-changing lenses.

INTELLIGENT AUDIO COLOR CHANGING GLASSES

Multi color selection of smart life portable assistant

Easy automatic pairing | Remote camera | Wireless audio call | Wake up voice assistant



Image: Smart glasses with color-changing lenses and key features.

7. MAINTENANCE

7.1 Cleaning

- Use the provided cleaning cloth to gently wipe the lenses and frame.
- For stubborn smudges, use a lens cleaning spray specifically designed for eyewear and a microfiber cloth.
- Avoid using abrasive materials or harsh chemicals, as these can damage the lenses and frame.

7.2 Storage

- When not in use, store the glasses in the provided storage bag or a protective case to prevent scratches and damage.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Glasses do not power on.	Low battery.	Charge the glasses for at least 1 hour.
Cannot connect via Bluetooth.	Glasses not in pairing mode; device Bluetooth off; out of range.	Ensure glasses are powered on and in pairing mode. Turn Bluetooth on your device. Move device closer to glasses (within 10m).
No sound from speakers.	Volume too low; not connected; media paused.	Increase volume using touch controls or connected device. Verify Bluetooth connection. Ensure media is playing.
Touch controls unresponsive.	Temporary software glitch; dirty sensor.	Power off and restart the glasses. Clean the touch sensor area on the temples.

9. SPECIFICATIONS

Feature	Detail
Product Material	PC+TAC
Battery Type	Lithium-ion Battery (Built-in)
Battery Capacity	70mAh x 2
Lens Type	Sun Protection, Anti-Blue Light Filter, Photochromic
Bluetooth Version	5.4
Effective Range	Approx. 10m / 32.81ft
Sensitivity	95±3dB
Playback Time	Up to 8 hours
Standby Time	Up to 200 hours
Charging Time	Approx. 1 hour
Model Number	Tangxit4oak5i3gz-12
Compatibility	Android, iOS

10. WARRANTY AND SUPPORT

Tangxi Smart Glasses come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or visit the official Tangxi website. For technical support, troubleshooting assistance, or warranty claims, please contact Tangxi customer service through their official channels.

You can find more information and support on the [Tangxi Store on Amazon](#).

11. USAGE SCENARIOS

The Tangxi Smart Glasses are suitable for various activities:

- **Office Use:** Manage calls and listen to audio discreetly.
- **Driving:** Hands-free communication and navigation audio.
- **Outdoor Activities:** Sun protection, music, and calls during sports, fishing, or relaxing.

Balancing Office and Leisure

Can be used for both office driving and outdoor leisure activities



Image: Examples of smart glasses usage in office and leisure settings.