

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LABIGO](#) /

› [LABIGO Upholstery & Carpet Cleaner Machine - Model KS-7915 User Manual](#)

LABIGO KS-7915

LABIGO Upholstery & Carpet Cleaner Machine - Model KS-7915

Instruction Manual

Sections:

[Introduction](#)

[Safety Instructions](#)

[Package Contents](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the LABIGO Upholstery & Carpet Cleaner Machine, Model KS-7915. This portable deep cleaning system is designed to effectively remove stubborn stains and refresh various fabric surfaces in your home and vehicle. Please read this manual thoroughly before initial use to ensure safe and optimal operation.



Image: The LABIGO Upholstery & Carpet Cleaner Machine, showing its main unit, hose, and cleaning attachments. The clean water tank is filled with blue liquid, and the dirty water tank is empty.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair,

and anything that may reduce airflow.

- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without tanks in place.
- Always connect to a properly grounded outlet.
- Do not exceed the maximum fill line on the water tanks, as this may reduce suction power.

3. PACKAGE CONTENTS

Please verify that all items are present in your package:

- LABIGO Upholstery & Carpet Cleaner Machine (Main Unit)
- Cleaning Brush Head
- Suction Nozzle (for tight spaces)
- Hose Assembly
- Power Cord
- Upper Power Cord Holder
- Lower Power Cord Holder
- Handle Holder

Enhance Cleaning with Concentrated Cleaner



Image: The LABIGO cleaner with its various components including the main unit, hose, brush head, and suction nozzle, along with cord and hose management accessories.

4. SETUP INSTRUCTIONS

4.1 Assembling the Cord and Hose Holders

1. **Install Power Cord Holders:** Insert the upper and lower power cord holders into their designated slots on the side of the main unit. Ensure they are securely clicked into place.
2. **Install Handle Holder:** Attach the handle holder to the main unit. This provides a convenient grip for carrying the machine.
3. **Install Hose Holder:** Secure the hose holder to the bottom of the main unit. This helps manage the hose when not in use.

Your browser does not support the video tag.

Video: Demonstrates the assembly of the power cord and hose holders, and general operation of the portable carpet cleaner.

4.2 Filling the Clean Water Tank

1. Remove the clean water tank from the main unit.
2. Open the water spout on the tank.
3. Fill the tank with clean water. You may add a suitable cleaning agent (e.g., carpet shampoo) to the water.
4. **Important:** Do not exceed the "MAX" fill line indicated on the tank. Overfilling can reduce suction power.
5. Close the water spout securely and place the clean water tank back onto the main unit.



Image: Illustrates the process of filling the clean water tank with water and cleaning solution, and the subsequent draining of the dirty water tank.

4.3 Attaching the Cleaning Head

Choose the appropriate cleaning head for your task:

- **Cleaning Brush Head:** For general upholstery and carpet cleaning.
- **Suction Nozzle:** For tight spaces, crevices, and picking up dry debris.

Attach the chosen cleaning head firmly to the end of the hose until it clicks into place.

5. OPERATING INSTRUCTIONS

5.1 General Cleaning Procedure (Spray, Scrub, Suction)

1. **Power On:** Plug the power cord into a grounded electrical outlet. Press the power button on the main unit to turn on the machine.
2. **Spray:** Hold the cleaning head over the stained area. Press the spray trigger on the handle to dispense cleaning solution onto the surface.
3. **Scrub:** Gently scrub the stained area with the brush head (if using the brush attachment) to loosen dirt and stains.
4. **Suction:** Release the spray trigger and slowly move the cleaning head over the treated area to suction up the dirty water. For best results, move the brush head back and forth repeatedly. Tilt the brush head (15°-45°) for optimal water pickup.
5. Repeat steps 2-4 as necessary until the stain is removed and the area is clean.

Clean Messes in 3 Easy Steps



Image: Visual representation of the three-step cleaning process: Spraying the solution, scrubbing the stain, and suctioning the dirty liquid.

5.2 Cleaning Different Surfaces

- **Carpets & Rugs:** Use the brush head for deep cleaning. Ensure the area is not oversaturated.
- **Upholstery (Sofas, Mattresses):** Use the brush head. Test on an inconspicuous area first to ensure colorfastness.
- **Pet Messes:** Address pet stains promptly. The powerful suction helps remove odors and residues.
- **Stairs & Car Interiors:** The compact design and various attachments make it suitable for hard-to-reach areas. Use the suction nozzle for crevices.

Cleans Every Corner



Couch Crevices



Seat Crevices



Pet Food Spills



Stair Corners

Image: Demonstrates the versatility of the cleaner in reaching and cleaning various tight spaces and surfaces, including couch crevices, car seats, pet food spills, and stair corners.



No More Messy Clean-Up!

Target spills and accidents in car interiors

Image: The LABIGO cleaner effectively removing a liquid spill from a light-colored car seat, highlighting its use for vehicle interiors.

6. MAINTENANCE

6.1 Emptying and Cleaning the Dirty Water Tank

After each use, or when the dirty water tank reaches its "MAX" fill line, it must be emptied and cleaned.

1. Turn off and unplug the machine.
2. Remove the dirty water tank from the main unit.
3. Carefully open the tank and pour out the dirty water.
4. Rinse the dirty water tank thoroughly with clean water.
5. Ensure all parts are dry before reassembling.



Image: Illustrates the process of filling the clean water tank with water and cleaning solution, and the subsequent draining of the dirty water tank.

6.2 Self-Cleaning Function

The machine features a self-cleaning function for the hose and brush head to prevent odors and maintain performance.

1. After emptying the dirty water tank, fill a bucket or measuring cup with clean water.
2. Place the cleaning head into the clean water.
3. Turn on the machine and press the spray trigger to draw clean water through the hose and cleaning head. Continue until the water being drawn into the dirty tank appears clean.
4. Turn off the machine and empty the dirty water tank again.

Your browser does not support the video tag.

Video: Demonstrates the self-cleaning function of the portable carpet cleaner by drawing clean water through the hose and cleaning head.

6.3 Storage

Once clean and dry, wrap the power cord around the integrated cord holders and secure the hose and attachments using the provided holders. Store the machine in a cool, dry place.



Easy to Storage



Portable & Compact

Image: Shows the compact design of the LABIGO cleaner, illustrating its ease of storage in a cabinet and portability for carrying up stairs.

7. TROUBLESHOOTING

If you encounter issues with your LABIGO Upholstery & Carpet Cleaner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Power	Machine not plugged in; Power outlet malfunction; Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button firmly.

Problem	Possible Cause	Solution
Weak or No Suction	Dirty water tank improperly seated; Dirty water tank overfilled; Hose or nozzle blockage; Filter clogged.	<p>Ensure the dirty water tank is correctly installed and sealed.</p> <p>Empty the dirty water tank if it exceeds the MAX line.</p> <p>Check the hose and nozzle for any obstructions and clear them.</p> <p>Clean the filter located in the dirty water tank.</p>
No Spray	Clean water tank empty; Clean water tank improperly seated; Spray nozzle clogged.	<p>Refill the clean water tank.</p> <p>Ensure the clean water tank is correctly installed.</p> <p>Check the spray nozzle for blockages and clean if necessary.</p>
Water Leaking	Tanks not properly sealed; Damaged tank or hose.	<p>Ensure both clean and dirty water tanks are securely closed and sealed.</p> <p>Inspect tanks and hose for cracks or damage. Contact support if damaged.</p>

Your browser does not support the video tag.

Video: Explains common reasons for suction loss and provides tips for maintaining strong suction with the LABIGO cleaner.

8. SPECIFICATIONS

Feature	Detail
Brand	LABIGO
Model Name	KS-7915
Item Model Number	KSRDE-7915-White
Suction Power	18Kpa
Clean Water Tank Capacity	1800ml
Dirty Water Tank Capacity	650ml
Item Weight	7.49 pounds (approx. 3.4 kg)
Package Dimensions	16.74 x 13.04 x 7.8 inches
Power	480W
Voltage	120V, 60Hz

9. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official LABIGO website. You may also contact the seller directly for assistance.

Protection plans are available for purchase separately. Please check product listings for details on 2-Year and 3-Year Protection Plans.

For further assistance, you can visit the [LABIGO Store on Amazon](#).
