



Manuals.plus /

› Generico /

› Generico Kids Watercolor Painting Book Set - Model TR8177RMQD690C37P Instruction Manual

## Generico TR8177RMQD690C37P

# Generico Kids Watercolor Painting Book Set - Model TR8177RMQD690C37P Instruction Manual

Enhance Creativity and Fine Motor Skills

## INTRODUCTION

This instruction manual provides guidance for the Generico Kids Watercolor Painting Book Set, Model TR8177RMQD690C37P. This portable art kit is designed to enhance fine motor skills and creativity in children. Each set includes a watercolor painting book and a brush.

The coloring books offer hours of colorful entertainment, promoting relaxation and creativity. Each finished page can also serve as a bookmark, encouraging young artists to create and stay organized. This set is an ideal gift for various occasions, fostering color recognition and hand-eye coordination.

The books are made with premium paper materials, ensuring durability and clear printing for long-lasting artistic expression. Their compact size makes them easy to carry, fitting conveniently into a backpack or pocket, making them a perfect travel companion for art on the go.

## SETUP

The Generico Kids Watercolor Painting Book Set is designed for immediate use with minimal setup.

1. **Unpack the Set:** Carefully remove the watercolor painting book and the brush from their packaging.
2. **Prepare Water:** You will need a small cup or container of clean water to activate the watercolors and clean the brush.
3. **Find a Workspace:** Choose a flat, stable surface for painting. It is recommended to cover the surface to protect it from water or paint spills.



Tappetino per pittura ad acquerello

Image: The compact size of the Generico Kids Watercolor Painting Book Set, shown fitting into a pocket, highlighting its portability.

## OPERATING INSTRUCTIONS

Follow these steps to begin painting with your Generico Kids Watercolor Painting Book Set:

1. **Wet the Brush:** Dip the brush into the clean water. Ensure the bristles are adequately wet but not dripping excessively.
2. **Activate Colors:** Gently touch the wet brush to the desired color strip within the painting book. The water will activate the pigment, allowing you to pick up color.
3. **Apply Color:** Apply the color to the designated areas on the coloring page. Use light strokes for a translucent effect or more paint for a bolder color.
4. **Change Colors:** Before switching to a new color, rinse the brush thoroughly in the water and gently blot it on a paper towel or cloth to remove excess water and previous color. This prevents colors from mixing unintentionally on the palette.
5. **Experiment:** Encourage experimentation with different amounts of water to achieve various shades and effects.




Image: A sequence showing the brush being dipped in water and then used to apply watercolor from the integrated paint strips onto the page.



Image: Two open watercolor painting books displaying various coloring pages and the integrated watercolor paint strips, ready for use.

## MAINTENANCE

Proper care will ensure the longevity of your painting set:

- **Brush Cleaning:** After each use, thoroughly rinse the brush with clean water until all paint residue is removed. Reshape the bristles and allow the brush to air dry completely before storing.
- **Book Storage:** Store the watercolor painting book in a dry place, away from direct sunlight and excessive humidity. Ensure pages are dry before closing the book to prevent sticking or mold.
- **Water Container:** Always use fresh, clean water for painting. Dispose of used water responsibly.

## TROUBLESHOOTING

- **Colors Not Appearing Vibrant:** Ensure the brush is sufficiently wet to activate the watercolor pigments. If the brush is too dry, it will pick up less color.

- **Paper Getting Too Wet/Warping:** Use a moderate amount of water. Excessive water can saturate the paper, causing it to warp or tear. Blot excess water from the brush before applying to the page.
- **Colors Mixing on the Page:** Clean the brush thoroughly between color changes. If colors are mixing unintentionally, it indicates residual paint on the brush.
- **Brush Bristles Losing Shape:** After cleaning, gently reshape the bristles with your fingers while they are still wet. Allow to dry flat or hanging downwards to maintain shape.

## SPECIFICATIONS

Feature	Detail
Brand	Generico
Model Number	TR8177RMQD690C37P
Item Weight	52 grams
ASIN	B0FNRTJBFH
Product Material	Paper
Product Dimensions (approx.)	19 cm x 8.2 cm (7.48 in x 3.23 in)
Package Contents	1 x Watercolor Painting Book, 1 x Brush






Image: The Generico Kids Watercolor Painting Book Set with its dimensions clearly indicated: 19cm (7.48in) in length and 8.2cm (3.22in) in width.

## WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not available in the provided product details. Please refer to the retailer or manufacturer's official website for specific warranty terms and support contact information.