

[Manuals.plus](#) /

› [radius](#) /

› radius HP-T10BT True Wireless Earphones User Manual

radius HP-T10BT

radius HP-T10BT True Wireless Earphones User Manual

Model: HP-T10BT

1. INTRODUCTION

Thank you for purchasing the radius HP-T10BT True Wireless Earphones. These compact and lightweight earphones are designed for comfortable wear and clear audio, featuring Bluetooth connectivity, hands-free calling, and splash-proof capabilities. This manual provides essential information for proper setup, operation, and maintenance of your device.

2. PACKAGE CONTENTS

Please ensure all items are present in the package:

- HP-T10BT True Wireless Earphones (Left and Right)
- Charging Case
- Ear Tips (S, M, L sizes) x 1 set each
- Charging Cable (USB-C to USB-A)
- Instruction Manual (includes Warranty Card)



Image: All included accessories, including the earphones, charging case, ear tips, and charging cable.

3. PRODUCT OVERVIEW

The radius HP-T10BT earphones are designed for portability and comfort. Their compact form factor ensures a snug fit for various ear sizes, while the lightweight design allows for extended wear without discomfort.



Image: A pair of blue radius HP-T10BT True Wireless Earphones, showcasing their compact design.



耳にすっきり収まる**軽やかな着け心地**

イヤホンはコンパクトなデザインで、耳にぴったりフィット。

女性や耳の小さな方でも快適に装着できます。

耳からの飛び出しが少なく、すっきりとしたシルエットに。

片耳わずか 3.3g の軽さで、長時間つけていても心地よいフィット感が続きます。

Image: A close-up of an earbud fitted in a person's ear, demonstrating its comfortable and secure placement.



耳にも指にもフィットするフォルム

イヤホン本体は指でつまみやすいフォルムを採用、耳への装着がスムーズに。
耳のくぼみにフィットする形状と、やわらかいイヤピースが優しく密着し、
安定した装着感を実現しました。

Image: An earbud being held by two fingers, emphasizing its small and ergonomic shape for easy handling and insertion.



手軽に持ち歩けるコンパクトな充電ケース

イヤホンだけでなく、充電ケースも軽くてコンパクト。
手のひらにすっぽり収まるサイズで、小さなバッグやポケットにもすっきり収納できます。
通勤や通学はもちろん、ちょっとしたお出かけにも手軽に持ち歩けます。

Image: A hand placing the compact charging case into a small handbag, illustrating its portability.

4. SETUP

4.1 Charging the Earphones and Case

1. Place the earphones into the charging case. Ensure they are correctly seated.
2. Connect the USB-C end of the charging cable to the charging port on the case and the USB-A end to a compatible USB power source (e.g., computer, USB wall adapter).
3. The indicator light on the charging case will show the charging status. A full charge takes approximately 1 hour.

4.2 Bluetooth Pairing

1. Ensure the earphones are charged.
2. Open the charging case. The earphones will automatically enter pairing mode, indicated by a flashing LED light on the earbuds.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "HP-T10BT" from the list of found devices.
5. Once connected, the LED indicator on the earphones will stop flashing or change to a steady light, depending on the

model.


5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Open the charging case, and the earphones will power on automatically.
- **Power Off:** Place the earphones back into the charging case and close the lid. They will power off automatically.

5.2 Music Playback

The HP-T10BT earphones support basic music controls via touch sensors on the earbuds. Refer to the detailed instructions in the included manual for specific touch commands for play/pause, track skipping, and volume adjustment.



小さくてもこだわりの高音質

コンパクトながら、音の細部までこだわったクリアなサウンド。

深みのある低音と、透き通るような中高音が、

お気に入りの J-POP やアニソンを心地よく響かせます。

AAC コーデック対応で、iPhone やスマートフォンでも高音質で楽しめます。

Image: Pink earbuds positioned near a smartphone screen showing a music application, illustrating high-quality sound delivery.

5.3 Hands-Free Calling

When connected to a smartphone, you can use the earphones for hands-free calls. Incoming calls can be answered or ended using the touch controls on the earphones. This feature is convenient for use during commutes, remote work, or

online classes.



ハンズフリー通話で、もっと自由に

音楽を聴いているときの着信も、タッチ操作でスマートに対応。
外出先や家事の合間でも、友人や家族と快適に通話できます。
PCやタブレットと接続すれば、オンライン授業やリモートワークでも活躍。
シーンを選ばずに使用できます。

Image: A woman smiling and wearing earbuds while looking at a laptop, demonstrating hands-free communication.

5.4 Single Ear Mode

The HP-T10BT supports single ear mode, allowing you to use just one earphone while the other charges in the case. This is useful for maintaining awareness of your surroundings or extending listening time by alternating earbuds.



さっと使える片耳モード

片側のイヤホンを充電しながら音楽や通話を楽しむ「片耳モード」を搭載。
片側だけ取り出したり、片側だけ充電ケースに戻したりすることで、
簡単にモードを切り替えられます。
周囲の音を気にしながら使いたいときにも便利です。

Image: A hand placing a pink earbud into its open charging case, highlighting the convenience of using one earbud at a time.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the ear tips and earphone surfaces with a soft, dry cloth.
- Remove ear tips and clean any earwax or debris from the earphone nozzles using a small brush or cotton swab.
- Ensure the charging contacts on both the earphones and the case are clean and free of dust to ensure proper charging.

6.2 Storage

- Always store the earphones in their charging case when not in use to protect them and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

6.3 Water Resistance (IPX4)

The HP-T10BT earphones feature IPX4 splash resistance, meaning they are protected against splashing water from any direction. This makes them suitable for outdoor activities or during light rain and sweat. **Note:** IPX4 does not mean they

are fully waterproof. Do not submerge the earphones in water.



雨や汗も気にせず使える防滴仕様

IPX4の防滴性能なので、急な雨や運動時の汗も気になりません。
アウトドアやランニングなど、アクティブなシーンでも快適に使用できます。

※IPX4：あらゆる方向からの飛沫を受けても有害な影響を受けない。(防沫形)

※完全防水ではありません。水没させないでください。

Image: Blue earbuds with small water droplets on their surface, demonstrating their IPX4 splash-proof design.

7. TROUBLESHOOTING

If you encounter issues with your HP-T10BT earphones, please try the following solutions:

- **No Power:** Ensure the earphones and charging case are fully charged.
- **Cannot Pair:**
 - Make sure Bluetooth is enabled on your device.
 - Ensure the earphones are in pairing mode (LED flashing).
 - Turn off Bluetooth on other nearby devices that might be trying to connect.
 - Try resetting the earphones (refer to the full instruction manual for specific reset procedures).
- **No Sound/Low Volume:**
 - Check the volume levels on both your earphones and your connected device.

- Ensure the earphones are properly seated in your ears.
- Clean any debris from the earphone nozzles and ear tips.

- **Intermittent Connection:**

- Move closer to your connected device to reduce interference.
- Avoid environments with strong Wi-Fi or other wireless signals.

If the problem persists, please consult the comprehensive instruction manual or contact customer support.

8. SPECIFICATIONS

Model Name	HP-T10BT (tiny Series)
Connectivity Technology	Wireless (Bluetooth)
Noise Control	None
Impedance	32 Ohms
Charging Time	Approximately 1 Hour
Water Resistance Level	IPX4 (Splash-proof)
Included Components	Ear Tips (S, M, L) x 1 set each, Charging Cable (USB-C to USB-A), Instruction Manual (Warranty Card)
Package Dimensions	10.4 x 10.1 x 5.7 cm
Item Weight	110 g

9. WARRANTY AND SUPPORT

radius products undergo thorough inspection, firmware updates, and periodic recharging before shipment to ensure quality. Therefore, you may find products that have been temporarily opened, but they are unused and meet quality standards. Your understanding is appreciated.

Purchases are covered by warranty if made from radius official stores or authorized dealers such as Kojima, Sofmap, e☆earphone, and Yamada Denki. Products sold by other businesses are not covered by the warranty. Please confirm the seller before making your purchase.

For detailed warranty information and support, please refer to the included instruction manual or visit the official radius website.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question