

WYBOT C2

WYBOT C2 Cordless Robotic Pool Cleaner Instruction Manual

1. PRODUCT OVERVIEW

The WYBOT C2 is a cordless robotic pool cleaner designed for efficient and autonomous cleaning of inground and above-ground pools. It features a dual filtration system, powerful triple-motor suction, smart navigation, and app control for a comprehensive cleaning experience.




Image: The WYBOT C2 robotic pool cleaner, showcasing its compact design and the WYBOT logo.

2. SETUP

2.1 Unpacking and Initial Charge

Carefully remove all components from the packaging. Ensure the charging port is securely closed before placing the cleaner in water. Fully charge the unit before its first use. Charging time is approximately 3-3.5 hours.

Smart Weekly Timer

Up to 4 Cleaning Cycles in 7 Days




Image: The WYBOT C2 robotic pool cleaner being charged with its power adapter.

2.2 Placing the Cleaner in the Pool

Once charged, press the power button to activate the cleaner. Gently submerge the unit into the pool. The cleaner will begin its default cleaning cycle automatically.

Dual Filtration System

Capturing every speck of dirt




Image: A person carefully lowering the WYBOT C2 robotic pool cleaner into the pool.

3. OPERATING INSTRUCTIONS

3.1 Smart Navigation and Cleaning Modes

The WYBOT C2 utilizes a built-in gyroscope for intelligent path planning, ensuring efficient coverage of your pool's floor, walls, and waterline. It avoids random movement, optimizing the cleaning process.

Intelligent Path Optimization

From floor to walls — fully automated



Image: Diagram illustrating the N-Shape, H-Shape, and S-Shape patterns for wall cleaning, and S-Shape, Cross-Pattern, and Star-Pattern for floor cleaning.

The cleaner offers 7 distinct cleaning modes and 4 cycling timers. These can be preset via the WYBOT App to automatically clean your pool. Available modes include: Floor (2H), Wall, Wall Then Floor, Eco Floor (3H), Water Line, Standard Full-Pool, and Turbo Floor (1H).



Image: Visual representation of the 7 cleaning modes available for the WYBOT C2.

3.2 App Control and Scheduling

Download the WYBOT App to access advanced features such as scheduling cleaning sessions, selecting different cleaning paths, and choosing between various cleaning modes. The app allows for full control and customization of your cleaning experience.

Use with WYBOT APP



Preset pool shape/material



4 Cycle Timer




Battery Monitoring



6 Path Planning



7 Cleaning Mode





Note: Support Bluetooth connection and preset the robotic pool cleaner's clean mode while it on the shore.

Image: A smartphone displaying the WYBOT App interface, showing options for cleaning modes and scheduling. The cleaner can operate for up to 180 minutes in Echo mode, covering pools up to 2152 sq.ft with a water depth of 9.84ft. It features self-parking technology, automatically moving near the pool edge for easy retrieval once cleaning is complete or the battery is low.

180 mins Running Time

3-hour Charging Time

Shorten Your Waiting Time

180 mins



WYBOT C2

 Runtime: 180 mins

 Cleaning Area: 2152 Sq.ft



Others

 Runtime: 150 mins

 Cleaning Area: 1600 Sq.ft

Image: The WYBOT C2 robotic pool cleaner in the pool, highlighting its 180-minute runtime and self-parking feature.

3.3 LED Indicators

The unit is equipped with LED indicators to communicate its status:

- **Blue Light:** Solid indicates Power On; Flashing indicates Under Working.
- **Green Light:** Solid indicates Fully Charged; Flashing indicates Charging in Progress.
- **Purple Light:** Solid indicates Connecting to App.



4. MAINTENANCE

4.1 Dual Filtration System

The WYBOT C2 features a dual-layer filtration system, combining a 180µm basket filter for larger debris (leaves, twigs) and a 10µm ultra-fine filter for fine particles (sand, dust, algae). This system ensures thorough cleaning and clear water.



Image: Illustration of the WYBOT C2's dual filtration system, showing the 180µm basket filter and 10µm ultra-fine filter capturing various debris types.

4.2 Cleaning the Filter Basket

The filter is washable, reusable, and replaceable. After each cleaning cycle, remove the filter basket and rinse it thoroughly with water to remove collected debris. Regular cleaning maintains optimal suction and filtration performance.

Newly Brushless Motor System

Powerful, Efficient, and Durable



2.5X ↑
Increasing Cleaning
Efficiency



3X ↑
Longer Lifespan



2X ↑
Longer Runtime




Image: A person removing and cleaning the filter basket of the WYBOT C2, showing collected leaves and fine debris.

5. TROUBLESHOOTING

5.1 General Cleaning Performance Issues

- **Incomplete Coverage:** Ensure the pool cleaner is fully charged. Verify that the selected cleaning mode is appropriate for your pool's shape and size. The smart navigation system plans paths, but complex pool designs may require specific mode adjustments.
- **Fine Debris/Silt Not Fully Captured:** Regularly clean both layers of the dual filtration system. If fine particles are still an issue, ensure the 10µm ultra-fine filter is correctly installed and not clogged.
- **Reduced Suction:** Check the filter basket for excessive debris. A clogged filter can significantly reduce suction power. Clean the brushes to ensure they are free from hair or other obstructions.

5.2 Movement and Navigation Issues

- **Difficulty Climbing Walls/Waterline:** Ensure the pool cleaner's brushes are clean and in good condition. Verify the

water chemistry is balanced, as excessive algae can reduce grip.

- **Erratic Movement:** The built-in gyroscope should prevent random movement. If the cleaner is moving erratically, try restarting the unit and ensuring a clear path. Check the app for any diagnostic messages.

5.3 App Connectivity Issues

- **Unable to Connect to App:** Ensure the cleaner is powered on and within Bluetooth range. Restart both the cleaner and your mobile device. Check for app updates.

6. SPECIFICATIONS

Feature	Detail
Brand	WYBOT
Model Name	C2
Material	Plastic
Color	Grey&Green
Product Dimensions	17"L x 16"W x 11"H
Power Source	Battery Powered
Dual Filtration System	180µm + 10µm
Control Method	App
Charging Time	3-3.5 Hours
Runtime (Echo Mode)	Up to 180 Minutes
Max Cleaning Area	2152 sq.ft
Max Water Depth	9.84 ft

7. WARRANTY AND SUPPORT

The WYBOT C2 cordless robotic pool cleaner comes with a 2-year product warranty. For any technical support or customer service inquiries, please contact WYBOT customer support.

8. OFFICIAL PRODUCT VIDEOS

Full Cleaning Coverage for All Pool Types

Your browser does not support the video tag.

Video: This video demonstrates the WYBOT C2's ability to provide full cleaning coverage for various pool types, including floor, wall, and waterline cleaning.

More Modes Through WYBOT App

Your browser does not support the video tag.

Video: This video highlights the additional cleaning modes and customization options available through the WYBOT mobile application.

WYBOT Cordless Robotic Pool Cleaner Is Fast And Efficient!

Your browser does not support the video tag.

Video: This video showcases the speed and efficiency of the WYBOT C2 cordless robotic pool cleaner in action.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question