

Huuger 63 x 55 Inch L Shaped Standing Desk

Huuger 63 x 55 Inch L Shaped Standing Desk Instruction Manual

Model: 63 x 55 Inch L Shaped Standing Desk

Brand: Huuger

[Assembly](#) [Operation](#) [Maintenance](#) [Overview](#) [Setup &](#)
[Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

The Huuger L Shaped Standing Desk offers a versatile workspace with adjustable height and a reversible design. It is equipped with integrated power outlets for convenience and features a robust construction for stability.

- **Adjustable Height:** Easily switch between sitting and standing positions with a height range of 28.3" to 46.5".
- **Reversible L-Shaped Design:** Maximize your desktop space (63 x 55.1 inches) and configure the L-shape on either the left or right side to fit your room layout.
- **Built-In Charging Station:** Features 4 AC outlets, 1 USB-A port, and 1 USB-C port to power your devices directly from the desk.
- **Smooth Motor Lift with Memory Presets:** A powerful motor ensures quiet and stable height adjustments. Save up to 3 preferred height settings for quick transitions.
- **Cable Management & Hooks:** Includes a cable management tray and two side headphone hooks to keep your workspace organized.
- **Durable Construction:** Made from sturdy particleboard and solid steel legs, designed for long-lasting stability and a load-bearing capacity of up to 260 lbs.



Image 1.1: The Huuger L Shaped Standing Desk in White, showcasing its spacious design.

2. SETUP & ASSEMBLY

Assembly of the Huuger L Shaped Standing Desk is designed to be straightforward. All parts are clearly numbered, and a detailed manual with installation tools is included. It is recommended to have assistance during assembly due to the size and weight of the components.

2.1 Unpacking and Component Check

1. Carefully unpack all components from the packaging.
2. Verify that all parts listed in the included manual are present and undamaged. Refer to the parts list in your manual.
3. Place all components on a soft, clean surface to prevent scratches during assembly.

2.2 Assembly Steps (General Guidance)

1. **Assemble the Desk Legs:** Attach the feet to the bottom of the desk legs using the provided screws. Ensure they are securely fastened.
2. **Connect the Crossbars:** Attach the crossbars between the desk legs. These provide structural support and house the motor mechanism.
3. **Install the Motor and Drive Shafts:** Carefully install the motor and connect the drive shafts to the lifting

columns. Ensure the drive shafts are fully extended and properly seated.

4. **Attach the Desktop Panels:** Place the desktop panels onto the assembled frame. Secure them using the designated screws. Note the reversible design allows you to choose the orientation of the L-shape (left or right).
5. **Install the Control Panel:** Mount the control panel to the underside of the desktop in the designated location. Connect its cable to the motor control box.
6. **Install the Power Strip:** Secure the built-in power strip to the underside of the desk. Connect its power cable to the control box.
7. **Attach Accessories:** Install the cable management tray and headphone hooks as desired.
8. **Cable Management:** Route all cables neatly using the cable management tray and any included ties to prevent tangling and ensure safe operation.



Image 2.1: Desk dimensions and illustration of the reversible L-shaped design.

3. OPERATING INSTRUCTIONS

This section details how to operate your Huuger L Shaped Standing Desk, including height adjustment and using the memory presets and integrated power outlets.

3.1 Height Adjustment

The desk features an electric motor for smooth height adjustments between 28.3" (minimum) and 46.5" (maximum).

1. **Raise the Desk:** Press and hold the **Up Arrow (^)** button on the control panel. The desk will move upwards. Release the button when the desired height is reached.
2. **Lower the Desk:** Press and hold the **Down Arrow (v)** button on the control panel. The desk will move downwards. Release the button when the desired height is reached.
3. The LED display on the control panel shows the current desk height.



Image 3.1: Illustration of the desk's adjustable height range.

3.2 Memory Presets

The control panel allows you to save up to three preferred height settings for quick and easy transitions.

1. Set a Memory Position:

- Adjust the desk to your desired height using the Up/Down buttons.
- Press the **"M"** button (or similar memory set button, if present, otherwise assume direct press). The display may flash "S-" or similar.
- Immediately press one of the numbered preset buttons (**1, 2, or 3**) to save the current height to that position. The display will confirm the setting.

- Recall a Memory Position:** Simply press the desired numbered preset button (**1, 2, or 3**). The desk will automatically move to the saved height.



Image 3.2: The desk's control panel, showing height display and memory preset buttons.


3.3 Built-In Charging Station

The desk includes a convenient power strip to charge your electronic devices.

- The charging station provides 4 AC outlets (20V/12A), 1 USB-A port (5V/3A), and 1 USB-C port (5V/3A).
- Plug your devices directly into the appropriate ports on the power strip.
- Ensure the desk is connected to a wall outlet for the charging station to function.

Built-In Power Strip

• Charge Up to 6 Devices at Once



4 AC Outlets
20V/12A



1 USB Port
5V/3A



1 USB-C Port
5V/3A

Image 3.3: The integrated power strip for convenient device charging.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Huuger L Shaped Standing Desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cable Management:** Periodically check and reorganize cables to prevent tangling and ensure they do not interfere with the desk's movement.
- **Fasteners:** Occasionally check all screws and bolts to ensure they are tight. Retighten if necessary.

- **Motor Inspection:** Listen for any unusual noises during height adjustment. If you notice any issues, refer to the troubleshooting section or contact customer support.

5. TROUBLESHOOTING

If you encounter any issues with your Huuger L Shaped Standing Desk, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Desk does not move or respond to control panel.	• Power cable disconnected. • Control panel cable loose. • Overload protection activated.	• Check if the power cable is securely plugged into the wall outlet and the desk's control box. • Ensure all cables connected to the control panel and motor are secure. • Unplug the desk for 20 minutes, then plug it back in to reset. Reduce weight on the desk.
Desk moves unevenly or makes unusual noises.	• Uneven weight distribution. • Loose connections in the lifting mechanism. • Drive shafts not fully extended or properly seated.	• Distribute weight evenly across the desktop. • Check all assembly points, especially where legs connect to the frame and motor. • Ensure drive shafts are correctly installed and fully extended as per assembly instructions.
Memory presets are not working.	• Incorrect saving procedure. • Temporary control panel glitch.	• Review "3.2 Memory Presets" section and repeat the saving process carefully. • Perform a reset by unplugging the desk for a few minutes and then plugging it back in.
Power outlets are not providing power.	• Desk not plugged into wall outlet. • Power strip cable disconnected. • Overload on power strip.	• Ensure the main power cable from the desk is securely plugged into a functional wall outlet. • Check the connection of the power strip to the desk's control box. • Unplug some devices from the power strip and try again.

6. SPECIFICATIONS

Detailed technical specifications for the Huuger L Shaped Standing Desk.

Feature	Detail
Brand	Huuger
Model	63 x 55 Inch L Shaped Standing Desk
Product Dimensions	55.12"D x 63"W x 28.35"H (L-shape configuration)
Height Adjustment Range	28.3" - 46.5"
Desktop Material	Engineered Wood
Base Material	Metal (Solid Steel Legs)
Load-Bearing Capacity	Up to 260 lbs
Noise Level (Operation)	Under 45dB
Power Outlets	4 AC Outlets (20V/12A), 1 USB-A Port (5V/3A), 1 USB-C Port (5V/3A)
Special Features	3 Memory Presets, Reversible Design, Anti-Collision System, Cable Management Tray, Headphone Hooks
Assembly Required	Yes (Instructions Included)



Excellent Load-bearing Capacity

Supporting Every One of Your Needs

Image 6.1: The desk's robust construction supports up to 260 lbs.

Better Quality, Worth of Trust




Upgraded Hardware + Solid Desk Legs

 **Ours**



Rock-solid stability, no shaking!

 **Others**



Wobbles easily, items fall off!

Image 6.2: Illustration of the upgraded hardware and solid desk legs ensuring stability.

7. WARRANTY & SUPPORT

Huuger is committed to providing high-quality products and customer satisfaction.

7.1 Warranty Information

Please refer to the warranty card included with your product for specific warranty terms and conditions. Generally, Huuger products are covered against manufacturing defects for a specified period from the date of purchase. Keep your proof of purchase for warranty claims.

7.2 Customer Support

If you have any questions, require assistance with assembly, or experience any issues not covered in the troubleshooting section, please contact Huuger customer support:

- **Email:** [Insert Customer Support Email Here]
- **Phone:** [Insert Customer Support Phone Number Here]
- **Website:** Visit the official Huuger website for FAQs and additional support resources.

When contacting support, please have your product model number and purchase date ready.