

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [MEPTY](#) /

› MEPTY 1500W Oil Filled Radiator Heater User Manual

MEPTY B0FNWGWD7J

MEPTY 1500W Oil Filled Radiator Heater User Manual

Model: B0FNWGWD7J

1. INTRODUCTION

Thank you for choosing the MEPTY 1500W Oil Filled Radiator Heater. This manual provides essential information for the safe and efficient operation of your new heater. Please read it thoroughly before use and retain it for future reference.

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This heater includes a **Tip-Over Protection** feature that automatically shuts off the heater if it is accidentally tipped over.
- The heater is constructed with **V0 flame retardant material** for enhanced safety.

- An **Overheat Protection** system is integrated to prevent the heater from reaching unsafe temperatures.
- Equipped with a **safety plug** for secure electrical connection.

3. PRODUCT OVERVIEW

The MEPTY Oil Filled Radiator Heater is designed to provide efficient and quiet heating for various indoor spaces. It features a user-friendly design with multiple safety mechanisms.

Key Features:

- **Radiant Heat:** Utilizes oil-filled fins to provide silent, consistent warmth without drying out the air.
- **High Efficiency:** Engineered for superior performance, delivering up to 92.3% greater heat efficiency.
- **Even Heat Distribution:** Designed with 6 fins and an increased radiating surface for pervasive warmth.
- **Digital Controls & Remote:** Easy temperature adjustment and mode selection via touchscreen or remote control.
- **Pre-assembled Wheels & Handles:** For effortless portability and movement between rooms.
- **24-Hour Timer:** Allows for scheduled operation to pre-heat spaces.
- **ECO Mode:** Optimizes energy consumption for savings.

Boosted Warmth Amplified Comfort



Unique Thermal Slot

Up to **75%** ↑
Dissipation Area




Figure 1: Front view of the MEPTY Oil Filled Radiator Heater.

MEPTY | Radiator Heater

**All-out Heat.
Ultimate Comfort.**



Figure 2: The heater providing warmth in a large room, demonstrating its heating efficiency.

4. SETUP

4.1 Unpacking

Carefully remove the heater from its packaging. Inspect the unit for any signs of damage. Ensure all components, including the remote control, are present. The remote control is typically secured within the packaging foam.

Your browser does not support the video tag.

Video 1: Overview of the MEPTY 1500W Oil Filled Radiator Heater, demonstrating its features and ease of use.

4.2 Wheel Assembly

The wheels are pre-assembled and designed for easy deployment. Simply pull them out from the base of the heater until they lock into position. This allows for smooth movement of the unit.



Figure 3: Detail of the pre-assembled wheels and integrated cord winder for convenient storage.

4.3 Placement

Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 meters) of clear space around the heater to allow for proper air circulation and to prevent fire hazards. Do not place the heater on soft surfaces like rugs or carpets that may block the air vents.

4.4 Power Connection

Plug the heater directly into a 120V AC, 60Hz wall outlet. Do not use extension cords or power strips.

5. OPERATING INSTRUCTIONS

The heater can be operated using the integrated touchscreen controls or the included remote control.

5.1 Power On/Off

Press the **Power button**  on the control panel or remote to turn the heater on or off.

5.2 Temperature Adjustment

Use the **Plus (+)** and **Minus (-)** buttons to set your desired temperature. The temperature range is 41°F to 95°F (5°C to 35°C). The heater will automatically maintain the set temperature.

Save Energy & Precise Temp Control



Figure 4: Digital display showing temperature control and an illustration of energy savings with ECO mode.

5.3 Heating Modes

The heater offers four heating modes for customized comfort:

- **ECO Mode:** Automatically adjusts power consumption to maintain the set temperature efficiently, saving energy.
- **600W Mode:** Low heat setting for smaller spaces or maintaining warmth.
- **900W Mode:** Medium heat setting for moderate warmth.
- **1500W Mode:** High heat setting for rapid heating of larger rooms.

5.4 Silent Mode

Press the **Silent Mode button** (often represented by a speaker icon) to mute button press sounds and dim the display lights, ideal for nighttime use in bedrooms.



Figure 5: The heater operating silently in a bedroom, ensuring undisturbed sleep.

5.5 24-Hour Timer

Activate the 24-hour timer function to set a specific duration for the heater to operate before automatically turning off. This feature is useful for pre-heating a room or ensuring the heater turns off after you fall asleep.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

6.1 Cleaning

- Always unplug the heater and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater.
- Do not use abrasive cleaners or solvents, as these may damage the surface.
- Ensure no water or liquid enters the interior of the heater.

6.2 Storage

When not in use, store the heater in a cool, dry place. You can use the integrated cord winder to neatly store the power cord.

7. TROUBLESHOOTING

If your heater is not operating correctly, please check the following common issues before contacting support:

- **Heater does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the tip-over protection has been activated (if the heater was moved or tilted).
- **No heat output:** Verify that the desired temperature setting is higher than the current room temperature. Check the selected heating mode.
- **Heater shuts off unexpectedly:** This may be due to the overheat protection or tip-over protection activating. Allow the heater to cool down and ensure it is on a stable, level surface with adequate clearance.
- **Remote control not working:** Check if the remote control batteries (2x AAA, not included) need replacement. Ensure there are no obstructions between the remote and the heater's sensor.

If the problem persists after checking these points, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	MEPTY
Model Number	B0FNWGWD7J
Heat Output	1500 Watts
Voltage	120 Volts

Feature	Detail
Fuel Type	Electric
Burner Type	Radiant
Product Dimensions	15.4"D x 10.5"W x 26.5"H
Color	Black
Indoor/Outdoor Usage	Indoor
Special Features	Adjustable Temperature, Energy Efficient, Noiseless, Tip-Over Protection, Wheels
Max Temperature Setting	54 Degrees Celsius (129.2°F)
Recommended Uses	Home, Office (Bedroom, Home Office, Kids Room, Living Room)

9. WARRANTY AND SUPPORT

MEPTY products are designed for reliability and performance. For specific warranty details, please refer to the warranty card included with your product or visit the official MEPTY website.

If you encounter any issues or have questions regarding your MEPTY Oil Filled Radiator Heater, please contact our customer support team. Have your model number (B0FNWGWD7J) and purchase date ready for faster service.

Customer Support:

- Refer to your product packaging or the MEPTY official website for contact information.