

[Manuals.plus](#) /

› [Fusion5](#) /

› Fusion5 FWIN232 PRO N5 10.1" Rugged Windows 11 Professional Tablet PC User Manual

Fusion5 FWIN232 PRO N5

Fusion5 FWIN232 PRO N5 10.1" Rugged Windows 11 Professional Tablet PC User Manual

Model: FWIN232 PRO N5

INTRODUCTION

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Fusion5 FWIN232 PRO N5 10.1" Rugged Windows 11 Professional Tablet PC. Please read this guide thoroughly to ensure proper use and to maximize the lifespan of your device.

The Fusion5 FWIN232 PRO N5 is a robust tablet designed for demanding environments, featuring a 10.1-inch Full HD IPS touchscreen, Intel 13th Gen processor, 12GB RAM, and 512GB SSD, running Windows 11 Professional.

WHAT'S IN THE BOX

- Fusion5 FWIN232 PRO N5 Tablet PC
- Charger (30W Type-C fast charger)
- User Manual

Please inspect all contents upon unboxing. If any items are missing or damaged, contact customer support immediately.

DEVICE OVERVIEW

Familiarize yourself with the tablet's physical features and ports.

Full connectivity

Certified for WiFi, HDMI, Bluetooth, and SD Card, Fusion5 delivers trusted quality every time.



Image: Overview of the Fusion5 tablet's ports, including Micro SD Slot, Charging Port, Micro HDMI, USB 3.0, USB Type-C, Volume buttons, and Headphone Jack.

1. **Micro SD Slot:** For expandable storage up to 512GB.
2. **Charging Port:** USB Type-C for charging.
3. **Micro HDMI:** For connecting to external displays.
4. **USB 3.0:** For connecting USB devices.
5. **USB Type-C:** Multi-functional port for data and charging.
6. **Volume Buttons:** Adjust audio output.
7. **Power Button:** Turn the device on/off or put it to sleep.
8. **Headphone Jack:** 3.5mm audio output.

SETUP

1. Initial Charging

Before first use, fully charge your tablet using the provided 30W Type-C fast charger. Connect the charger to the USB Type-C port on the tablet and plug it into a power outlet. The charging indicator will illuminate.

2. Power On/Off

- To power on: Press and hold the **Power Button** until the Fusion5 logo appears.
- To power off: Press and hold the **Power Button**, then select "Shut down" from the Windows menu. Alternatively, go to Start > Power > Shut down.
- To sleep/wake: Briefly press the **Power Button**.

3. Initial Windows 11 Setup

Follow the on-screen prompts to complete the Windows 11 Professional setup. This includes selecting your region, language, connecting to a Wi-Fi network, and creating a user account.

Your browser does not support the video tag.

Video: This video demonstrates the initial setup and features of the Fusion5 10.1" Windows 11 Pro Rugged Tablet, including its operating system and hardware specifications.

OPERATING INSTRUCTIONS

Touchscreen Navigation

The 10.1" Full HD IPS touchscreen supports multi-touch gestures. Use standard Windows touch gestures for navigation, scrolling, zooming, and interacting with applications.



Image: The tablet's responsive capacitive touchscreen for accurate and instant control.

Connectivity (Wi-Fi and Bluetooth)

- **Wi-Fi:** Access Wi-Fi settings via the Windows Action Center or Settings > Network & Internet > Wi-Fi. The tablet supports dual-band Wi-Fi (2.4GHz/5GHz) for stable connections.
- **Bluetooth 5.0:** Enable Bluetooth in Settings > Bluetooth & devices to pair with compatible accessories like keyboards, mice, or headphones.

Using the Cameras

The tablet features dual Full HD cameras. Use the built-in Camera app in Windows to capture photos and videos or for video calls.

Expandable Storage

Insert a microSD card (up to 512GB) into the Micro SD Slot to expand the tablet's storage capacity. Ensure the card is inserted correctly until it clicks into place.

Hands-Free Strap and Stand

Utilize the integrated hands-free strap for secure one-handed operation, especially in mobile or active environments. The adjustable rear stand allows for convenient tabletop viewing.

Protected ports and reliable connections

Covered ports withstand dirt, impact, and the elements.



Micro HDMI



USB Type C



USB 3.0



**Micro SD Slot
up to 512GB**



Image: The Fusion5 tablet featuring its hands-free strap and adjustable rear stand for versatile use.

MAINTENANCE

Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn marks, slightly dampen the cloth with water or a screen-safe cleaner.
- Avoid harsh chemicals, abrasive materials, or excessive moisture.

Battery Care

- To prolong battery life, avoid extreme temperatures.
- Do not leave the tablet fully charged or fully discharged for extended periods.
- Use only the provided charger or a compatible 30W Type-C charger.

Port Protection

Keep the protective covers over the Micro HDMI, USB Type-C, and USB 3.0 ports closed when not in use to prevent dust

and moisture ingress, maintaining the tablet's rugged integrity.

TROUBLESHOOTING

Issue	Possible Solution
Tablet does not power on.	Ensure the tablet is fully charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a hard reset by holding the power button for 10-15 seconds.
Touchscreen is unresponsive.	Restart the tablet. If the issue persists, ensure the screen is clean and free of debris. If still unresponsive, contact customer support.
Wi-Fi connection issues.	Check if Wi-Fi is enabled in Windows settings. Restart your router and the tablet. Ensure you are within range of the Wi-Fi network and have the correct password.
Device is slow or freezing.	Close unnecessary applications. Check for Windows updates. Ensure sufficient free storage space. A restart can often resolve temporary performance issues.
Accidental damage (drops, spills).	Refer to the warranty section for information on accidental damage coverage. Do not attempt to repair the device yourself.

SPECIFICATIONS

Feature	Detail
Brand	Fusion5
Model Name	FWIN232 PRO N5
Operating System	Windows 11 Professional
Processor	Intel 13th Gen Alder Lake N100 (up to 3.4 GHz)
RAM	12 GB
Storage	512 GB SSD
Expandable Storage	MicroSD up to 512 GB
Screen Size	10.1 Inches
Display Resolution	1920x1200 Pixels (Full HD IPS)
Graphics Coprocessor	Intel UHD Graphics or Intel Iris Xe Graphics
Connectivity	Dual-band Wi-Fi (802.11 ac/b/g/n), Bluetooth 5.0
Ports	Micro HDMI, USB Type-C (charging), USB 3.0, 3.5mm Headphone Jack
Cameras	Dual Full HD Cameras (Photo Sensor Resolution: 2 MP)
Battery Capacity	6000 mAh (approx. 5 hours average life)
Item Weight	636 Grams

Feature	Detail
Dimensions (L x W x Thickness)	10"L x 6.7"W x 0.43"Th

WARRANTY AND SUPPORT

2-Year Full Warranty + Accidental Damage Cover

Your Fusion5 FWIN232 PRO N5 tablet comes with a **24-month full warranty**. This includes coverage for up to **2 accidental damage incidents**, such as drops, spills, or bumps. To activate your coverage, please scan the QR code provided in the packaging or visit the Fusion5 warranty registration website.

The warranty covers damaged screens (up to 2 claims), liquid spills, accidental drops, equipment failure due to power surges, and mechanical & electrical malfunctions. It does not cover pre-purchase damage, loss, theft, or products used for commercial or business use (unless explicitly stated for business use cases).

	2-year gold standard protection	Standard protection
Coverage duration	🛡️ 24 months from purchase	12 months from purchase
Accidental screen damage	🛡️ Up to 2 claims covered	Not included
Technical support	🛡️ Priority support with dedicated tech team	Basic troubleshooting
Returns	🛡️ 30-day hassle-free return	30-day return policy
Zero contact support	🛡️ Zero-contact help via QR scan	Not included
Peace of mind	🌟 Best for long-term confidence	Good

Image: Details of the 2-year full coverage, including accidental screen damage for the Windows 11 tablet.

Customer Support

For technical assistance, warranty claims, or any product-related inquiries, please refer to the contact information provided in your product packaging or visit the official Fusion5 support website. Zero-contact support is available via QR scan for quick assistance.

SAFETY INFORMATION

- Do not expose the tablet to extreme temperatures, direct sunlight, or excessive humidity.
- Avoid dropping or subjecting the tablet to severe impacts, despite its rugged design.
- Keep the device away from water and liquids.
- Do not attempt to disassemble or repair the tablet yourself, as this will void the warranty.
- Use only manufacturer-approved accessories.

