

DIVINEEAGLE MEE007s

DIVINEEAGLE MEE007s 1080p Dome Camera User Manual

Model: MEE007s

1. INTRODUCTION

This user manual provides comprehensive instructions for the DIVINEEAGLE MEE007s 1080p Dome Camera. This device is designed for discreet video recording, offering features such as 1080p Full HD resolution, motion detection, and local microSD storage. It operates offline, ensuring data privacy without the need for Wi-Fi or external applications. The camera is ideal for monitoring pets and indoor environments like homes, apartments, hotels, and offices.

Key Features:

- **1080p Full HD Video:** Provides crisp and reliable video recording.
- **Data Protected by Design:** Utilizes local microSD storage for offline recording, eliminating Wi-Fi/App/Cloud exposure.
- **Smart Motion Detection:** Automatically records when movement is detected.
- **User-Friendly Setup:** Simple plug-in operation for immediate recording.
- **Versatile Use:** Suitable for pet monitoring, home security, and general indoor surveillance.

2. PRODUCT OVERVIEW

The DIVINEEAGLE MEE007s is a compact and discreet dome camera integrated into a standard wall charger design. Its small form factor allows it to blend seamlessly into various environments.

SHOOTS FULL HD VIDEO and CHARGES AT THE SAME TIME

2-in-1:

- Full HD Camera
- Phone Charger

*Records while
you're away*

Figure 2.1: Front view of the DIVINEEAGLE MEE007s Dome Camera, showing the USB port and camera lens.



Figure 2.2: The camera functions as both a Full HD camera and a phone wall charger.




Figure 2.3: Illustrates the camera's offline design for enhanced data privacy, with no Wi-Fi, cloud, or third-party server connections.

3. WHAT'S INCLUDED

The DIVINEEAGLE MEE007s package typically includes the following components:

- Premium Full HD Dome Camera
- SD Card Reader
- Type-C Connector
- Reset Pin
- USB-USB Data Cable
- User Guide

WHAT'S INCLUDED?

- Premium Full HD camera
 - 10 cover stickers
 - 2-in-1 charging cable
 - Card reader
 - USB-C adapter
 - USB-USB data cable
 - User guide (EN/ES/FR)
 - Reset pin
- ⊘ **Note:** microSD not included (select options available)



Figure 3.1: All items included in the DIVINEEAGLE MEE007s product package.

4. SETUP

Follow these steps to set up your DIVINEEAGLE MEE007s Dome Camera:

1. **Insert microSD Card:** Locate the microSD card slot on the device. Insert a compatible microSD card (up to 256GB, formatted to FAT32 for optimal performance) into the slot until it clicks into place.



Figure 4.1: Inserting the microSD card into the camera's designated slot.

2. **Select Recording Mode:** The camera supports two recording modes: Continuous Loop (L) and Motion Detection (M). Use the small switch near the microSD slot to select your desired mode.
3. **Plug In:** Plug the camera directly into a standard AC wall outlet (110-240V) or a power bank. The camera will automatically begin recording based on the selected mode.



Figure 4.2: Plugging the camera into a power source to initiate recording.

4. **Optional: Use with Power Bank:** For portability, the camera can be powered by a power bank.



Figure 4.3: The camera can be powered by a portable power bank for flexible placement.

5. **Optional: Apply Cover Sticker:** Use the included cover stickers to discreetly hide the microSD slot and mode switch for a cleaner appearance.



Figure 4.4: Applying a discreet sticker to cover the microSD slot and mode switch.

Setup Video Guide

Video 4.1: This video provides a quick guide to unboxing and setting up your DIVINEEAGLE MEE007s camera, demonstrating the initial steps for operation.

5. OPERATING THE CAMERA

The DIVINEEAGLE MEE007s camera is designed for simple, plug-and-play operation without complex settings or live viewing capabilities, prioritizing data privacy.

Recording Modes:

- **Continuous Loop Recording (L):** In this mode, the camera records continuously. When the microSD card is full, the oldest files are automatically overwritten to make space for new recordings.
- **Motion Detection Recording (M):** In this mode, the camera only records when it detects movement. This helps conserve storage space and makes it easier to review relevant footage.

To switch between modes, use the small physical switch located on the camera body, typically near the microSD card slot.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your DIVINEEAGLE MEE007s camera.

MicroSD Card Management:

- **Formatting:** For optimal performance and to avoid recording issues, it is recommended to format your microSD card to FAT32, especially for cards larger than 32GB. Many modern computers default to exFAT, which may not be compatible. Specialized formatting tools may be required.
- **Capacity:** The camera supports microSD cards up to 256GB. A 32GB card provides approximately 3 hours of continuous recording, a 128GB card provides about 12 hours, and a 256GB card provides about 24 hours before overwriting begins in loop mode.
- **Data Transfer:** To transfer video files, remove the microSD card and insert it into the included card reader. Connect the card reader to your computer or mobile device using the appropriate adapters.

Setting Time and Date Stamp:

To ensure your video files have the correct time and date stamp, you will need to modify a text file on the microSD card. This process typically involves connecting the microSD card to a computer or mobile device, locating a 'TIME.txt' file, editing it with the current date and time, and saving the changes. The camera will then use this information for future recordings.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter with your DIVINEEAGLE MEE007s camera:

- **Video Files Not Playing or Corrupted:**
 - **MicroSD Card Format:** Ensure your microSD card is formatted to FAT32. If it's formatted to exFAT,

reformat it using a tool that supports FAT32.

- **Video Player Compatibility:** Ensure you are using a compatible video player (e.g., VLC Media Player) as some default players may not support the AVI format.

- **Incorrect Time/Date Stamp on Videos:**

- **Update TIME.txt:** Follow the instructions in the Maintenance section to correctly set the time and date via the 'TIME.txt' file on the microSD card.

- **Slow File Transfer:**

- **Direct Card Reader:** For faster transfer speeds, remove the microSD card from the camera and use the included card reader to connect directly to your computer or mobile device. Transferring files directly from the camera via USB cable can be slower.
- **USB Port Compatibility:** Some users report better compatibility with USB 2.0 ports for direct camera connection, as USB 3.0 might not always recognize the device.

- **Motion Detection Issues:**

- **Lighting Conditions:** Ensure adequate lighting in the monitored area. Extreme lighting conditions or flickering lights can affect motion detection accuracy.
- **Placement:** Position the camera to minimize false triggers from environmental factors like moving curtains or reflections.

Video Guides for Viewing Files and Timestamp Setup:

Video 7.1: This video demonstrates how to view recorded video files on a PC and how to set up the timestamp for accurate recording dates.

Video 7.2: This video guides users through viewing recorded video files on a mobile phone and setting up the timestamp for mobile access.

8. SPECIFICATIONS

Feature	Specification
Brand	DIVINEEAGLE
Model Name	Pet Camera
Model Number	MEE007s
Recommended Uses	Indoor Security, Pet Monitoring
Connectivity Technology	Offline by Design — Local microSD Storage
Special Feature	1080p Full HD, Offline by Design (No Wi-Fi/App), Silent Video-Only Recording, Local Storage Control via microSD, Fast Plug-in Setup, Motion Detection
Compatible Devices	Mac OS, Windows

Feature	Specification
Controller Type	Push Button
Mount Type	Plug Mount, Power Strip, Powerbank
Color	Gloss
Installation Type	Wall-Mounted
Enclosure Material	Plastic
Shape	Rectangular
Alert Type	No
Light Source	LED
Control Method	Touch
Connectivity Protocol	MicroSD Card
Wireless Technology	Not Supported
Video Capture Resolution	1920×1080 (Image only)
Frame Rate	30 fps
Number of Channels	1
Video Capture Format	MJPEG
Item Dimensions	2.17 x 0.98 x 0.98 inches
Item Weight	1.12 ounces
Power Source	AC 110-240 or Powerbank
Voltage	110 Volts (AC)
Wattage	5 Watt-hours
Batteries Required	No
Viewing Angle	100 Degrees

Feature	Specification
---------	---------------

Focus Type	Auto Focus
Photo Sensor Technology	CMOS

9. WARRANTY AND SUPPORT

Warranty Information:

The DIVINEEAGLE MEE007s camera comes with a **5-Year Manufacturer Warranty**. For specific details regarding coverage and claims, please refer to the warranty documentation included with your product or contact DIVINEEAGLE customer support.

Customer Support:

DIVINEEAGLE provides friendly and responsive U.S.-based customer support. For assistance with setup, troubleshooting, or any other inquiries, please refer to the contact information provided in your user guide or visit the official DIVINEEAGLE website.