

Manuals.plus /
› HOOBRO /
› HOOBRO Dumbbell Rack BE85CJ01N1 Instruction Manual

HOOBRO BE85CJ01N1

HOOBRO Dumbbell Rack BE85CJ01N1 Instruction Manual

Model: BE85CJ01N1

1. PRODUCT OVERVIEW

The HOOBRO Dumbbell Rack (Model BE85CJ01N1) is a versatile storage solution designed to organize various fitness equipment in your home gym, yoga studio, or garage. This rack helps maintain a tidy workout space by efficiently storing items such as dumbbells, kettlebells, yoga mats, foam rollers, yoga blocks, resistance bands, and jump ropes. Key features include a sturdy metal frame for stability, a multi-functional design with a side metal mesh basket for yoga mats and foam rollers, a top bar for smaller dumbbells or kettlebells, and five S-hooks for hanging accessories. The rack is equipped with four swivel wheels, two of which have brakes, allowing for easy mobility and secure placement. Adjustable feet ensure stability on uneven surfaces.



Image 1.1: Fully assembled HOOBRO Dumbbell Rack with fitness equipment.

2. SAFETY INSTRUCTIONS

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
- Assemble the rack on a soft, clean surface to prevent scratches or damage.
- Do not overtighten screws during assembly, as this may damage the components. Tighten firmly but gently.
- Do not exceed the maximum weight capacity for each section or the overall rack. Refer to the Specifications section for details.
- Keep children and pets away from the assembly area.
- Always use the rack on a stable, level surface.
- Regularly inspect the rack for any loose screws, damaged parts, or signs of wear. Tighten or replace as necessary.

- Engage the wheel brakes when the rack is in a desired position to prevent accidental movement.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer service.

- Metal Frame Components (various bars and supports)
- Metal Mesh Shelves
- Non-Woven Fabric Basket
- 4 Swivel Wheels (2 with brakes)
- 5 S-Hooks
- Assembly Hardware (screws, nuts, Allen wrench)
- Instruction Manual



Image 3.1: Unassembled HOOBRO Dumbbell Rack components.

4. ASSEMBLY INSTRUCTIONS (SETUP)

Follow these steps carefully to assemble your HOOBRO Dumbbell Rack.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface and compare them against the package contents list to ensure everything is present.

2. **Attach Wheels:** Secure the four swivel wheels to the base frame of the rack. Ensure that the two wheels with brakes are positioned on the same side for easier access. Tighten them securely using the provided wrench.
3. **Assemble Main Frame:** Connect the vertical support bars to the base and top frame sections. Use the provided screws and Allen wrench, tightening them partially at first.
4. **Install Shelves and Basket:** Insert the metal mesh shelves into their designated slots. Attach the non-woven fabric basket to its frame.
5. **Attach S-Hooks:** Hang the five S-hooks onto the side mesh panel as desired for accessory storage.
6. **Final Tightening:** Once all components are in place, go back and fully tighten all screws and connections. Ensure the rack is stable and does not wobble.
7. **Adjust Feet:** If the rack is to be used in a fixed position without wheels, or if the surface is uneven, adjust the leveling feet at the bottom for optimal stability.




Image 4.1: Detailed view of rack features for assembly reference.

5. USAGE (OPERATING)

This section provides guidance on how to effectively use your HOOBRO Dumbbell Rack to organize your fitness equipment.

- **Dumbbell and Kettlebell Storage:** Place dumbbells and kettlebells on the designated shelves. The top bar is suitable for smaller weights, while the lower mesh shelves can accommodate larger items.
- **Yoga Mat and Foam Roller Storage:** Utilize the side metal mesh basket for storing yoga mats and foam rollers.
- **Accessory Hooks:** Hang resistance bands, jump ropes, towels, or other small accessories on the five S-hooks located on the side panel.
- **Mobility:** To move the rack, ensure the brakes on the swivel wheels are disengaged. Push or pull the rack to your desired location.
- **Stability:** Once the rack is in position, engage the brakes on the two wheels to secure it. If using the adjustable feet, ensure they are properly set to prevent wobbling.



Image 5.1: The rack organized with various workout accessories.

6. MAINTENANCE

Proper maintenance will ensure the longevity and continued performance of your dumbbell rack.

- **Cleaning:** Wipe the metal frame and shelves with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Wheel Inspection:** Keep the wheels free of debris and hair to ensure smooth movement. Lubricate if needed.
- **Storage:** Store the rack in a dry environment to prevent rust or material degradation.

7. TROUBLESHOOTING

Refer to this section for solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Screws are loose; rack is on an uneven surface; adjustable feet are not properly set.	Ensure all assembly screws are fully tightened. Adjust the leveling feet to compensate for uneven flooring.
Difficulty moving the rack.	Wheel brakes are engaged; wheels are obstructed by debris.	Disengage both wheel brakes. Check wheels for any obstructions (e.g., hair, dust) and clean them.
Missing parts during assembly.	Packaging error.	Double-check all packaging materials. If parts are still missing, contact HOOBRO customer service with your purchase details.

8. SPECIFICATIONS

Detailed specifications for the HOOBRO Dumbbell Rack BE85CJ01N1.

- **Brand:** HOOBRO
- **Model Number:** BE85CJ01N1
- **Material:** Metal, Non-Woven Fabric
- **Overall Dimensions (L x W x H):** Approximately 15.7" x 11.8" x 31.7" (40cm x 30cm x 80.5cm)
- **Item Weight:** 8.2 Pounds (3.7 kg)
- **Maximum Load Capacity:**
 - Top Shelf: 44.5 lbs (20.2 kg)
 - Middle/Lower Shelf: 55.6 lbs (25.2 kg)
 - Side Mesh Basket: 11.1 lbs (5 kg)
- **Number of Storage Racks/Shelves:** 3 main storage areas
- **Frame Type:** Rectangular Frame
- **Wheels:** 4 Swivel Casters (2 with brakes)




Image 8.1: Product dimensions and load capacities.



360° Smooth Casters, 2 with Brakes

Easy to move and secure in place.



Image 8.2: Detail of the 360° smooth casters with brakes.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official HOOBRO website. If you encounter any issues or require assistance with your HOOBRO Dumbbell Rack, please contact HOOBRO customer service.

Customer Service Contact: Please refer to your purchase receipt or the HOOBRO official website for the most up-to-date contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FNZY2GT5>

More documents and user manuals: <https://manuals.plus/>