

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LINSY HOME](#) /

› [LINSY HOME 66-inch Farmhouse TV Stand Instruction Manual \(Model B0FP16T67B\)](#)

LINSY HOME B0FP16T67B

LINSY HOME 66-inch Farmhouse TV Stand

MODEL: B0FP16T67B

Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Do not exceed the maximum weight capacity of 360 lbs (163 kg) for the TV stand.
- Ensure all parts are securely fastened before placing any items on the stand.
- Place the TV stand on a flat, stable, and level surface to prevent tipping.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Follow assembly instructions carefully to avoid injuries during installation.

Package Contents

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

- All necessary wood panels and shelves.
- Hardware kit (screws, dowels, cam locks, handles, hinges).
- Assembly tools (typically an Allen wrench and screwdriver).
- Instruction manual.

Assembly Instructions

Assembly is required for this TV stand. Detailed step-by-step instructions and all necessary hardware are included in the product packaging. It is recommended to have two people for assembly to ensure stability and ease of construction. The estimated assembly time is approximately 1.5 hours.

Please refer to the printed instruction manual provided in your package for specific assembly steps and diagrams.

Product size

Enhanced tabletop and base structure
adding weight capacity




Figure 1: Product Dimensions and Weight Capacity. The stand measures 66 inches in width, 15.7 inches in depth, and 22 inches in height, with a maximum weight capacity of 360 lbs.




Figure 2: Adjustable Shelf Mechanism. The shelves within the cabinets are height-adjustable to accommodate various items.



Figure 3: Cable Management. Integrated cutouts in the back panels help organize and conceal cables.

Features

- **Sturdy Construction:** Features an extra wooden support base for enhanced stability, supporting up to 360 lbs.
- **Ample Storage:** Includes height-adjustable shelves and side cabinets, along with two layers of display space behind glass doors.
- **TV Compatibility:** Designed to support televisions ranging from 50 to 75 inches.
- **Premium Material:** Crafted from eco-friendly engineered wood with an exquisite sealing process for a waterproof surface and smooth texture.
- **Cord Management:** Equipped with cable cutouts in the cabinet layers to keep wires organized.
- **Design:** Rustic Washed Grey & Brown finish with glass doors, offering a modern farmhouse aesthetic.



Figure 4: Overall View of the TV Stand. The stand features a spacious tabletop, open shelves, and cabinets with glass doors.



Figure 5: TV Size Compatibility. The stand is suitable for TVs up to 75 inches.

Usage and Operating Instructions

This TV stand is designed for holding televisions and organizing media components and decorative items. Utilize the adjustable shelves to customize storage space for various electronics, books, or display pieces. The glass doors allow for visibility of contents while protecting them from dust.

Ensure proper weight distribution when placing items on the shelves and tabletop. Use the cable management cutouts to route and conceal power cords and audio/video cables, maintaining a tidy appearance.



Figure 6: Storage Layout. The stand offers a spacious tabletop, central storage, and side display cabinets for organization.

Maintenance

To maintain the appearance and longevity of your LINSY HOME TV stand, follow these guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Spills:** Promptly clean up any spills to prevent moisture damage. The sealed surface offers some water resistance, but prolonged exposure to liquids should be avoided.
- **Weight Distribution:** Distribute weight evenly across the tabletop and shelves. Do not overload any single section.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood finish.
- **Hardware Check:** Periodically check and tighten all screws and fasteners to ensure the stand remains stable.



Figure 7: Wood Finish Detail. The stand features an environmental wood finish with a smooth texture.

Troubleshooting

If you encounter any issues with your TV stand, consider the following common solutions:

- **Wobbling/Instability:** Ensure the stand is on a level surface. Check all assembly hardware and tighten any loose screws.
- **Doors Not Aligning:** Adjust the hinges on the glass doors as needed. Refer to the assembly manual for hinge adjustment instructions.
- **Missing Parts:** If you discover missing parts during assembly, refer to the package contents list and contact customer support for replacements.

Specifications

Brand	LINSY HOME
Model Name	TV Stand
Model Number	B0FP16T67B
Color	Washed Grey & Brown
Material	Engineered Wood
Product Dimensions	15.7"D x 66"W x 22"H (39.9 cm D x 167.6 cm W x 55.9 cm H)
Item Weight	100 Pounds (45.36 kg)
Weight Limit	360 Pounds (163 kg)
Number of Shelves	3
Door Style	Glass Front
Assembly Required	Yes

Warranty and Support

For any product inquiries, support, or to report missing/damaged parts, please contact LINSY HOME customer service. This product is eligible for 30-day easy returns through the retailer.

