

## VEGER V2053

# VEGER 20000mAh 22.5W Fast Charging Power Bank

Model: V2053 | Brand: VEGER

## INTRODUCTION

Thank you for choosing the VEGER 20000mAh 22.5W Fast Charging Power Bank. This portable power bank is designed to provide efficient and rapid charging for your mobile devices, ensuring you stay powered throughout your day. Please read this manual carefully to understand the product's features, operation, and maintenance for optimal performance and safety.

## PRODUCT OVERVIEW

### Key Features:

- **High Capacity:** 20000mAh battery provides multiple charges for smartphones and tablets.
- **Fast Charging:** Supports 22.5W fast charging with PD3.0 and QC4.0 protocols, offering up to 3 times faster charging than standard 5V/1A power banks.
- **Multiple Ports:** Equipped with USB-A and USB-C output ports, and USB-C and Micro-USB input ports for versatile charging.
- **LED Digital Display:** Clear LED screen shows the precise battery percentage from 0% to 100%.
- **Compact Design:** Despite its high capacity, the power bank features a reduced size for portability.
- **Safety Protections:** Built-in safeguards against short-circuiting, overcharging, and other potential hazards.

### Package Contents:

- VEGER 20000mAh Power Bank x1
- USB-A to USB-C Charging Cable x1
- User Manual x1

## SETUP

### Initial Charging of the Power Bank:

1. Before first use, fully charge your VEGER power bank.
2. Connect the provided USB-A to USB-C cable to a compatible USB wall charger (not included) and the USB-C input port on the power bank. Alternatively, you can use a Micro-USB cable with the Micro-USB input port.
3. The LED digital display will show the charging progress, indicating the battery percentage.
4. Charging is complete when the display shows 100%.

## Charge & Recharge Conveniently



Image: The VEGER power bank showing its USB-A output ports, USB-C input/output port, Micro-USB input port, and the LED digital display indicating 100% charge.

### OPERATING INSTRUCTIONS

#### Charging Your Devices:

1. Use a compatible charging cable for your device.
2. Connect one end of the cable to your device and the other end to one of the power bank's output ports (USB-A or USB-C).
3. The power bank will automatically begin charging your device. The LED display will show the remaining battery percentage.
4. You can charge up to three devices simultaneously using the available output ports.



Image: The VEGER power bank simultaneously charging a smartphone, wireless earbuds, and another smartphone, demonstrating its multi-device charging capability.

### **Fast Charging Compatibility:**

This power bank supports various fast charging protocols, including PD3.0 and QC4.0, making it compatible with a wide range of devices such as iPhones (14/13/12/11/X/XR/8 series), Android smartphones (Samsung, Xiaomi, Huawei, etc.), iPads, and other tablets. It can also power heated apparel like vests, jackets, hats, and gloves.

# Wide Compatibility



## For iPhone

14/13...6/SE/Airpods  
all series



## For Android

Samsung/Xiaomi/Google...  
/other Android



## For Tablets

iPad/iPad Pro/Samsung  
/Huawei Tablets



## For Heated Apparel

jackets/vests/pants  
/hats/gloves



Image: A visual representation of the power bank's wide compatibility, showing it can charge iPhones, Android phones, tablets, and even heated apparel.

# 4X Faster than Normal Charger



VEGER **22.5W** Fast Charge



Other **5V 2A / 1.5A**



Image: A graphic illustrating that the VEGER 22.5W fast charge is up to 4 times faster than typical 5V 2A/1.5A chargers, highlighting its efficiency.

## MAINTENANCE

- Keep the power bank away from extreme temperatures, direct sunlight, and liquids.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank in a cool, dry place when not in use.
- To prolong battery life, fully charge and discharge the power bank at least once every three months if stored for extended periods.

## TROUBLESHOOTING

## Power Bank Not Charging:

- Ensure the charging cable is securely connected to both the power bank's input port and the wall charger.
- Try a different charging cable or wall adapter.
- Verify that the wall outlet is functioning correctly.

## Device Not Charging from Power Bank:

- Check if the power bank has sufficient charge (refer to the LED display).
- Ensure the charging cable is securely connected to both the power bank's output port and your device.
- Try a different charging cable or a different output port on the power bank.
- Confirm your device is compatible with the power bank's charging specifications.

## Slow Charging:

- Ensure you are using a fast-charging compatible cable and your device supports fast charging.
- Some devices may limit charging speed when multiple devices are connected.
- Environmental factors (e.g., extreme temperatures) can affect charging speed.

## SPECIFICATIONS

<b>Model Number</b>	V2053
<b>Battery Capacity</b>	20000mAh
<b>Max Power Output</b>	22.5W
<b>Input (USB-C)</b>	18W (PD)
<b>Input (Micro-USB)</b>	18W
<b>Output (USB-A)</b>	22.5W (QC4.0)
<b>Output (USB-C)</b>	20W/18W (PD3.0)
<b>Number of Ports</b>	4 (2x USB-A Out, 1x USB-C In/Out, 1x Micro-USB In)
<b>Battery Cell Composition</b>	Lithium Polymer
<b>Dimensions (L x W x H)</b>	10.9 x 7.0 x 2.8 cm
<b>Item Weight</b>	340 Grams
<b>Special Features</b>	Digital Display, Short-circuit Protection, Overcharge Protection, Fast Charging

# Power for Days



Image: The VEGER power bank with a large '20000mAh' graphic, emphasizing its high capacity for extended use.

## SAFETY INFORMATION

---

- Do not disassemble, modify, or repair the device yourself.
- Do not expose the power bank to fire, water, or extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations.

## WARRANTY AND SUPPORT

---

## **Warranty:**

This VEGER power bank comes with a **2-year product warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

## **Customer Support:**

For any questions, technical assistance, or warranty claims, please contact VEGER customer support through the retailer's platform or visit the official VEGER website for contact information. Please have your model number (V2053) and purchase details ready when contacting support.