

Zwide NA08H-N150

Zwide NA08H-N150 8-inch 2-in-1 Laptop Tablet User Manual

Model: NA08H-N150

1. INTRODUCTION

Thank you for purchasing the Zwide NA08H-N150 8-inch 2-in-1 Laptop Tablet. This device combines the functionality of a laptop and a tablet, offering versatility for various tasks from business to daily use. It features a 360-degree rotating touchscreen, a Japanese keyboard, and runs on Windows 11 Pro. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience.

2. PRODUCT OVERVIEW

Key Features

- **2-in-1 Design:** Functions as both a laptop and a tablet with a 360-degree rotating screen.
- **Operating System:** Pre-installed with Windows 11 Pro.
- **Processor:** Intel TwinLake N150 CPU (4 Cores, 4 Threads, up to 3.60GHz).
- **Memory & Storage:** 16GB RAM + 512GB SSD, expandable via TF card (up to 1TB).
- **Display:** 8.4-inch HD touchscreen with 1920x1200 FHD resolution.
- **Keyboard:** Japanese layout keyboard with fingerprint authentication on the power button.
- **Connectivity:** Bluetooth 5.2, Wi-Fi, USB 3.0, Mini HDMI, TF card slot, earphone jack.
- **Compact & Portable:** Ultra-compact size (20x13x1.8cm) and lightweight (960g).

Components and Ports

The Zwide NA08H-N150 features a variety of ports for connectivity and expansion.

様々な場合で活用



Image: Diagram illustrating the various ports on the Zide NA08H-N150. These include a charging port, HD display port, USB 3.0 port, TF card slot, and earphone jack.

N150の最新CPU、3.6GHz周波数

N100プロセッサと比べて、性能は約6%~10%向上しています。



Image: Side view of the Zide NA08H-N150, highlighting the USB 3.0 port, earphone/microphone jack, and SD card slot.

Your browser does not support the video tag.

Video: This video demonstrates the various ports and connectivity options of a compact laptop, including Thunderbolt (Type-C), HDMI, 3.5mm audio jack, USB 3.0, and LAN port. It shows how to connect peripherals and external displays.

3. SETUP

Initial Power On

1. Unpack the device and all accessories from the box.
2. Connect the power adapter to the charging port on the device and plug it into a power outlet.
3. Press and hold the power button located on the keyboard until the screen lights up.
4. Follow the on-screen instructions to complete the initial Windows 11 Pro setup, including language, region, network connection, and user account creation.

Fingerprint Authentication Setup

The device supports fingerprint authentication for secure and quick login.

1. Navigate to Windows Settings > Accounts > Sign-in options.
2. Locate 'Fingerprint recognition (Windows Hello)' and click 'Set up'.
3. Follow the on-screen prompts to register your fingerprint by repeatedly touching the power button.



Image: Close-up of the Zwide NA08H-N150 keyboard showing the power button with integrated fingerprint sensor. A finger is shown touching the sensor for authentication.

4. OPERATING INSTRUCTIONS

Using the 2-in-1 Functionality

The Zwide NA08H-N150 can be used in various modes thanks to its 360-degree rotating hinge.

- **Laptop Mode:** Traditional laptop setup for typing and productivity.
- **Tablet Mode:** Fold the keyboard back completely to use as a standalone tablet with touchscreen input.
- **Tent Mode:** Position the device in an inverted 'V' shape for media consumption or presentations.
- **Stand Mode:** Flip the keyboard underneath to prop up the screen for viewing.



Image: The Zide NA08H-N150 shown in different configurations, including laptop mode, tablet mode, and tent mode, demonstrating its 360-degree rotation capability for office, drawing, and gaming.

Your browser does not support the video tag.

Video: This video showcases the Chuwi MiniBook X N150, demonstrating its 360-degree flipping ability, compact size, Intel N150 processor, 16GB LPDDR5 RAM, 512GB SSD, and 10.51-inch 16:10 display. It highlights its versatility for various uses, including tablet mode and touch screen interaction.

Touchscreen and Stylus Use

The 8.4-inch FHD touchscreen supports multi-touch gestures. You can also use a compatible stylus (sold separately) for precise input, drawing, or note-taking.

指紋認証

パスワードを入力する必要がなく、キーボードの電源ボタンで指をタッチするだけで安全にログインできます。



Image: A person using the Zwide NA08H-N150 in tablet mode, interacting with the touchscreen using a stylus to write or draw on a document.

Connectivity

- **Wi-Fi:** Connect to wireless networks via the built-in Wi-Fi.
- **Bluetooth:** Pair with Bluetooth devices like headphones, mice, or keyboards using Bluetooth 5.2.
- **USB 3.0:** Connect USB peripherals such as external drives or mice.
- **Mini HDMI:** Connect to an external monitor or TV for a larger display.
- **TF Card:** Insert a TF card into the slot to expand storage up to 1TB.

5. MAINTENANCE

Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and exterior.
- For stubborn smudges, lightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasives, or solvents.

Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the device in a cool, dry place when not in use for extended periods.
- Use only the original or certified power adapter for charging.

Software Updates

Regularly check for and install Windows updates to ensure your system has the latest security patches and performance improvements. Go to Settings > Windows Update.

6. TROUBLESHOOTING

Common Issues and Solutions

- **Device does not power on:** Ensure the device is charged. Connect the power adapter and try again. If the battery is completely drained, it may take a few minutes before it can power on.
- **Screen is unresponsive:** Restart the device. If the issue persists, ensure the screen is clean and free of debris.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled in Windows settings. Restart your router and the device. Ensure you are within range of the Wi-Fi signal.
- **Slow performance:** Close unnecessary applications. Check for available Windows updates. Ensure sufficient free storage space on the SSD.
- **Fingerprint sensor not working:** Ensure your finger is clean and dry. Re-register your fingerprint in Windows settings if necessary.

Factory Reset

If you encounter persistent software issues, you may need to perform a factory reset. This will erase all data on the device. Back up important files before proceeding.

1. Go to Settings > System > Recovery.
2. Under 'Recovery options', click 'Reset PC'.
3. Choose whether to keep your personal files or remove everything, then follow the on-screen instructions.

7. SPECIFICATIONS

Feature	Specification
Brand	Zwide
Model Number	NA08H-N150
Operating System	Windows 11 Pro
CPU	Intel TwinLake N150 (4 Cores, 4 Threads, up to 3.6 GHz)
RAM	16 GB LPDDR5
Storage	512 GB SSD (Expandable up to 1TB via TF card)
Display Size	8.4 inches
Resolution	1920x1200 pixels (FHD)
Graphics	Intel Integrated Graphics

Feature	Specification
Connectivity	Wi-Fi, Bluetooth 5.2
Ports	1x USB 3.0, Mini HDMI, TF Card Slot, Earphone Jack, Charging Port
Battery	3500mAh Lithium Polymer (13.3 Wh)
Dimensions	20 x 13 x 1.8 cm
Weight	960 g
Included Components	Keyboard

8. WARRANTY AND SUPPORT

Warranty Information

Your Zwide NA08H-N150 device comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Zwide customer support. Contact information can typically be found on the Zwide official website or on the packaging materials.