

AOC AX15

AOC AX15 Laptop User Manual

Model: AX15

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your AOC AX15 laptop. Please read this manual thoroughly before using your device to ensure optimal performance and longevity.



Image 1.1: The AOC AX15 laptop, showcasing its 15.6-inch display, Windows 11 operating system, Intel processor, 16GB RAM, and 512GB SSD.

2. SETUP

2.1 Unboxing and Initial Inspection

Carefully remove the laptop and all accessories from the packaging. Verify that all components are present and undamaged. The package should contain:

- 1 × AOC AX15 Laptop (16GB RAM + 512GB SSD)
- 1 × Power Adapter
- 1 × User Manual (this document)

2.2 Powering On and Initial Configuration

1. Connect the power adapter to the laptop's charging port (Type-C DC Jack) and then to a power outlet.
2. Open the laptop lid and press the power button, typically located on the keyboard deck.
3. Follow the on-screen instructions to complete the initial Windows 11 setup, including language selection, network connection, and user account creation.

2.3 Connecting Peripherals

The AOC AX15 laptop offers various ports for connecting external devices:

- **USB 3.2 Gen1 (Type-A):** For high-speed data transfer with compatible devices.
- **USB 2.0 (Type-A):** For standard USB devices like mice or keyboards.
- **Type-C (Data):** For data transfer with USB-C devices.
- **HDMI:** To connect to external displays or projectors.
- **3.5mm Headphone Jack:** For audio output to headphones or external speakers.
- **TF Card Socket:** For reading and writing to microSD cards.



Image 2.1: Detailed view of the laptop's connectivity ports, including USB, Type-C, HDMI, and audio jack.

3. OPERATING YOUR LAPTOP

3.1 Basic Navigation

The laptop features a responsive touchpad and a full-size keyboard for navigation and input. Familiarize yourself with common Windows 11 gestures and keyboard shortcuts for efficient use.

3.2 Wireless Connectivity

- **Wi-Fi:** To connect to a wireless network, click the Wi-Fi icon in the taskbar, select your desired network, and enter the password if prompted.
- **Bluetooth 5.0:** To pair Bluetooth devices, go to **Settings > Bluetooth & devices**, turn on Bluetooth, and select your device to pair.

3.3 Battery Management

The AOC AX15 is equipped with a 5000 mAh lithium-ion battery. To maximize battery life:

- Adjust screen brightness to a comfortable level.
- Close unused applications and browser tabs.
- Utilize Windows 11 battery saver mode when power is low.
- Avoid extreme temperatures.

Work More Efficiently

Get rid of Power Supply Worries



Image 3.1: The AOC AX15 laptop in use, highlighting its 5000mAh battery for extended productivity.

3.4 Integrated Webcam and Microphone

The laptop includes a built-in HD camera and digital high-definition microphone, suitable for video calls and online communication.

Face-to-face in one step

Built-in HD camera, digital microphone and stereo speakers,
easy to meet friends online



Wide Vision
HD Camera



Digital High definition
Microphone



Image 3.2: The laptop's integrated HD camera and microphone facilitate clear video conferencing.

4. MAINTENANCE

4.1 Cleaning Your Laptop

- Use a soft, lint-free cloth to clean the screen and exterior.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid harsh chemicals or abrasive materials.

4.2 Software Updates

Regularly update your Windows 11 operating system and drivers to ensure security, stability, and optimal performance. You can check for updates via **Settings > Windows Update**.

4.3 Storage Management

The 512GB SSD provides fast storage. To maintain performance, periodically:

- Delete unnecessary files.
- Uninstall unused applications.
- Utilize cloud storage for large files.

4.4 Cooling System

The laptop is designed with a scientific cooling scheme. Ensure proper airflow by keeping vents clear and using the laptop on a hard, flat surface. Avoid blocking the vents with soft materials like blankets.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your AOC AX15 laptop.

5.1 Power Issues

- **Laptop not turning on:** Ensure the power adapter is securely connected to both the laptop and a working power outlet. Check if the power indicator light is on.
- **Battery not charging:** Verify the power adapter and cable are not damaged. Try a different power outlet.

5.2 Display Problems

- **No display:** Connect an external monitor via HDMI to check if the issue is with the laptop's internal screen. Restart the laptop.
- **Flickering screen:** Update your graphics drivers. Adjust display refresh rate in Windows settings.

5.3 Connectivity Issues

- **Wi-Fi not connecting:** Ensure Wi-Fi is enabled. Restart your router and the laptop. Check network settings in Windows.
- **Bluetooth device not pairing:** Ensure Bluetooth is enabled on both devices. Make sure the device is in pairing mode and within range.

5.4 System Performance

- **Slow performance:** Close unnecessary applications. Check for malware. Ensure sufficient free storage space.
- **Applications freezing:** End the task via Task Manager (Ctrl+Shift+Esc). Update the application or reinstall it.

5.5 Factory Reset

If persistent issues occur, you may consider performing a factory reset. This will reinstall Windows 11 and remove all your personal files, apps, and settings. Navigate to **Settings > System > Recovery > Reset**

this PC and follow the prompts.

6. SPECIFICATIONS

Key technical specifications for the AOC AX15 laptop:

Feature	Specification
Model	AX15
Processor	Intel N95 (up to 3.4GHz)
RAM	16GB DDR4
Storage	512GB M.2 2280 SSD
Display	15.6-inch FHD (1920x1080) IPS Screen
Graphics	Integrated Intel Graphics
Operating System	Windows 11
Ports	2x USB 3.2 Gen1, 1x USB 2.0, 1x Type-C (Data), 1x Type-C (DC Jack), 1x TF Card Socket, 1x 3.5mm Headphone Jack, 1x HDMI
Wireless	Wi-Fi 5, Bluetooth 5.0
Battery	5000 mAh Lithium-ion
Weight	Approximately 3.7 lbs (1.68 kg)
Dimensions	14.06 x 9.75 x 0.78 inches



Intel® Processor N95
Cores 4 Cache 6 MB 3.40 GHz



Intel® UHD Graphics 1.2GHz

Battery capacity

5000MAH



16GBRAM
+
512GBSSD



Windows 11



WIFI
Bluetooth

Image 6.1: Overview of the AOC AX15 laptop's core components and features.

Great Image Quality

16:9 Full HD technology brings you a more vibrant color and immersive viewing experience



15.6" IPS FHD (1920 x 1080)

FULL HD

Full HD 1920×1080



Bright View



IPS



Protezione
degli occhi

Image 6.2: The 15.6-inch Full HD IPS display offers a clear and vibrant visual experience.

intel 12th Gen Alder lake N95



CPU
N95



Cores
4

intel

Lithography
intel 7



Cache
6MB



Turbo Boost
3.4GHz

intel
INSIDE™

intel High-Performance CPU | Blow Away The Competition

SINGLE-CORE



MULTI-CORE




Image 6.3: Details of the Intel N95 processor, showing its core count, cache, and turbo boost frequency.

7. WARRANTY AND SUPPORT

7.1 Product Warranty






The AOC AX15 laptop comes with a **one-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Service

For technical assistance, warranty claims, or any product-related inquiries, please contact AOC customer

service. Refer to the contact information provided with your product packaging or visit the official AOC support website for details.

Related Documents - AX15

	<p>AOC Monitor Adjusting and Driver Installation Guide</p> <p>Comprehensive guide for adjusting AOC monitor settings and installing necessary drivers for optimal display performance across various Windows operating systems.</p>
	<p>AOC AGM700 Gaming Mouse: High-Performance Specs and Features</p> <p>Detailed specifications for the AOC AGM700 gaming mouse, featuring a Pixart 3389 sensor, 16,000 DPI, 400 IPS tracking, 50G acceleration, customizable RGB lighting, and ergonomic design for competitive gaming.</p>
	<p>AOC SPX24V2 User Manual - Setup, Operation, and Specifications</p> <p>Comprehensive user manual for the AOC SPX24V2 display, covering safety, setup, operation, media playback, file management, troubleshooting, and technical specifications. Visit www.aoc.com for more information.</p>
	<p>AOC 22B2H LED Monitor User Manual and Specifications</p> <p>Detailed user manual and technical specifications for the AOC 22B2H 21.5-inch Full HD LED monitor. Learn about setup, OSD menu adjustments, connectivity options (VGA, HDMI), software features (i-Menu, e-Saver, Screen+), and compliance.</p>
	<p>AOC GK500 Mechanical Gaming Keyboard User's Guide</p> <p>Comprehensive user guide for the AOC GK500 Mechanical Gaming Keyboard. Covers package contents, specifications, device layout, installation and usage of AOC G-Tools software for profile management, button assignment, macro programming, RGB lighting effects (Light FX), and sensitivity settings, along with safety and maintenance guidelines.</p>



[Instrukcja obsługi AOC Q27G4SRU - Monitor Gamingowy](#)

Szczegółowa instrukcja obsługi dla monitora gamingowego AOC Q27G4SRU, zawierająca informacje o instalacji, konfiguracji, ustawieniach, rozwiązywaniu problemów i specyfikacjach technicznych.