

Invengo SSPF-S4

Invengo Stainless Steel Cat Water Fountain Instruction Manual

Model: SSPF-S4

INTRODUCTION

Thank you for choosing the Invengo Stainless Steel Cat Water Fountain. This manual provides essential information for the proper setup, operation, and maintenance of your new pet drinking fountain. Please read these instructions carefully before use to ensure optimal performance and the safety of your pets.

The Invengo Cat Water Fountain is designed to provide fresh, filtered water for cats, dogs, and small animals, encouraging them to drink more and stay hydrated. Its 3.2-liter capacity and durable stainless steel construction offer convenience and hygiene.

PRODUCT FEATURES

- **Large 3.2L Capacity:** Provides ample water, reducing refill frequency.
- **Whisper-Quiet Operation:** Operates at approximately 20dB for a peaceful environment.
- **Two Water Flow Modes:** Offers both bubbling fountain and gentle stream options.
- **Durable Stainless Steel:** Constructed from high-quality 304 stainless steel for hygiene and longevity.
- **Transparent Water Level Window:** Allows for easy monitoring of water levels.
- **Splash-Proof Design:** Features a raised rim to minimize spills.
- **5-Layer Filtration System:** Ensures clean and fresh water by removing impurities.
- **Easy to Clean:** Quick-detach design for simple hand washing.

PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x Water Dispenser (Stainless Steel Bowl and Lid)
- 1 x Water Pump
- 1 x Power Adapter
- 4 x Filter Elements

- 4 x Foam Sponges
- 1 x Instruction Manual



Image: Complete package contents of the Invengo Cat Water Fountain, including the stainless steel unit, power adapter, filters, and sponges.

SETUP INSTRUCTIONS

Follow these steps to set up your Invengo Cat Water Fountain:

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Rinse Components:** Wash the stainless steel bowl, lid, and pump thoroughly with water. Do not use soap on the pump.
3. **Prepare Filter:** Rinse the filter element and foam sponge under running water to remove any loose carbon dust.
4. **Assemble Pump:** Place the foam sponge over the outer perimeter of the water pump, ensuring it does not obstruct the indicator light.
5. **Install Filter:** Insert the filter element into its designated slot on the lid assembly.
6. **Place Pump:** Secure the pump into the bottom of the lid assembly.
7. **Fill Water:** Fill the stainless steel bowl with water up to the MAX line. Do not overfill.
8. **Attach Lid:** Carefully place the lid assembly onto the stainless steel bowl, ensuring the pump's power cord is routed through the designated groove to prevent pinching.
9. **Connect Power:** Plug the power adapter into a wall outlet.

Setup in a Snap



Image: Step-by-step visual guide for setting up the Invengo Cat Water Fountain.

Your browser does not support the video tag.

Video: Official guide on how to get started with the MeowFlow B30D fountain, demonstrating assembly and initial setup.

Your browser does not support the video tag.

Video: Official unboxing and assembly demonstration for the Invengo 304 Stainless Steel Cat Water Fountain.

OPERATING INSTRUCTIONS

Once assembled and filled, the fountain will begin operating automatically when plugged in. The fountain offers two distinct water flow modes:

- **Faucet Flow:** Provides a stream of water similar to a tap.
- **Fountain Flow:** Offers a gentle bubbling water surface.

You can switch between these modes by adjusting the spout attachment on the lid. The transparent window allows you to monitor the water level at a glance. Ensure the water level is always maintained above the minimum mark to prevent pump damage and ensure quiet operation.

Transparent Window & 2 Flow Modes

Monitor Water Levels and Enjoy Faucet or Gentle Fountain Flow



1. Faucet Flow



2. Fountain Flow

Image: The InvenGo Cat Water Fountain showcasing its transparent water level window and the two available water flow options: faucet and fountain.

Ultra-Quiet – Only 20dB

Peaceful Hydration for Cats & Dogs Without Disturbing Your Home



Image: A cat resting peacefully next to the Invengo Cat Water Fountain, illustrating its ultra-quiet operation at 20dB.

MAINTENANCE

Regular cleaning and filter replacement are crucial for maintaining water quality and extending the life of your fountain.

Daily Maintenance:

- Check the water level through the transparent window and refill as needed.
- Wipe down the stainless steel bowl to remove any dust or debris.

Weekly Cleaning:

1. Unplug the fountain from the power outlet.
2. Disassemble the fountain by removing the lid and pump assembly.
3. Wash the stainless steel bowl and lid with warm water and a mild, pet-safe detergent. Rinse thoroughly.
4. Clean the pump: Disassemble the pump and clean all parts, including the impeller, with a small brush to remove any hair or debris. Rinse thoroughly.
5. Reassemble the fountain and refill with fresh water.



Image: A person demonstrating the easy cleaning process of the Invengo Cat Water Fountain, highlighting its quick-detach design.

Filter Replacement:

The 5-layer filtration system includes a filter element and a foam sponge. Replace these components every 2 to 4 weeks, or more frequently if you have multiple pets or notice reduced water flow/quality.

5-Layer Filtration for 24/7 Pure Water

Removes Hair, Odor, and Impurities—Delivering Fresh, Clean Hydration All Day

① Non-Woven Fabric

② Activated Carbon

③ Ion-Exchange Resin

④ Maifan Stone

⑤ Non-Woven Fabric




Image: Detailed diagram illustrating the 5-layer filtration system of the Invengo Cat Water Fountain, showing non-woven fabric, activated carbon, ion-exchange resin, and Maifan stone layers.



Image: Invengo replacement filters and foam sponges for the cat water fountain.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not dispensing water	Power not connected; water level too low; pump clogged; filter clogged.	Ensure power adapter is securely plugged in. Refill water to the MAX line. Clean the pump and impeller. Replace the filter element.
Fountain making excessive noise	Water level too low; pump dirty or clogged; fountain not level.	Refill water to the MAX line. Clean the pump and impeller thoroughly. Place the fountain on a flat, stable surface.
Water tastes or smells bad	Filter needs replacement; fountain needs cleaning.	Replace the filter element and foam sponge. Perform a thorough cleaning of all fountain components.
Water leaking from fountain	Lid not properly seated; water overfilled; pump not correctly installed.	Ensure the lid is securely placed and aligned. Do not fill water above the MAX line. Verify the pump is correctly installed in the lid assembly.

SPECIFICATIONS

Feature	Detail
Model Number	SSPF-S4 (Manufacturer Part Number: MF-B40P)
Capacity	3.2 Liters (108 oz)
Material	304 Stainless Steel
Product Dimensions	9.06 x 9.06 x 4.73 inches
Item Weight	1.87 Pounds (0.85 Kilograms)
Noise Level	Approximately 20dB
Pet Type	Cat, Dog, Small Animal
Indoor/Outdoor Usage	Indoor

WARRANTY INFORMATION

The Invengo Cat Water Fountain comes with the following warranty:

- **Water Dispenser (Main Unit):** One (1) year warranty from the date of purchase.
- **Water Pump:** Two (2) year warranty from the date of purchase.

This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, neglect, accidents, or unauthorized modifications. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, concerns, or technical assistance, please contact Invengo Customer Service:

- **Email:** service@invengo.com
- **Availability:** 24/7 Customer Service Support

Our team is dedicated to providing exceptional support and ensuring your satisfaction with Invengo products.