

[Manuals.plus](#) /

> [BUDDGO](#) /

> BUDDGO Play Kitchen for Toddlers Instruction Manual (Model BL-20113)

## BUDDGO BL-20113

# BUDDGO Play Kitchen for Toddlers Instruction Manual

Model: BL-20113

## 1. INTRODUCTION

---

Thank you for choosing the BUDDGO Play Kitchen for Toddlers. This manual provides essential information for the safe assembly, operation, and maintenance of your new play kitchen. Please read these instructions carefully before assembly and retain them for future reference.

## 2. SAFETY INFORMATION

---

- **Age Recommendation:** This play kitchen is designed for children aged 3 years and older.
- **Choking Hazard:** Contains small parts. Adult supervision is required during assembly and play to prevent choking hazards.
- **Assembly:** Adult assembly is required. Ensure all parts are securely fastened before allowing children to play.
- **Stability:** Place the play kitchen on a flat, stable surface to prevent tipping.
- **Maintenance:** Regularly inspect the play kitchen for loose parts, damage, or wear. Tighten screws and replace damaged components as needed.

## 3. WHAT'S IN THE BOX

---

The BUDDGO Play Kitchen package includes the following components:

- Kids Kitchen Playset (main structure)
- Installation Instructions manual
- 4 Kitchen Utensils
- 2 Pots
- 2 Spatulas
- 2 Felt Storage Boxes
- 3 Ice Cubes (for ice maker)

Please verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

## 4. SETUP AND ASSEMBLY

---

Assembly of the BUDDGO Play Kitchen requires adult supervision and adherence to the provided instructions. A detailed assembly guide is included in your package. For visual assistance, assembly videos may be available on the manufacturer's website.

### 4.1 Assembly Steps

1. Unpack all components and lay them out on a clean, flat surface.
2. Identify each part using the provided parts list in the installation instructions.
3. Follow the step-by-step diagrams and instructions to connect the main kitchen frame.
4. Attach the various appliances such as the oven, microwave, sink, and coffee maker according to the guide.
5. Secure all screws and fasteners tightly. Do not overtighten.
6. Install the range hook, faucet, and any decorative elements like curtains.
7. Place the felt storage boxes into their designated compartments.
8. Ensure the entire structure is stable and all moving parts operate smoothly before use.



Image: The fully assembled BUDDGO Play Kitchen, ready for play.

## 5. OPERATING INSTRUCTIONS

The BUDDGO Play Kitchen features several interactive elements designed to enhance imaginative play.

### 5.1 Interactive Features

- **Stove:** Turn the knobs on the stove to hear clicking sounds, simulating cooking.
- **Range Hood:** The range hood includes a light and produces realistic exhaust sounds when activated.
- **Faucet and Sink:** The faucet features dual-control rotation and can be turned 360 degrees for simulated cleaning.
- **Ice Maker:** Press the button on the ice maker to dispense the included toy ice cubes.
- **Microwave:** The microwave has a smart display and dual knobs for simulated heating.
- **Oven:** The oven features knobs with sound effects for a more realistic baking experience.
- **Washing Machine:** The washing machine door opens, allowing for pretend laundry play.
- **Coffee Maker:** The coffee maker allows for simulated coffee preparation.

# Exclusively for Your Little One

The ideal size for children to play cooking



Image: Detailed view of the range hood with light and sound, and stove with clicking knobs.

# Begin Your Little Chef Journey



## Range Hood

Dual Effects:  
Light &  
Realistic Exhaust Sound.

## Stove

Turn the knob,  
hear the click,  
cooking is more fun.

Image: Detailed view of the rotating faucet, microwave with display, and oven with sound effects.

# Mini Appliance Fun



Washing machine



Coffee maker



Ice maker

Image: Detailed view of the washing machine, coffee maker, and ice maker dispensing cubes.

## 5.2 Storage Solutions

The play kitchen includes integrated storage to help organize play accessories:

- **Cabinets:** Upper and lower cabinets provide space for toy dishes and food items.
- **Shelves:** Open shelves are available for displaying play spices or other small items.
- **Felt-Lined Boxes:** Two pull-out felt boxes are perfect for storing toy fruits and vegetables, promoting tidiness.

# Nature a Heart of Order



## Cabinets

A Safe Home for Little Plates and Bowls.

## Shelves

A Display Shelf for Spices and Dreams.

## Felt-Lined Boxes

A Cozy Home for Toy Fruits & Veggies.

Image: View of the various storage options including cabinets, shelves, and felt-lined boxes.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and safety of your BUDDGO Play Kitchen.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight. Retighten as necessary.
- **Damage:** If any part becomes damaged or broken, discontinue use immediately and replace the part or contact customer support.
- **Storage:** Store the play kitchen in a dry environment, away from direct sunlight or extreme temperatures, to prevent warping or fading.

## 7. TROUBLESHOOTING

If you encounter any issues with your play kitchen, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Stove/Oven knobs do not click or make sound.	Mechanism obstruction or wear.	Check for any foreign objects obstructing the knob. If worn, contact support for replacement parts.
Range hood light or sound not working.	Battery issue or loose connection.	Ensure batteries (if applicable, not specified but common for lights/sounds) are correctly installed and charged. Check connections.
Ice maker not dispensing cubes.	Cubes jammed or mechanism issue.	Ensure toy ice cubes are properly loaded and not jammed. Gently clear any obstructions.
Loose parts or instability.	Screws have loosened over time.	Retighten all visible screws and fasteners. Ensure the kitchen is on a level surface.

## 8. SPECIFICATIONS

Feature	Detail
Brand	BUDDGO
Model Number	BL-20113
Age Range	3+ years old (Manufacturer Minimum Age: 36 months, Maximum Age: 96 months)
Material Type	Wood
Item Dimensions (D x W x H)	39.96" x 11.61" x 39.37" (101.5 cm x 29.5 cm x 100 cm)
Color	White and Yellow (Curtains)
Included Components	Kids Kitchen Playset, Installation Instructions



Image: Product dimensions diagram for the play kitchen.

## 9. WARRANTY AND SUPPORT

No specific warranty information is provided in the product details. For warranty inquiries, please refer to the retailer where the product was purchased or visit the official BUDDGO website for their current warranty policy.

## **9.1 Customer Support**

For any questions, missing parts, or assistance with assembly or operation, please contact BUDDGO customer support through their official website or the contact information provided with your purchase documentation.