

## LEMBERI PB-82TVS-50F

# LEMBERI PB-82TVS-50F 82-inch Fireplace TV Stand User Manual

Model: PB-82TVS-50F | Brand: LEMBERI

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your LEMBERI PB-82TVS-50F 82-inch Fireplace TV Stand. This unit is designed to accommodate TVs up to 90 inches and includes a 50-inch electric fireplace with LED lighting and ample storage space. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.

## 2. IMPORTANT SAFETY INFORMATION

---

To reduce the risk of fire, electric shock, or injury, please adhere to the following safety guidelines:

- Read all instructions before using this appliance.
- Do not operate any fireplace with a damaged cord or plug, or if the heater has malfunctioned, been dropped, or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Always unplug the fireplace when not in use.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Ensure the TV stand is assembled on a flat, stable surface to prevent tipping.
- Do not overload the shelves or the top surface of the TV stand.
- Keep children and pets away from the fireplace and moving parts.

## 3. PACKAGE CONTENTS


---

Your LEMBERI Fireplace TV Stand is shipped in two separate packages: one for the TV stand components (Box A)

and one for the 50-inch electric fireplace insert (Box B). These packages may arrive on different days. Please ensure you have received both packages and all components before beginning assembly. Verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- TV Stand Panels (Top, Bottom, Sides, Shelves, Back Panel)
- 50-inch Electric Fireplace Insert
- LED Light Strips and Remote Control
- Assembly Hardware (Screws, Dowels, Cam Locks, Brackets, etc.)
- Instruction Manual

## Product Size



Come with 2 packages

Image: Product dimensions and packaging details. The TV stand measures 82.6 inches wide, 15.7 inches deep, and 38.3 inches high. The 50-inch fireplace insert is shown separately, along with two boxes indicating separate shipments.

## 4. ASSEMBLY INSTRUCTIONS

### 4.1. Before You Begin

- Clear a spacious, clean area for assembly.
- Gather necessary tools: Phillips head screwdriver, hammer (optional, for dowels).
- Review all diagrams and instructions before starting.
- It is recommended to have two people for assembly.

## 4.2. Step-by-Step Assembly

1. **Unpack Components:** Carefully remove all parts from both packages and lay them out on a soft, clean surface to prevent scratches. Identify each part using the provided parts list.
2. **Assemble Base Frame:** Attach the side panels to the bottom panel using the provided dowels and cam locks. Ensure all connections are secure.
3. **Install Interior Shelves:** Insert the adjustable shelves into the designated slots. The shelves feature a 3-tier adjustable design, allowing customization of storage space.
4. **Attach Top Panel:** Secure the top panel to the assembled frame using the appropriate hardware.
5. **Insert Fireplace:** Carefully slide the 50-inch electric fireplace insert into the central opening of the TV stand. Ensure it fits snugly and is flush with the front surface.
6. **Install LED Lights:** Adhere the LED light strips to the interior edges of the shelves or desired locations. Connect the LED strips to the power supply and controller.
7. **Secure Back Panel:** Attach the back panel(s) to the rear of the TV stand using small nails or screws to enhance stability and conceal wiring.
8. **Final Placement:** Move the assembled TV stand to its desired location. Ensure it is level and stable before placing a television or other items on it.



*Image: The fully assembled LEMBERI Fireplace TV Stand, featuring the central electric fireplace, illuminated side shelves, and a television placed above.*



Image: Detailed view highlighting the ample storage space with 3-tier adjustable shelves and the control panel for the electric fireplace.

## 5. OPERATING INSTRUCTIONS

### 5.1. Electric Fireplace Operation

The 50-inch electric fireplace features a captivating 3D flame effect and can operate with or without heat. It includes a remote control for convenient adjustments.

- **Power (ON/OFF):** Press the power button on the control panel or remote to turn the fireplace on or off.
- **Heater (750W/1500W):** Toggle between 750 watts and 1500 watts for heating. The fireplace can heat rooms up to 400 square feet.
- **Flame Speed:** Adjust the speed of the flame effect through 5 available levels.
- **Flame Color:** Select from various flame colors to match your ambiance.
- **Dimmer:** Adjust the brightness of the flame effect (5 levels).
- **Timer:** Set an automatic shut-off timer for 1 to 8 hours.



Image: The control panel of the electric fireplace, illustrating buttons for heater settings (750W/1500W), flame speed (5 levels), flame color, dimmer (5 brightness options), timer (1-8 hours), and power ON/OFF.

## 5.2. LED Lighting Operation

The entertainment center features built-in LED lights with 20 color options, controlled by a dedicated remote.

- **Power:** Use the LED remote control to turn the lights on or off.
- **Color Selection:** Choose from 20 different light colors to create various moods.
- **Brightness Adjustment:** Adjust the intensity of the LED lights to your preference.
- **Modes:** Some remotes may offer additional modes like flash, strobe, fade, or smooth transitions.



*Image: A visual representation of the 20 available LED light colors and 12 realistic flame color variations for the fireplace.*



Image: The LEMBERI TV stand showcasing its LED lighting feature, with blue lights illuminating the shelves and a matching blue flame effect in the electric fireplace.

## 6. CARE AND MAINTENANCE

---

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft, dry cloth to wipe the exterior. For glass, use a glass cleaner sprayed onto a cloth, not directly onto the unit.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Cord Care:** Periodically check the power cord for any signs of damage. If damaged, discontinue use and contact customer support.
- **Hardware Check:** Periodically check all assembly hardware to ensure it remains tight. Retighten if necessary.

## 7. TROUBLESHOOTING

---

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power switch off, remote battery dead.	Ensure unit is plugged in, check wall outlet, turn on main power switch, replace remote batteries.
No heat output from fireplace.	Heater function not activated, thermostat setting too low.	Activate heater function (750W/1500W), increase thermostat setting.
LED lights are not working.	LED strip not connected, remote battery dead, power supply issue.	Check LED strip connections, replace remote batteries, ensure LED power supply is connected.
TV stand feels wobbly after assembly.	Hardware not fully tightened, uneven floor.	Retighten all screws and cam locks. Use shims under the stand if the floor is uneven.

## 8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	LEMBERI
Model Name	PB-82TVS-50F
Product Dimensions	15.7"D x 82.6"W x 38.3"H
Material	Engineered Wood
Color	Black With Black Fireplace
Fireplace Size	50 inches
Heat Output	750 Watts / 1500 Watts (adjustable)
Heating Area	Up to 400 square feet
Special Features	LED Lighting (20 colors), 3D Flame Effect, Timer, Dimmer, Adjustable Shelves
Max TV Size Supported	Up to 90 inches
Weight Capacity	Up to 150 pounds (TV stand top)
Power Source	Corded Electric



*Image: A visual guide indicating the LEMBERI TV stand is suitable for TV sizes up to 90 inches, with examples of 32, 43, 55, 65, 82, and 90-inch televisions.*

## 9. WARRANTY AND CUSTOMER SUPPORT

---

LEMBERI products are manufactured with quality and care. This product comes with a limited warranty covering manufacturing defects. Please refer to the warranty card included in your package for specific terms and conditions. For technical assistance, missing parts, or warranty claims, please contact LEMBERI customer support. You can find more information and contact details on the official LEMBERI store page:

[Visit the LEMBERI Store on Amazon](#)