

[manuals.plus](#) /› [Element](#) /› [Element 2.1 Sound Bar & Subwoofer \(ESBAE21\) User Manual](#)

Element ESBAE21

Element 2.1 Sound Bar & Subwoofer (ESBAE21) User Manual

Model: ESBAE21

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Element 2.1 Sound Bar and Wireless Subwoofer (ESBAE21). Please read this manual thoroughly before operating the device and retain it for future reference.

The Element 2.1 Sound Bar and Wireless Subwoofer system is designed to enhance your home entertainment audio experience, delivering powerful, room-filling sound with deep bass and clear audio.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following precautions:

- Do not expose the unit to rain, moisture, or extreme temperatures.
- Do not block ventilation openings.
- Use only the power adapters provided with the unit.
- Avoid placing the unit near heat sources or in direct sunlight.
- Do not attempt to disassemble or modify the unit. Refer all servicing to qualified personnel.
- Keep the unit away from strong magnetic fields.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 Element Sound Bar
- 1 Wireless Subwoofer
- 1 Remote Control (batteries included)
- 2 Power Adapters (one for sound bar, one for subwoofer)
- 1 HDMI Cable
- 2 Mounting Screws

- 2 Wall Plugs
- 1 User Manual (this document)



Image 1: Element 2.1 Sound Bar and Subwoofer with included accessories.

4. SETUP

4.1 Physical Placement

The sound bar features a slim, space-saving design suitable for placement under your television or mounted on a wall. The wireless subwoofer can be placed anywhere in the room for optimal bass performance without requiring a direct cable connection to the sound bar.

- **Tabletop Placement:** Place the sound bar on a stable, flat surface directly in front of your TV.
- **Wall Mounting:** Use the included mounting screws and wall plugs to securely attach the sound bar to a wall. Ensure the wall can support the weight of the sound bar.
- **Subwoofer Placement:** Position the wireless subwoofer on the floor, ideally in a corner or near a wall, to enhance bass response.

4.2 Connection Options

The Element 2.1 Sound Bar offers multiple connectivity options for various devices:

- **HDMI (ARC):** For the best audio quality and control, connect the sound bar to your TV's HDMI ARC port using the supplied HDMI cable. This allows your TV remote to control the sound bar's volume.
- **Optical:** Connect an optical cable (not included) from your TV's optical output to the sound bar's optical input.
- **Auxiliary (AUX):** Use a 3.5mm audio cable (not included) to connect devices with an AUX output to the sound bar's AUX input.
- **USB:** Insert a USB drive containing audio files into the sound bar's USB port for direct playback.
- **Bluetooth:** For wireless audio streaming from compatible devices like smartphones, tablets, and laptops. Refer to Section 5.3 for Bluetooth pairing instructions.

4.3 Power Connection

Connect the provided power adapters to the sound bar and the subwoofer, then plug them into a standard electrical outlet. The units will automatically power on or enter standby mode.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Overview

The included remote control allows full command over the sound bar's functions. Ensure the batteries are correctly inserted.

- **Power Button:** Turns the sound bar on or off.
- **Input/Source Button:** Cycles through available input sources (HDMI, Optical, AUX, USB, Bluetooth).
- **Volume Up/Down:** Adjusts the master volume level.
- **Mute Button:** Mutes or unmutes the audio.
- **Bass/Treble Controls:** Adjusts bass and treble levels (if available).

- **Sound Modes:** Selects preset equalizer modes (e.g., Movie, Music, News).

5.2 Basic Operation

1. **Power On/Off:** Press the Power button on the remote or the sound bar.
2. **Select Input:** Press the Input/Source button repeatedly to select your desired audio source (e.g., HDMI, Optical, Bluetooth). The sound bar's indicator will show the active input.
3. **Adjust Volume:** Use the Volume Up (+) or Volume Down (-) buttons to set the listening level.

5.3 Bluetooth Pairing

To connect a Bluetooth device:

1. Turn on the sound bar and select the Bluetooth input mode. The Bluetooth indicator will typically flash, indicating it is in pairing mode.
2. On your mobile device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Element ESBAE21" (or similar name) from the list of devices.
4. Once paired, the Bluetooth indicator on the sound bar will become solid, and you can begin streaming audio.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your sound bar system:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the sound bar and subwoofer. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure that the ventilation openings are not obstructed to prevent overheating.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active	Ensure power cables are securely connected to the sound bar, subwoofer, and a working power outlet.
No sound	Incorrect input selected; Volume too low; Mute activated; Cable connection issue	Select the correct input source. Increase volume. Deactivate mute. Check all audio cables for secure connection.
Bluetooth pairing fails	Sound bar not in pairing mode; Device too far; Interference	Ensure sound bar is in Bluetooth pairing mode. Move device closer to sound bar. Turn off other Bluetooth devices.
Remote control not working	Batteries depleted; Obstruction between remote and sound bar	Replace remote control batteries. Ensure clear line of sight between remote and sound bar.

8. SPECIFICATIONS

Detailed technical specifications for the Element 2.1 Sound Bar & Subwoofer (ESBAE21):

- **Model Name:** ESBAE21
- **Speaker Type:** Soundbar with Wireless Subwoofer
- **Surround Sound Channel Configuration:** 2.1
- **Speaker Maximum Output Power:** 120 Watts
- **Connectivity Technology:** Auxiliary, Bluetooth, HDMI (ARC), Optical, USB
- **Wireless Communication Technology:** Bluetooth, Wi-Fi
- **Control Method:** Remote
- **Power Source:** Corded Electric
- **Material:** Metal, Plastic
- **Mounting Type:** Wall Mount, Tabletop
- **Compatible Devices:** Television, Laptop, Tablet, Smartphone
- **UPC:** 810649034157
- **Manufacturer:** Element

9. WARRANTY AND SUPPORT

9.1 Limited Warranty

The Element 2.1 Sound Bar & Subwoofer (ESBAE21) comes with a limited warranty. Please refer to the warranty card included in your package or visit the official Element website for detailed terms and conditions regarding coverage, duration, and claims procedures.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Element customer support. Contact information can typically be found on the Element official website or on the product packaging.