Wobble WB32QDZGU2841BT

Wobble Z Series 32-inch HD Smart QLED TV WB32QDZGU2841BT User Manual

Model: WB32QDZGU2841BT

1. Introduction

Thank you for choosing the Wobble Z Series 32-inch HD Smart QLED TV. This manual provides essential information for setting up, operating, and maintaining your new television. Please read this manual thoroughly before using the product and retain it for future reference.



Image of the Wobble Z Series 32-inch HD Smart QLED TV, showcasing its slim bezel design and display.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Place the TV on a stable, level surface to prevent it from falling.
- Use only the power cable supplied with the TV.
- Unplug the TV during lightning storms or when unused for long periods.
- Do not open the TV casing. Refer all servicing to qualified personnel.
- Keep small parts and batteries out of reach of children.

3. Package Contents

Verify that all items are present in the package:

- Wobble Z Series 32-inch HD Smart QLED TV
- Power Cable
- Remote Control (with batteries)
- Table Stand (if applicable, assembly required)
- User Manual (this document)
- Warranty Card

4. Setup

4.1 Physical Installation

Table Stand Installation: If using the included table stand, carefully attach it to the bottom of the TV using the provided screws. Ensure the stand is securely fastened before placing the TV on a stable surface.
Wall Mounting: If wall mounting, use a compatible VESA wall mount kit (sold separately) and follow the instructions provided with the wall mount. Ensure the wall can support the TV's weight.

4.2 Connecting Power

Connect the supplied power cable to the TV's power input port and then plug the other end into a suitable AC power outlet.

4.3 Connecting External Devices

Your TV features multiple ports for connecting external devices:

- **HDMI Ports:** Connect Blu-ray players, gaming consoles, set-top boxes, etc.
- **USB Ports:** Connect USB storage devices for media playback.
- **Antenna/Cable Input:** Connect an antenna or cable TV feed.
- **Ethernet Port:** For a wired internet connection.

4.4 Initial Setup (Google TV)

Upon first power-on, the TV will guide you through the initial setup process for Google TV. This includes:

1. **Language Selection:** Choose your preferred language.
2. **Network Connection:** Connect to your Wi-Fi network (Dual Band WiFi supported) or use an Ethernet cable.
3. **Google Account Sign-in:** Sign in with your Google account to access Google TV features, apps, and personalized recommendations.
4. **Channel Scan:** Scan for available TV channels if an antenna or cable is connected.
5. **Privacy Settings:** Configure your privacy preferences.

5. Operating the TV

5.1 Remote Control

The remote control allows you to navigate the Google TV interface, adjust settings, and control playback. Familiarize yourself with the buttons for power, volume, channel, input selection, and dedicated app buttons (e.g., Netflix, Prime Video, YouTube).
Bluetooth Connectivity: The remote uses Bluetooth for enhanced control. Ensure it is paired during initial setup or

via the TV's settings menu if necessary.

5.2 Google TV Interface

Google TV organizes your entertainment from various apps and subscriptions into a single, personalized home screen. You can:

- Browse movies and TV shows across your streaming services.
- Discover new content based on your viewing history.
- Access installed apps like Netflix, Prime Video, and YouTube directly.
- Use Google Assistant for voice commands (if supported by your remote).

5.3 Picture and Sound Settings

Access the TV's settings menu to customize picture and sound:

- **Picture Modes:** Select from standard, vivid, movie, sport, or custom modes. Adjust brightness, contrast, color, and sharpness. Features like QLED, Micro dimming, MFSE, Pro Saturation, and HDR10 enhance visual quality.
- **Sound Modes:** Choose from standard, music, movie, speech, or custom modes. Adjust bass, treble, and balance. The 30W Ultra Speakers and Dolby Audio technology provide an immersive audio experience.

6. Maintenance

Proper maintenance ensures the longevity of your TV:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Do not spray cleaner directly onto the screen.
- **Cleaning the Casing:** Use a soft, dry cloth to wipe the TV casing. Avoid abrasive cleaners.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked by dust or objects.
- **Power Cord:** Regularly check the power cord for any damage.

7. Troubleshooting

If you encounter issues with your TV, refer to the following common solutions:

Problem	Possible Solution
No power	Ensure the power cable is securely connected to both the TV and the power outlet. Check if the outlet is working.
No picture, but sound is present	Check the input source. Ensure external devices are powered on and connected correctly.
No sound, but picture is present	Check the volume level and mute status. Verify audio cables for external devices.
Remote control not working	Replace batteries. Ensure no obstructions between the remote and TV. Re-pair the Bluetooth remote if necessary.
Cannot connect to Wi-Fi	Check your router and modem. Ensure the Wi-Fi password is correct. Try restarting the TV and router.

Problem	Possible Solution
Apps are slow or freezing	Close unused apps. Clear app cache in settings. Ensure sufficient internet speed. Restart the TV.

If the problem persists, please contact customer support.

8. Specifications

Feature	Detail
Brand	Wobble
Model	WB32QDZGU2841BT
Screen Size	32 Inches (80.01 cm)
Display Technology	QLED
Resolution	HD (1366x768), 720p
Refresh Rate	60 Hz
Operating System	Google TV with Android 14
Processor	A55 Quad Core Processor
RAM	1.5GB
Storage	16GB
Audio Output	30W Ultra Speakers, Dolby Audio
Connectivity	Dual Band WiFi, Bluetooth
Special Features	Micro dimming, MFSE, 16.7 Million Colours, Pro Saturation, HDR10, Zero Edge Design
Product Dimensions (LxWxH)	19.2 x 71.6 x 47.4 cm
Item Weight	3.85 kg
Included Components	Power Cable

9. Warranty and Support

Your Wobble Z Series 32-inch HD Smart QLED TV is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.
For technical support, troubleshooting assistance, or service requests, please contact Wobble customer support. Contact information can typically be found on the warranty card or the official Wobble website.
Manufacturer: Dixon Technologies (India) Limited