

[Manuals.plus](#) /

› [Lehoo Castle](#) /

› Lehoo Castle Dinosaur Sit and Spin Toy Instruction Manual

Lehoo Castle SNS-001-E

Lehoo Castle Dinosaur Sit and Spin Toy Instruction Manual

Model: SNS-001-E

1. INTRODUCTION AND OVERVIEW

The Lehoo Castle Dinosaur Sit and Spin Toy is designed to provide engaging and active play for toddlers aged 1-4. This unique toy features 360° spinning action, LED lights, and music, promoting motor skills, body coordination, and sensory development. It is suitable for both indoor and outdoor use.

The toy includes three customizable modes: Lights & Music, Lights Only, or Silent spinning, allowing children to tailor their play experience. The gentle glow-in-the-dark effect and adorable dinosaur-on-truck designs enhance the multi-sensory experience.

Through twisting to control speed and direction, children can practice and master crucial balance, coordination, motor skills, and concentration. This makes it an ideal sensory development tool for preschoolers, including those with autism.



Image: Child enjoying the 360-degree spinning action of the Lehou Castle Dinosaur Sit and Spin Toy.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Assembly is required. Adult supervision is recommended during play.

The Lehou Castle Sit and Spin Toy is crafted from safe and stable ABS material, featuring an ergonomic non-slip handle and smooth rounded edges for child safety. Its sturdy construction supports up to 130 lbs, allowing for safe play. The roomy 17.5-inch diameter base can accommodate up to two children playing together.

3. PACKAGE CONTENTS

- 1 x Spinning Base
- 1 x Central Post
- 1 x Top Handle with Dinosaur Enclosure

- Screws for assembly
- 1 x Screwdriver

4. SETUP AND ASSEMBLY

Assembly of the Lehoo Castle Dinosaur Sit and Spin Toy is quick and straightforward. Please follow these steps:

1. **Connect the Top:** Align the central post with the top handle unit and firmly connect them.
2. **Secure the Top:** Use the provided screwdriver to tighten the two small screws located on the underside of the top handle unit, securing it to the central post.
3. **Connect the Base:** Insert the bottom of the central post into the designated slot on the spinning base.
4. **Secure the Base:** Tighten the large screw on the underside of the spinning base to firmly attach the central post.
5. **Install Batteries:** Locate the battery compartment on the underside of the top handle unit. Unscrew the cover, insert 2 AA batteries (not included) ensuring correct polarity, and then replace the cover and screw it shut.

Your browser does not support the video tag.

Video: This video demonstrates the quick assembly process for the Sit and Spin toy, showing how to connect the parts and secure them with screws.



Image: Detailed diagram illustrating the assembly steps for the Sit and Spin toy.

5. OPERATING INSTRUCTIONS

To operate the Lehoo Castle Dinosaur Sit and Spin Toy, follow these guidelines:

- **Sitting Position:** Have the child sit on the spinning base with their legs wrapped around the central post, holding onto the ergonomic handle.
- **Initiate Spinning:** The child can use their feet to push off the floor and initiate the spinning motion. They can also pull on the central handle to help rotate the base.
- **Control Speed and Direction:** Encourage the child to experiment with twisting their body and pulling the handle to spin faster, slower, forward, or backward. This helps develop balance and coordination.
- **Light and Music Modes:** Use the simple On/Off switch located on the underside of the top handle unit to select one of three modes:
 - **Lights & Music:** Activates both the cheerful songs and softly flashing LED lights.

- **Lights Only:** Activates only the flashing LED lights.
- **Silent Spinning:** Disables both lights and music for quiet play.



Image: The control panel showing the 3 adjustable modes for lights and music.

Your browser does not support the video tag.

Video: This video demonstrates how the sensory spin toy aids in balance and coordination development through active play.

6. MAINTENANCE

To ensure the longevity and cleanliness of your Lehou Castle Dinosaur Sit and Spin Toy, follow these simple maintenance steps:

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap as needed. Avoid using abrasive cleaners or harsh chemicals, as these can damage the plastic and decals.
- **Drying:** Ensure the toy is completely dry before storing or allowing children to play with it again.

- **Storage:** Store the toy in a cool, dry place away from direct sunlight to prevent material degradation and fading of colors.
- **Battery Replacement:** If the lights or music become dim or stop working, replace the 2 AA batteries in the top handle unit. Always use new batteries and dispose of old ones responsibly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights and/or music not working	Batteries are dead or incorrectly installed. Switch is in the 'Off' or 'Lights Only' position.	Replace batteries with new 2 AA batteries, ensuring correct polarity. Check the On/Off switch and set it to 'Lights & Music' or 'Lights Only' as desired.
Toy does not spin smoothly	Obstruction under the base. Loose assembly.	Check the area under the toy for any objects. Ensure all screws are tightened securely as per assembly instructions.
Toy feels unstable during use	Loose assembly. Uneven surface.	Verify that all parts are correctly assembled and screws are tight. Ensure the toy is used on a flat, stable surface.

8. SPECIFICATIONS

- **Brand:** Lehoo Castle
- **Model Number:** SNS-001-E
- **Material Type:** Acrylonitrile Butadiene Styrene (ABS)
- **Item Dimensions:** 17.88 x 4.44 x 17.88 inches
- **Size (Diameter):** 17.5 Inches
- **Maximum Weight Capacity:** 130 lbs
- **Power Source:** 2 AA batteries (not included)
- **Assembly Required:** Yes
- **Educational Objective:** Enhance motor skills, coordination, and sensory development
- **Theme:** Animal (Dinosaur)

LARGE SIZE & CAPACITY

1.5-5 years
old



Loadable
130 lbs



28cm/11in

45.5cm/17.9in

Image: Large size and capacity details for the Sit and Spin toy.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Lehou Castle Dinosaur Sit and Spin Toy, please contact Lehou Castle customer service. Refer to the product packaging or the official Lehou Castle website for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question