

[Manuals.plus](#) /

› [Globber](#) /

› Globber ECO Learning Trike 3-in-1 User Manual

## Globber 738-109

# Globber ECO Learning Trike 3-in-1 User Manual

**Brand:** Globber | **Model:** 738-109

## 1. INTRODUCTION

---

The Globber ECO Learning Trike 3-in-1 is designed to support the developmental stages of toddlers aged 12 to 36 months. This versatile product transforms from a guided trike to a training trike and then to a balance bike, encouraging motor skill development, balance, and confidence. It features a 100% tool-less design and a patented wheel switch mechanism for easy adaptation as your child grows.



Image: The Globber ECO Learning Trike 3-in-1 in Pistachio, showcasing its compact and ergonomic design.

## 2. SAFETY INFORMATION

---

Please read and understand all safety warnings and instructions before assembly and use. Failure to follow these instructions may result in serious injury.

- Always supervise children when using the trike.
- Ensure all parts are securely fastened before each use.
- Children must wear a helmet and appropriate protective gear (knee pads, elbow pads) at all times.
- Do not use on public roads, near motor vehicles, steep inclines, or stairs.
- The trike is designed for children aged 12 to 36 months.
- Maximum weight capacity: Refer to specifications.
- Regularly check for loose parts, damage, or wear. Replace worn parts immediately.
- Keep hands and feet clear of moving parts.

### 3. PACKAGE CONTENTS

---

Verify that all components are present and undamaged before proceeding with assembly.

- (1) Globber ECO Learning Trike 3-in-1 (main frame, wheels, seat, handlebars, parent handle, pedals, basket)

### 4. ASSEMBLY AND SETUP

---

The Globber ECO Learning Trike features a 100% tool-less design for quick and easy assembly and mode transitions.

#### Initial Assembly

1. **Attach Front Wheel and Handlebars:** Insert the front wheel assembly into the main frame. Secure the handlebars by pushing them firmly into place until you hear a click.
2. **Attach Rear Wheels:** Slide the rear wheel assembly onto the main frame. Ensure they lock securely.
3. **Install Seat:** Position the dual-height saddle onto the frame and adjust to the desired height (27.1cm or 28.3cm from the ground) by pressing the adjustment button and sliding.
4. **Attach Basket:** Clip the removable front TPR basket onto the front of the handlebars.



Image: Front view of the trike, illustrating the handlebar and basket attachment points.

## Video: Assembly and Mode Transitions

Your browser does not support the video tag.

Video: Official demonstration of the Globber Learning Trike 3-in-1, showing assembly and seamless transitions between its three modes.

## 5. OPERATING INSTRUCTIONS

---

The ECO Learning Trike offers three distinct modes to adapt to your child's growth and skill level.

### 5.1 Guided Trike Mode (12-36 months)

In this mode, parents maintain control using the adjustable parent handle. The child can rest their feet on the footrests or learn to pedal if the pedals are attached.

- **Attach Parent Handle:** Insert the 2-position height adjustable parent handle into the designated slot at the rear of the trike. Ensure it clicks into place.
- **Footrests:** Ensure the child's feet are comfortably placed on the footrests if not pedaling.



Image: A child riding the trike in guided mode, with a parent steering using the adjustable handle.

## 5.2 Training Trike Mode (18-36 months)

Once your child is ready to pedal independently, transition to this mode. The parent handle can be removed, and pedals can be attached.

- **Remove Parent Handle:** Press the release button and pull the parent handle out.
- **Attach Pedals:** Insert the removable pedals into the front wheel. Ensure they are securely locked. Pedals can be stored under the saddle when not in use.



Image: The trike configured for training mode, featuring attached pedals and no parent handle.

### 5.3 Balance Bike Mode (24-36 months)

This mode helps children develop balance and coordination before transitioning to a two-wheeled bicycle. The pedals and parent handle are removed, and the rear wheels are brought together.

- **Remove Pedals:** Detach the pedals and store them under the saddle.
- **Convert Rear Wheels:** Utilize the patented wheel switch mechanism to bring the two rear wheels together, transforming the trike into a balance bike. This is a tool-less process.



Image: The trike converted into a balance bike, with the rear wheels merged and pedals removed.

## Mode Transition Overview



Image: A visual guide illustrating the seamless transformation of the trike through its guided, training, and balance bike modes.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and safe operation of your Globber ECO Learning Trike.

- **Cleaning:** Wipe down the trike with a damp cloth and mild soap. Avoid harsh chemicals.
- **Inspection:** Periodically check all bolts, screws, and quick-release mechanisms to ensure they are tight and secure.
- **Wheels:** Inspect EVA foam wheels for wear or damage.
- **Storage:** Store the trike in a dry place away from direct sunlight and extreme temperatures to prevent material degradation.

## 7. TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Trike feels unstable:** Ensure all assembly points (handlebars, seat, wheels) are securely locked into place.
- **Pedals not engaging:** Verify that the pedals are correctly inserted and locked into the front wheel mechanism.
- **Difficulty adjusting seat/handle:** Ensure no debris is obstructing the adjustment mechanism. Apply gentle pressure while pressing the release button.
- **Wheels not turning smoothly:** Check for any foreign objects lodged in the wheels or axles. Ensure wheels are properly seated.

For issues not covered here, please contact Globber customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand Name	Globber
Model Number	738-109
Manufacturer Minimum Age	12 Months
Manufacturer Maximum Age	36 Months
Material Type	Recycled plastic (PP, reinforced)
Item Weight	2.4 Kilograms
Item Dimensions (L x W x H)	32.7"L x 16.6"W x 33.3"H (approx.)
Saddle Height	2-height adjustable (27.1 cm or 28.3cm from ground)
Assembly Required	Yes (tool-less)

## 9. WARRANTY AND SUPPORT

Globber products are manufactured to high standards and are covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty details, registration, or to contact customer support, please visit the official Globber website or refer to the warranty card included with your product.

For further assistance, please contact your retailer or Globber customer service directly.

