

SMOTURE VAC03

SMOTURE VAC03 Cordless Vacuum Cleaner User Manual

Model: VAC03

1. INTRODUCTION

Welcome to the SMOTURE VAC03 Cordless Vacuum Cleaner. This manual provides essential information for safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and retain it for future reference.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Use the appliance only as described in this manual.
- Do not use with a damaged power cord or plug.
- Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- Do not pick up flammable or combustible materials (e.g., lighter fluid, gasoline, kerosene) or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and filters properly installed.
- Use only the charger supplied by the manufacturer.
- Do not store the appliance near heat sources or in direct sunlight.
- Do not incinerate the battery.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- 600W 45KPA Cordless Vacuum Main Body
- Extra Upholstery Cleaning Tool
- Crevice Tool

- Dusting Brush
- Mini Cleaning Tool
- Two Extra HEPA Filters
- Battery
- Charger
- Electric Floor Brush with Anti-tangle Roller
- Wall-mounted Charging Dock
- Adjustable Tube
- Quick User Manual



Figure 3.1: All components included with the SMOTURE VAC03 Cordless Vacuum Cleaner.

4. PRODUCT OVERVIEW

The SMOTURE VAC03 is a versatile cordless vacuum cleaner designed for various cleaning tasks. It features

a powerful motor, multiple suction modes, and specialized attachments for different surfaces.



Figure 4.1: Overview of the SMOTURE VAC03 main unit and its attachments.

5. ASSEMBLY

Follow these steps to assemble your SMOTURE VAC03 Cordless Vacuum Cleaner:

1. Attach the dust cup to the main motor body. Ensure it clicks securely into place.

2. Insert the battery pack into the handle of the main unit until it locks.
3. Connect the adjustable tube to the main unit.
4. Attach the electric floor brush to the other end of the adjustable tube.
5. For handheld use, attach desired accessories (crevice tool, dusting brush, or upholstery cleaning tool) directly to the main unit.

Video 5.1: Demonstration of how to install the dust canister and battery onto the vacuum cleaner's main body.

6. CHARGING

Before first use, fully charge the battery. The battery can be charged while attached to the vacuum or separately.

- **Wall-Mounted Charging:** Install the wall-mounted charging dock in a convenient location. Place the vacuum onto the dock to charge.
- **Separate Charging:** Remove the battery from the vacuum and connect it directly to the charger.

A full charge typically takes approximately 4 hours. The LED display on the vacuum will indicate charging status.

Self-Standing Feature

We no longer have to find a spot to prop the vacuum up



Figure 6.1: The vacuum cleaner being charged on its integrated wall-mounted dock.

7. OPERATION

Your SMOTURE VAC03 offers multiple modes and features for effective cleaning.

7.1 Powering On and Suction Modes

Press the power button to turn on the vacuum. Use the mode selection button to cycle through the following suction modes:

- **ECO Mode:** Provides up to 60 minutes of runtime for light cleaning tasks.
- **STANDARD Mode:** Offers balanced suction for everyday cleaning, with approximately 30 minutes of runtime.
- **BOOST Mode:** Delivers maximum suction (45KPA) for deep cleaning and stubborn debris, with approximately 15-20 minutes of runtime.
- **AUTO Mode:** The vacuum automatically adjusts suction power based on the surface type (hard floor or carpet) to optimize cleaning and battery life.

Video 7.1: Overview of the SMOTURE VAC03 Cordless Vacuum Cleaner's features and operation, including its 600W motor and 45KPA suction.

Video 7.2: A brief demonstration highlighting the powerful 600W brushless motor of the vacuum cleaner.



Figure 7.1: Visual representation of the 600W brushless motor and 45KPA suction capability.

7.2 Specialized Cleaning Tools

- **Electric Floor Brush:** Ideal for both hard floors and carpets. The anti-tangle roller helps prevent hair wrap.
- **Mattress Cleaning Tool:** Use this specialized tool to effectively remove dust mites, pet dander, and hair from mattresses, upholstery, and pet beds.
- **Crevice Tool:** Perfect for narrow gaps, corners, and hard-to-reach areas.

- **Dusting Brush:** Suitable for cleaning delicate surfaces, curtains, and keyboards.



Figure 7.2: The mattress cleaning tool effectively removing debris from a mattress surface.

7.3 Self-Standing Feature

The vacuum is designed to stand upright on its own, allowing you to pause cleaning conveniently without needing to lean it against a wall or furniture.



Figure 7.3: The vacuum cleaner demonstrating its self-standing capability.

7.4 Runtime

The 8-cell lithium-ion battery provides sufficient runtime for cleaning homes up to 2,500 sq. ft. Runtime varies by mode:

- ECO Mode: Up to 60 minutes
- STANDARD Mode: Approximately 30 minutes
- BOOST Mode: Approximately 15-20 minutes

Integrated Wall Charging Mount

Charging and storage 2 in 1



Figure 7.4: Visual representation of the vacuum's 60-minute runtime.

8. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

8.1 Emptying the Dustbin

Empty the dustbin regularly, especially when debris reaches the 'MAX' line. Press the dustbin release button to detach it from the main unit, then open the bottom flap to empty contents into a trash receptacle.

Video 8.1: Instructions on how to remove and re-install the dust canister and battery for cleaning or replacement.

8.2 Cleaning Filters

The vacuum features a multi-layer high-density filtration system, including washable HEPA filters. Clean filters regularly to maintain suction power.

1. Remove the dust cup and separate the filter components.
2. Tap off loose dirt. Rinse the HEPA filter and other washable filters under cold water.
3. Allow filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or other heating methods.

8.3 Cleaning the Brush Roll

Periodically check the electric floor brush for tangled hair or debris. To clean:

1. Turn off the vacuum and detach the floor brush.
2. Locate the release mechanism on the side of the brush head and remove the brush roll.
3. Use scissors or the provided mini cleaning tool to cut and remove any tangled hair or fibers.
4. Reinsert the brush roll and secure the release mechanism.

Video 8.2: A step-by-step guide on how to remove and install the roller brush from the vacuum cleaner head.

9. TROUBLESHOOTING

If you encounter issues with your SMOTURE VAC03, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery not charged or not properly installed.	Ensure battery is fully charged and securely inserted.
Low suction power	Dustbin full, filters clogged, or brush roll obstructed.	Empty dustbin, clean filters, and remove any obstructions from the brush roll.
Brush roll not spinning	Obstruction in brush roll or brush roll not properly installed.	Clear any debris from the brush roll and ensure it is correctly reinstalled.
Short runtime	Using BOOST mode frequently or battery not fully charged.	Charge battery fully. Use ECO or STANDARD mode for longer cleaning sessions.

If the problem persists, please contact customer support.

10. SPECIFICATIONS





Feature	Detail
Brand	SMOTURE
Model Name	VAC03
Motor Power	600W Brushless Motor



Feature	Detail
Suction Power	45KPA
Battery Type	8-cell Lithium-Ion
Max Runtime	60 minutes (ECO Mode)
Charging Time	4 Hours
Dustbin Capacity	1.5 Liters
Filter Type	Multi-layer High-density Filtration System (HEPA washable)
Form Factor	Stick
Product Dimensions	11"L x 10"W x 46"H
Item Weight	6 pounds
Noise Level	64 Decibels

11. WARRANTY AND SUPPORT

SMOTURE provides a 3-year protection plan for this product. We also offer 24/7 after-sales service to assist with any inquiries or issues you may have. Additionally, a 30-day easy return and exchange policy is available. If you require assistance or believe your machine's runtime is shorter than expected, please contact our support team.

Related Documents - VAC03

	SMOTURE VAC03 Cordless Vacuum Cleaner User Manual Official user manual for the SMOTURE VAC03 Cordless Vacuum Cleaner, providing detailed instructions on operation, maintenance, troubleshooting, specifications, and warranty information.
	SMOTURE VAC02 Cordless Vacuum Cleaner User Manual Comprehensive user manual for the SMOTURE VAC02 Cordless Vacuum Cleaner, covering setup, operation, maintenance, troubleshooting, specifications, and warranty information. Learn how to use and care for your vacuum cleaner.
	SMOTURE VAC01 Cordless Vacuum Cleaner User Manual Comprehensive user manual for the SMOTURE VAC01 Cordless Vacuum Cleaner, covering safety instructions, package contents, product features, operation guide, maintenance procedures, troubleshooting tips, and warranty information.
	SMOTURE VAC01 SMOTURE VAC01

 The image shows the cover of the user manual for the SMOTURE VAC01 Cordless Vacuum Cleaner. It has an orange background with a white line drawing of the vacuum cleaner. The text on the cover includes 'SMOTURE', 'User Manual', and 'Cordless Vacuum Cleaner'.	<p>SMOTURE VAC01 Cordless Vacuum Cleaner User Manual</p> <p>This user manual provides comprehensive instructions for the SMOTURE VAC01 Cordless Vacuum Cleaner, covering product details, assembly, operation, maintenance, specifications, troubleshooting, and warranty information to ensure safe and efficient use.</p>
 The image is a promotional graphic for the SMOTURE Cordless Vacuum Cleaner. It features a woman in a white shirt and dark pants standing in a modern living room. The vacuum cleaner is shown in a green and white color scheme. Text overlays include 'Cordless Vacuum Cleaner', '600W', '50000Pa', and 'Intelligent Auto Mode'.	<p>SMOTURE Cordless Vacuum Cleaner with 600W Motor and Intelligent Auto Mode</p> <p>Discover the SMOTURE Cordless Vacuum Cleaner, featuring a powerful 600W brushless motor, 50000Pa suction, intelligent auto mode that adjusts to surfaces, an efficient filtration system, and a long-lasting rechargeable battery with wall mount storage.</p>