

[Manuals.plus](#) /

› [Vekkia](#) /

› Vekkia MST116 Professional 116 LED Rechargeable Music Stand Light User Manual

Vekkia MST116

Vekkia MST116 Professional 116 LED Rechargeable Music Stand Light User Manual

Model: MST116 | Brand: Vekkia

1. INTRODUCTION

The Vekkia MST116 Professional 116 LED Rechargeable Music Stand Light is designed to provide optimal illumination for musicians, readers, and crafters. Featuring advanced SMD LED technology, this foldable clip-on lamp offers eye-protective lighting with customizable brightness and color temperature settings. Its versatile design allows for secure attachment to various surfaces or independent standing, making it ideal for diverse applications.



Figure 1: Vekkia MST116 Professional 116 LED Rechargeable Music Stand Light.

2. WHAT'S IN THE BOX

Upon unboxing your Vekkia MST116 Music Stand Light, please ensure all the following items are present:

- Music Stand Light (1 unit)
- Type-C USB Cable (1 unit)
- Instruction Manual (1 unit)
- Free Carry Bag (1 unit)

Your browser does not support the video tag.

3. PRODUCT FEATURES

- **Advanced SMD LED Technology:** Provides uniform, glare-free light with 116 high-quality LED beads, ensuring comfortable viewing and reduced eye fatigue. The color rendering index (Ra) is adjusted for eye protection.



Figure 2: Illustration of 116 LEDs for uniform light and eye protection.

- **Customizable Lighting:** Offers 5 brightness levels and 3 color temperature options (warm, white, daylight) for a total of 15 lighting modes.




Figure 3: Visual representation of the 3 color temperatures and 5 brightness levels.

- **Professional Broadbeam with Anti-Glare Shield:** The lamp's design ensures a wide illumination area that covers an 88-key digital piano, with a discrete back fin to direct light onto sheet music and away from the audience.




Figure 4: Comparison of illumination range, highlighting coverage for an 88-key digital piano.

- **Lightweight & Versatile Clip-on Design:** Weighing only 9oz, the lamp features a clamp that opens up to 2.36 inches, suitable for music stands, pianos, or desks. Patented anti-slip rubber strips protect surfaces from scratches. It can also stand independently.



Figure 5: Details of the firm clamping mechanism and flexible gooseneck.

- **Long-Lasting Rechargeable Battery:** Equipped with a 4000mAh battery, providing up to 100 hours of continuous use at the lowest brightness setting. Easily charged via USB-C (cable included).



Figure 6: Information on the rechargeable battery, working hours, and charging.

4. SETUP

4.1 Attaching the Light

1. Identify the desired surface for attachment (e.g., music stand, piano, desk).
2. Open the clip by pressing the top lever. The clip can open up to 2.36 inches.
3. Position the clip securely onto the edge of the surface. The anti-slip rubber strips will help prevent scratches and ensure stability.
4. Alternatively, the light can stand independently on a flat surface.



Figure 7: The flexible gooseneck allows for precise positioning of the light.

4.2 Adjusting the Gooseneck

The flexible gooseneck allows for 360-degree adjustment. Bend and twist the gooseneck to position the light head directly over your music or work area for optimal illumination.



Figure 8: The extendable lighting head provides wider coverage.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the **Power Button** (center button on the light head) to turn the light ON or OFF.

5.2 Adjusting Brightness

The light offers 5 brightness levels. Short click the **Brightness Level Button** (right button on the light head) to cycle through the 5 levels. Long press for stepless dimming adjustment.

5.3 Adjusting Color Temperature

The light offers 3 color temperature options (Warm, White, Daylight). Short click the **Color Temperature Button** (left button on the light head) to cycle through the options.




Figure 9: Close-up of the control buttons on the light head.

5.4 Charging the Battery

Connect the included Type-C USB cable to the charging port on the clip base and to a USB power source (AC adapter not included). The four blue LED indicators on the clip base will show the charging status. When all four LEDs are solid, the battery is fully charged.

ATTENTIVE DESIGN FOR USERS

Four power indicators remind you if you need to charge before the performance



Figure 10: The power indicator LEDs on the clip base.

Your browser does not support the video tag.

Video 2: Demonstration of the music stand light's brightness and color temperature settings in a night-time environment.

Your browser does not support the video tag.

Video 3: Overview of the 5 brightness settings and 3 color temperatures, highlighting the USB-C charging capability.

6. MAINTENANCE

6.1 Cleaning

To clean the light, gently wipe it with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish or electronic components.

6.2 Battery Care

To prolong battery life, avoid leaving the light plugged in for extended periods once fully charged. Recharge the battery when the power indicators show a low charge.

6.3 Storage

When not in use, fold the light and store it in the provided carry bag to protect it from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.

We Offer a Portable Bag Along With Our Product, So You Can Conveniently Carry It Wherever You Go

Going Out to Perform

How to Fold in Carry Bag




Figure 11: Instructions on how to fold the light for storage in the carry bag.

7. TROUBLESHOOTING

- **Light not turning on:** Ensure the battery is charged. Press the power button firmly. If the battery is depleted, connect the USB-C cable to a power source.
- **Light not charging:** Verify that the USB-C cable is securely connected to both the light and the power source. Try a different USB-C cable or power adapter if available. Check the power indicator LEDs for charging status.
- **Inconsistent brightness or color:** Ensure the light head is clean and free from obstructions. If issues persist, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Name	MST116
Number of Light Sources	116 LEDs
Wattage	6 Watts
Power Source	Battery Powered
Battery Life	Up to 100 Hours (low brightness)
Charging Port	USB Type-C
Brightness Levels	5
Color Temperatures	3 (Cool White, Warm White, Daylight)

Product Dimensions	3.15"D x 11.82"W x 10.23"H
Item Weight	1 pound
Material	Plastic
Indoor/Outdoor Usage	Indoor

9. WARRANTY AND SUPPORT

9.1 Warranty

The Vekkia MST116 Music Stand Light comes with a 12-month coverage period from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

9.2 Return Policy

A 30-day refund policy is available from the date of purchase. Please refer to the retailer's specific return instructions for details.

9.3 Customer Support

For any questions, technical assistance, or warranty claims, please contact Vekkia customer support. We aim to reply within 24 hours.

Online Support: Visit the [Vekkia Store on Amazon](#) for product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question