

NEEWER PA985

NEEWER BASICS PA985 Magnetic Selfie Stick Tripod User Manual

Model: PA985

1. PRODUCT OVERVIEW

The NEEWER BASICS PA985 is a versatile and portable magnetic selfie stick tripod designed for smartphones. It combines the functionality of a handheld grip, an extendable selfie stick, and a stable desktop tripod. Its compact design makes it ideal for various content creation needs, including video recording, vlogging, and live streaming.

- **Compact and Portable:** Folds down to 4.6 inches (11.65 cm) and weighs only 6.8 oz (194 g), easily fitting into a pocket or bag.
- **Magnetic Attachment:** Compatible with MagSafe iPhones (12 series and newer) for quick and secure attachment.
- **Universal Compatibility:** Includes a magnetic ring and phone clip holder for use with non-MagSafe smartphones like Samsung Galaxy, Google Pixel, and Huawei.
- **Multi-functional Design:** Functions as a handheld grip, an extendable selfie stick, and a stable desktop tripod.
- **Flexible Angles:** Features a 180° tilt joint and a 360° rotating magnetic ring for seamless switching between portrait and landscape modes and various shooting angles.
- **Detachable Wireless Remote:** Comes with a Bluetooth remote shutter for capturing photos or starting/stopping videos from up to 33 feet (10 meters) away.




Image 1.1: The PA985 tripod demonstrating its wide application as a desktop stand, selfie stick, and handheld grip.

2. SETUP INSTRUCTIONS

2.1 Package Contents

- 1 x NEEWER BASICS PA985 Magnetic Selfie Stick Tripod
- 1 x Charging Cable (for remote)
- 1 x Magnetic Ring (for non-MagSafe phones)

Image 2.1: Visual representation of the PA985 package contents.

2.2 Attaching Your Smartphone

The PA985 offers two methods for attaching your smartphone:

1. **For MagSafe Compatible Phones (iPhone 12 series and newer):** Simply align your MagSafe-enabled iPhone or MagSafe-compatible phone case with the magnetic holder on the tripod head. The magnets will securely attach the phone.
2. **For Non-MagSafe Phones (e.g., Samsung, Google Pixel, Huawei):**
 - **Option A (Magnetic Ring):** Peel off the adhesive backing from the included magnetic ring and firmly attach it to the center back of your phone or phone case. Once attached, your phone can be magnetically mounted to the tripod head.
 - **Option B (Phone Clip Holder):** Expand the included phone clip holder and securely place your smartphone within its jaws. The phone clip can then be magnetically attached to the tripod head.



Image 2.2: Instructions for attaching both MagSafe and non-MagSafe phones.

2.3 Pairing the Wireless Bluetooth Remote

1. Ensure the remote control is charged.
2. Turn on the remote control (usually by pressing and holding a button until an indicator light flashes).
3. On your smartphone, navigate to the Bluetooth settings.
4. Search for available devices. The remote should appear as "VIP" or a similar device name.
5. Select the remote to pair. Once paired, the indicator light will typically stop flashing or turn solid.



Image 2.3: Steps for pairing the wireless Bluetooth remote.

3. OPERATING INSTRUCTIONS

3.1 Adjusting Height and Mode

The PA985 can be used in several configurations:

- **Desktop Tripod Mode:** Press the quick setup button at the bottom of the handle to deploy the tripod legs. Place on a flat surface for stable recording or viewing.
- **Selfie Stick Mode:** Extend the telescopic sections upwards to achieve desired height for wider shots or group photos. The stick extends from 10 inches (25.5 cm) to 16.5 inches (42 cm).
- **Handheld Grip Mode:** Fold the tripod legs back into the handle for a compact and stable handheld grip, ideal for on-the-go recording.



Image 3.1: The telescopic height adjustment of the PA985 tripod.


3.2 Adjusting Shooting Angles

The tripod head offers flexible adjustments:

- **Tilt Adjustment:** Use the 180° tilt joint to adjust the vertical angle of your smartphone.
- **Rotation:** The 360° rotating magnetic ring allows for quick switching between portrait and landscape orientations without re-mounting your phone.

Flexible Angles

180° rotation and 225° tilt for variable shooting angles.



Vertical Shooting



Horizontal Shooting

Image 3.2: Demonstrating the flexible angle adjustments of the PA985.

3.3 Using the Wireless Remote

Once paired, open your smartphone's camera app. Press the button on the detachable remote to trigger the shutter for photos or to start/stop video recording. The remote can be stored at the top of the selfie stick when not in use to prevent loss.

Your browser does not support the video tag.

Video 3.3.1: A demonstration of the NEEWER BASICS PA985 Magnetic Selfie Stick Tripod in use, showcasing its features and versatility.

Your browser does not support the video tag.

Video 3.3.2: A short clip highlighting the magnetic attachment and quick setup of the PA985 tripod.

4. MAINTENANCE

- **Cleaning:** Wipe the tripod and remote with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Remote Battery:** Recharge the remote control regularly using the provided Type-C charging cable to ensure optimal performance.
- **Avoid Overloading:** Do not exceed the maximum weight limit of 7 ounces (198 grams) to prevent damage.

5. TROUBLESHOOTING

- **Remote Not Pairing:**
 - Ensure the remote is charged and powered on.
 - Verify Bluetooth is enabled on your smartphone and the remote is within the 33ft (10m) range.
 - Try unpairing and re-pairing the remote in your phone's Bluetooth settings.
- **Phone Not Attaching Securely:**

- For MagSafe, ensure the phone or case is properly aligned with the magnetic holder.
 - For non-MagSafe, ensure the magnetic ring is correctly applied to the phone/case, or that the phone is firmly secured within the phone clip holder.
- **Tripod Instability:**
 - Ensure the tripod legs are fully extended and locked into position.
 - Place the tripod on a flat, stable surface.
 - Do not exceed the recommended weight limit for your device.

6. SPECIFICATIONS

Image 6.1: Detailed specifications of the PA985.

Feature	Detail
Model	PA985
Material	Nylon Alloy, Aluminum Alloy, Silicone
Telescopic Length Range	8.7" / 22cm - 16.3" / 41.5cm
Compatibility	iOS/Android/Harmony OS (MagSafe compatible, includes adapter for non-MagSafe)
Weight	6.8 oz / 194 g
Folded Size	4.6" (11.65 cm)
Wireless Remote Distance	≤ 33 ft / 10 m
Battery Voltage (Remote)	4.2V
Item Model Number	10106987
Product Dimensions	11.65 x 11.65 x 11.65 cm (folded)
Weight Limit	7 Ounces / 198 Grams

7. WARRANTY AND SUPPORT

NEEWER products are designed for reliability and performance. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your package or visit the official NEEWER website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or any inquiries regarding your NEEWER BASICS PA985 Magnetic Selfie Stick Tripod, please contact NEEWER customer service through their official website or the contact information provided in your product packaging.

Online Resources:

- Official NEEWER Website: www.neewer.com

- Amazon Store: [Visit the NEEWER Store on Amazon](#)

© 2025 NEEWER. All rights reserved.