

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### Manuals.plus /

- > [pexar](#) /
- > Pexar Starlight 15.6-inch Digital Picture Frame User Manual (Model PX-156SSLGL)

## pexar PX-156SSLGL

# Pexar Starlight 15.6-inch Digital Picture Frame User Manual

Model: PX-156SSLGL

## 1. INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your Pexar Starlight 15.6-inch Digital Picture Frame. Please read this guide thoroughly to ensure optimal performance and longevity of your device. This digital picture frame is designed to display your cherished photos and videos with a vibrant, anti-glare touchscreen and convenient sharing features.

## 2. WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- Pexar Starlight 15.6-inch Digital Picture Frame
- Frame Stand
- Power Adapter with Interchangeable Plugs
- Wall-Mount Kit
- Quick Start Guide

**Private, Secure, Hold 80,000 Photos**

Local Storage  
**64GB**  
Hold 80,000 Photos

Expand Storage\*  
SD card USB Drive

100% Privacy Protection  
GDPR Compliant CCPA Compliant PSTI Compliant

Figure 2.1: Included components in the Pexar Starlight 15.6-inch Digital Picture Frame package.

## 3. PRODUCT OVERVIEW

Familiarize yourself with the main parts of your digital picture frame:




Figure 3.1: Front and rear view of the Pexar Starlight Digital Picture Frame with labeled components.

- **Touch Screen:** 15.6-inch 1920x1080 resolution display with anti-glare coating.
- **Power Port:** Connects to the power adapter (no built-in battery).
- **SD Card Slot:** For expanding storage or direct media import.
- **USB Port:** For expanding storage or direct media import (USB-A for flash drives, USB-C for data cable).
- **Built-in Speaker:** For audio playback with videos.
- **Metal Stand:** Supports both portrait and landscape orientation.
- **Wall Mount:** Integrated mounting points for wall installation.

## 4. SETUP

### 4.1 Power Connection

1. Select the appropriate interchangeable plug for your region and attach it to the power adapter.
2. Connect the power adapter cable to the Power Port on the back of the frame.
3. Plug the power adapter into a wall outlet. The frame will automatically power on.

Your browser does not support the video tag.

Video 4.1: Demonstrates how to connect the power adapter and set up the frame for initial use.

### 4.2 Stand Installation

- For tabletop display, attach the metal stand to the magnetic points on the back of the frame.
- The stand allows for both horizontal (landscape) and vertical (portrait) orientations.

### 4.3 Wall Mounting

- Use the provided Wall-Mount Kit to securely attach the frame to a wall.
- Ensure the mounting surface is suitable to support the frame's weight.

### 4.4 Initial Configuration

1. Upon first power-on, follow the on-screen prompts to select your language, time zone, and connect to a Wi-Fi network.
2. The frame requires a Wi-Fi connection for app-based photo/video transfers and features like weather updates.

## 5. OPERATING THE FRAME

### 5.1 Downloading the Frameo App

- Download the 'Frameo' app from your device's app store (compatible with Apple iOS 14+ and Android 6.0+).
- Create an account and follow the in-app instructions to connect your smartphone or tablet to your Pexar Starlight frame.

### 5.2 Adding Photos and Videos

You can add media to your frame using several methods:

- **Via Frameo App:** Select photos or videos from your phone's gallery within the app and send them directly to the frame. You can add captions and select specific frames if you have multiple.
- **Via SD Card:** Insert an SD card into the designated slot on the frame. Navigate to the 'Manage Photos' section in the frame's settings to import media.
- **Via USB Drive:** Connect a USB flash drive to the USB port on the frame. Use the 'Manage Photos' section to import media.




Figure 5.1: Sharing photos and videos to the frame using the Frameo app.

### 5.3 Managing Photos and Videos

- **Albums:** Organize your media into custom albums for themed slideshows.
- **Captions & Reactions:** Add text captions to photos/videos and react to received media directly on the touchscreen.
- **Orientation:** The frame supports dual orientation. Photos and videos will automatically adjust to portrait or landscape mode based on how the frame is positioned.



Figure 5.2: Organizing and playing albums on the frame.

## 5.4 Sharing with Friends and Family

- You can invite friends and family to share photos and videos to your frame via the Frameo app.
- Generate a unique code from your frame's settings and share it with trusted individuals. They can then send media directly to your frame from their own devices.

## 6. KEY FEATURES

---

- **Gallery Lighting:** Built-in backlighting adds warmth and dimension to your displayed photos.
- **Anti-Glare Touchscreen:** A 15.6-inch 1920x1080 resolution display with an anti-glare coating reduces reflections for clear viewing from any angle.
- **64GB Local Storage:** Stores over 80,000 600KB photos directly on the device.
- **Expandable Storage:** Supports SD cards and USB flash drives for additional storage capacity.
- **Dual Orientation:** Automatically adjusts content display for both portrait and landscape frame positioning.
- **Smart Features:** Includes weather updates, a clock, and a customizable sleep mode.
- **Greeting Card Function:** Convert photos into digital greeting cards for special occasions.
- **Privacy Compliant:** GDPR, CCPA, and PSTI compliant for secure data handling.

## 7. MAINTENANCE

---

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the screen and frame. Avoid abrasive cleaners or solvents.
- **Placement:** Place the frame on a stable surface or mount it securely. Avoid direct sunlight or extreme temperatures.
- **Software Updates:** Ensure your frame's software is up-to-date for the best performance and latest features. Updates are typically managed through the Frameo app or frame settings.

## 8. TROUBLESHOOTING

---

- **Frame not powering on:** Ensure the power adapter is securely connected to both the frame and a working wall outlet.
- **Cannot connect to Wi-Fi:** Verify your Wi-Fi network name and password. Ensure the frame is within range of your router.
- **Photos/Videos not appearing:** Check if the media was successfully uploaded via the app, SD card, or USB. Ensure the file formats are supported.
- **Screen unresponsive:** Try restarting the frame by unplugging and re-plugging the power adapter.

## 9. SPECIFICATIONS

---

Feature	Specification
Model Number	PX-156SSLGL
Screen Size	15.6 Inches
Resolution	1920 x 1080
Internal Storage	64GB
Compatible Devices	Apple (iOS 14+), Android (6.0+)
Connectivity	Wi-Fi, SD Card, USB
Product Dimensions	7.09 x 10.24 x 0.99 inches
Item Weight	5.19 pounds

## 10. WARRANTY AND SUPPORT

---

For warranty information and technical support, please refer to the contact details provided in your Quick Start Guide or visit the official Pexar website. Keep your purchase receipt for warranty claims.