VELATEMOR VELATEMORtsfg3mda69-12

VELATEMOR Wireless USB 2.0 Network Print Server User Manual

Model: VELATEMORtsfg3mda69-12

1. Product Overview

The VELATEMOR Wireless USB 2.0 Network Print Server is a compact device designed to enable multiple users to share a single USB printer over a network. It supports both wired LAN and wireless network printing, making your USB printer accessible from various devices and operating systems.

Key Features:

- Supports efficient image and text printing.
- Equipped with a Type-C power port, USB printer connection port, and a network cable interface.
- Enables wireless network printing for multiple users.
- Compatible with over 95% of USB printer brands on the market.
- Supports various operating systems including Linux 3.4, Android, and iOS.
- Features a simple and compact design for space-saving and portability.

2. Package Contents

Please verify that all items are present in your package:

- 1 x USB 2.0 Network Print Server
- 1 x Data Cable
- 1 x User Manual (This document)
- 1 x Power Supply



Image: Package contents including the print server, power adapter, and data cable.

3. Setup Instructions

Follow these steps to set up your VELATEMOR Wireless USB 2.0 Network Print Server:

1. **Connect Power:** Plug the provided power supply into the Type-C power port on the print server and then into a power outlet.
2. **Connect USB Printer:** Connect your USB printer to the USB port on the print server using a USB cable.
3. **Connect Network:** Connect the print server to your network router or switch using an Ethernet cable. For wireless functionality, ensure the device is powered on and within range of your Wi-Fi network.
4. **Driver Installation:** Install the necessary printer drivers on your computer or mobile device. The print server acts as an intermediary, so your device still needs the printer's specific drivers.






Image: Connection diagram for the print server, illustrating power, printer, and network connections, and how it enables mobile and computer printing.




Image: Working principle diagram, showing how the print server connects a USB printer to a network for access by multiple smart devices.



Image: Detailed view of the print server's interfaces: Type-C power, USB printer port, and Ethernet port.

4. Operating Instructions

Once the print server is set up and connected to your network, you can begin printing from your devices.

4.1. Printing from Computers

- Ensure your computer is connected to the same network as the print server.
- Add the network printer through your operating system's printer settings. Refer to your operating system's documentation for specific steps on adding a network printer.
- Select the newly added network printer from your application's print dialog to send print jobs.

4.2. Printing from Mobile Devices (Android/iOS)

- Ensure your mobile device is connected to the same Wi-Fi network as the print server.
- Depending on your printer model, you may need to install a specific printer app or use your device's built-in printing features (e.g., Android Print Service, Apple AirPrint).
- From your mobile application, select the print option and choose the network printer.



Image: Remote mobile device control printing, showing how smartphones and laptops can send print jobs to the shared printer via the print server.

5. Maintenance

To ensure the longevity and optimal performance of your print server, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or aerosols.
- **Environment:** Keep the print server in a cool, dry place, away from direct sunlight, excessive heat, and moisture.
- **Ventilation:** Ensure the ventilation openings are not blocked to prevent overheating.
- **Power Off:** If the device will not be used for an extended period, disconnect it from the power source.

6. Troubleshooting

If you encounter issues with your print server, refer to the following common troubleshooting steps:

6.1. Printer Not Detected

- **Check Connections:** Ensure the print server is properly connected to power, the USB printer, and the network.
- **Restart Devices:** Power cycle the print server, your printer, and your network router.
- **Printer Compatibility:** Verify that your USB printer is compatible with network print servers. While this device supports most, some specialized printers may have limitations.
- **Driver Installation:** Confirm that the correct printer drivers are installed on the client device (computer/mobile).

6.2. Cannot Print

- **Network Connectivity:** Ensure your client device and the print server are on the same network and have a stable connection.
- **Printer Status:** Check if the printer itself is powered on, has paper, and ink/toner, and is not showing any error messages.
- **Print Queue:** Clear any pending print jobs from your device's print queue.

6.3. Slow Printing

- **Network Congestion:** High network traffic can affect printing speed. Try printing during off-peak hours or check your network's performance.
- **Printer Settings:** Review your printer's settings for print quality (lower quality often prints faster).

7. Specifications

Feature	Detail
Brand	VELATEMOR
Model	VELATEMORtsfg3mda69-12
Type	Wireless USB 2.0 Network Print Server
Material	ABS

Interfaces	1 x Type-C Power Port, 1 x USB 2.0 Printer Port, 1 x Ethernet (LAN) Port
Max Memory Card Support	256GB (not included)
Supported OS	Android, iOS, Linux 3.4 and above
Dimensions (Package)	9 x 9 x 7 cm
Weight (Product)	154 g

8. Warranty Information

This VELATEMOR product comes with a standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your package or contact the seller directly. Keep your proof of purchase for warranty claims.

9. Customer Support

If you require further assistance or have questions not covered in this manual, please contact your retailer or the manufacturer's customer support. Please have your product model number (VELATEMORtsfg3mda69-12) and purchase details ready when contacting support.

© 2025 VELATEMOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question