



Manuals.plus /

› AILINKE /

› AILINKE KC-MH-2109 Humidifier User Manual

## AILINKE KC-MH-2109

# AILINKE KC-MH-2109 Humidifier User Manual

Model: KC-MH-2109

---

## 1. INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your AILINKE KC-MH-2109 Humidifier. Please read all instructions carefully before use and retain this manual for future reference.

## 2. PRODUCT OVERVIEW

---

The AILINKE KC-MH-2109 is a versatile humidifier designed for large rooms, offering both warm and cool mist options. Key features include a large water tank, smart humidity control, and a unique flame light design.



Image: AILINKE KC-MH-2109 Humidifier displaying its control panel and simulated flame mist effect.

## Key Features:

- **Ultrasonic Warm and Cool Mist:** Utilizes innovative thermal mist technology for year-round comfort.
- **10L (2.64 Gallon) Water Tank:** Large capacity for extended operation, covering up to 1000 sq.ft.
- **Flame Light Design:** Creates a warm and ambient atmosphere.
- **Smart Humidity Control:** Adjustable humidity levels (45-95%) with automatic misting adjustment.
- **12-Hour Timer:** Program continuous misting for up to 12 hours.
- **Quiet Operation:** Operates below 30 decibels for minimal disturbance.
- **Top Fill Design:** Convenient water refilling.

- **Remote Control:** Adjust settings from a distance.
- **Water Shortage Protection:** Automatic shut-off when water level is low.

### 3. SETUP

---

Before initial use, ensure all packaging materials are removed. Place the humidifier on a flat, stable surface.

#### Water Filling:

1. Lift the top cover of the humidifier.
2. Pour clean water directly into the water tank. Do not exceed the 'MAX' fill line.
3. Replace the top cover securely.



Image: Illustration of the humidifier's top-fill design, touch panel, remote control, built-in handles, easy cleaning, and water shortage protection features.

### 4. OPERATING INSTRUCTIONS

---

Plug the humidifier into a power outlet. The display will illuminate.

#### Power On/Off:

- Press the Power button on the control panel or remote to turn the unit on or off.

#### Mist Level Adjustment:

The humidifier offers three adjustable mist levels (Low, Medium, High).

- Press the Mist button repeatedly to cycle through the mist output levels.




Image: Visual representation of low, medium, and high mist output levels, indicating mist elevation up to 40 inches and width up to 5.31 inches.

## Warm/Cool Mist Selection:

Choose between warm or cool mist based on your preference and environmental needs.

- Press the Warm Mist button to activate or deactivate the warm mist function.




Image: Diagram showing the internal mechanism for producing both cool and warm mist, with blue mist representing cool and orange mist representing warm.

## Smart Humidity Control:

Set your desired humidity level, and the humidifier will automatically maintain it.

- Press the Humidity button to set the target humidity between 45% and 95%. The unit will pause misting once the target is reached and resume if humidity drops.



Image: Humidifier demonstrating smart humidity control, allowing users to set desired humidity levels (45-95%) for different needs like instruments, plants, babies, or pets.

### Timer Function:

Set a timer for automatic shut-off.

- Press the Timer button to select an operating duration from 1 to 12 hours.

### Flame Light:

Activate the simulated flame light for ambiance.

- Press the Color Light button to turn the flame light on or off.

Video: A short demonstration of the humidifier's simulated flame effect, showcasing its visual appeal.

### Remote Control:

All functions can be controlled using the included remote control.

## 5. MAINTENANCE

Regular cleaning is essential to prevent mold and mineral buildup, ensuring optimal performance and longevity of your humidifier.

### Cleaning the Water Tank and Base:

1. Unplug the humidifier from the power outlet.
2. Remove the top cover and any internal components that can be easily detached.
3. Empty any remaining water from the tank and base.
4. Use a soft cloth or the provided cleaning brush to gently wipe down the interior surfaces of the water tank and base. For stubborn mineral deposits, a solution of white vinegar and water can be used.
5. Rinse all components thoroughly with clean water. Ensure no cleaning solution residue remains.
6. Allow all parts to air dry completely before reassembling.

Video: A demonstration of cleaning a humidifier (model LCD-MH-J18), showing how to disassemble, clean with citric acid/vinegar, and reassemble. Note: While the model number differs, the general cleaning principles may apply.

## 6. TROUBLESHOOTING

---

- **No Mist Output:** Check if the water tank is empty. Ensure the unit is properly assembled and plugged in. Clean the atomizer if it appears dirty.
- **Unusual Odor:** Clean the water tank and replace the water. Use distilled water if tap water quality is poor.
- **Excessive Noise:** Ensure the unit is on a flat, stable surface. Check for any foreign objects in the water tank or mist outlet.
- **Water Leakage:** Ensure the top cover is securely closed and the water tank is not overfilled.

## 7. SPECIFICATIONS

---

Attribute	Value
Model Number	KC-MH-2109
Brand	AILINKE
Water Tank Capacity	10 Liters (2.64 Gallons)
Coverage Area	Up to 1000 sq.ft
Mist Output Levels	3 (Low, Medium, High)
Noise Level	Below 30dB
Timer	1-12 Hours
Product Dimensions	7.09 x 11.81 x 15.04 inches
Item Weight	7.33 pounds (3.33 Kilograms)
Material	Plastic
Color	White

## 8. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the product packaging or contact AILINKE customer service directly. Keep your purchase receipt as proof of purchase.