Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC-DC Adapter for ZDZA ZD06

Onerbl AC-DC Power Adapter for ZDZA ZD06 36V 7.8Ah Battery Instruction Manual

Model: AC-DC Adapter for ZDZA ZD06 36V 7.8Ah Battery DC42V

1. Introduction

This manual provides essential information for the safe and efficient use of your Onerbl AC-DC Power Adapter. This adapter is designed to convert AC power from a wall outlet into DC power, specifically for charging or powering compatible devices such as the ZDZA ZD06 36V 7.8Ah Battery, requiring a DC42V input. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Use only with compatible devices as specified. Incorrect voltage or current can damage your device.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not disassemble or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure proper ventilation around the adapter during use to prevent overheating.
- Unplug the adapter from the power outlet when not in use for extended periods.
- This adapter features **Over Voltage Protection** and **Over Heat Protection** to safeguard your devices.

3. Package Contents

Verify that all items are present in your package:

- Onerbl AC-DC Power Adapter Unit
- AC Power Cord




Image: Detached AC power cord for the Onerbl AC-DC adapter. This image shows the detachable AC power cord, which connects the adapter to a wall outlet. It features a standard two-prong plug on one end and a C7 connector on the other, designed to fit into the adapter unit.

4. Specifications

Brand	Onerbl
Input Voltage	AC 100-240V, 50/61Hz (Worldwide Auto Input)
Output Voltage	DC 42V (for ZDZA ZD06 36V 7.8Ah Battery)
Connector Type	Barrel Connector
Compatible Devices	ZDZA ZD06 36V 7.8Ah Battery DC42V
Special Features	Over Voltage Protection, Over Heat Protection, Short Circuit Protection
Color	Black
Power Source	Corded Electric
Manufacturer	Shenzhen Waweis Technology Co., Ltd



Image: Diagram showing the dimensions of the Onerbl AC-DC power adapter and its cables. This diagram illustrates the physical dimensions of the Onerbl AC-DC power adapter. The total cable length is 127.8 inches. The adapter unit measures 4.2 inches in length. The DC output cable is 44.3 inches long, and the AC input cable is 79.3 inches long. The DC connector tip is 1.8 inches long, with a barrel diameter of 1.2 inches.

5. Setup

Follow these steps to set up your Onerbl AC-DC Power Adapter:

1. **Connect the AC Power Cord:** Insert the C7 connector end of the AC power cord firmly into the AC input port on the Onerbl adapter unit.
2. **Connect to Power Outlet:** Plug the two-prong end of the AC power cord into a standard wall electrical outlet (AC 100-240V).
3. **Connect to Device:** Insert the barrel connector of the adapter's output cable into the charging port of your compatible device (e.g., ZDZA ZD06 36V 7.8Ah Battery). Ensure the connection is secure.



Image: Onerbl AC-DC power adapter connected to a wall outlet and a device. This image demonstrates the Onerbl AC-DC power adapter in use, connected to a standard wall outlet. The adapter unit rests on a surface, with its blue indicator light illuminated, signifying active power supply. The output cable extends to power a compatible device (not fully visible).

6. Operating Instructions

Once properly connected, the adapter will begin to supply power or charge your device. Observe the indicator light on the adapter unit:

- A **blue indicator light** typically signifies that the adapter is receiving power and is actively supplying output to the connected device.
- Refer to your device's manual for specific charging indicators or power status.

Always disconnect the adapter from the device and the wall outlet when charging is complete or when the device is not in use.

7. Maintenance

Proper maintenance ensures the longevity and optimal performance of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture. Avoid tightly winding the cables to prevent damage.
- **Inspection:** Periodically inspect the cables and connectors for any signs of wear, fraying, or damage. If any damage is observed, discontinue use and replace the adapter.

8. Troubleshooting

If you encounter issues with your Onerbl AC-DC Power Adapter, try the following steps:

- **No Power/No Indicator Light:**
  - Ensure the AC power cord is securely connected to both the adapter and the wall outlet.
  - Verify that the wall outlet is functional by testing it with another device.
  - Check for any visible damage to the adapter or cables.
- **Device Not Charging/Powering On:**
  - Confirm that the adapter's barrel connector is fully inserted into your device's charging port.
  - Ensure your device is compatible with a DC42V input.
  - If your device has a removable battery, ensure it is properly seated.
  - Try disconnecting and reconnecting all cables.
- **Adapter Overheating:**
  - Ensure the adapter is placed in a well-ventilated area and not covered.
  - If overheating persists, discontinue use immediately and contact support.

If these steps do not resolve the issue, please contact customer support.

9. Warranty and Support

For warranty information or technical assistance, please contact the manufacturer, Shenzhen Waweis Technology Co., Ltd, or your retailer. Keep your purchase receipt as proof of purchase.
Manufacturer: Shenzhen Waweis Technology Co., Ltd
Brand: Onerbl

© 2025 Onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FP55GL3M

More documents and user manuals: **https://manuals.plus/**