onerbl USB Charging Cable for Lxlu RX05 RX05-A

Onerbl USB Charging Cable for Lxlu RX05 RX05-A Electric Spin Scrubber

Instruction Manual

Introduction

This manual provides essential information for the safe and effective use of your Onerbl USB Charging Cable, designed specifically for the Lxlu RX05 and RX05-A Electric Spin Scrubber Cordless Cleaning Brush with a 3000mAh battery. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

To ensure safe operation and prevent damage, observe the following precautions:

- Do not expose the cable to water or excessive moisture.
- Avoid extreme temperatures.
- Do not attempt to modify or repair the cable.
- Keep out of reach of children.
- Ensure the cable is fully inserted into compatible ports.
- Disconnect the cable by pulling the plug, not the cord.
- Discontinue use if the cable appears damaged.

Setup

Setting up your Onerbl USB charging cable is straightforward:

1. **Identify the Charging Port:** Locate the USB charging port on your Lxlu RX05 or RX05-A Electric Spin Scrubber.
2. **Connect to Scrubber:** Insert the smaller end of the Onerbl USB charging cable into the charging

port of the spin scrubber. Ensure a snug fit.

3. **Connect to Power Source:** Insert the standard USB-A end of the cable into a compatible USB power adapter (not included) or a powered USB port on a computer or wall outlet.
4. **Verify Connection:** Confirm that the charging indicator on your Lxlu spin scrubber (if available) illuminates, indicating that charging has begun.



Image: The Onerbl USB Charging Cable, showing its USB-A connector and the smaller device-specific connector. This image illustrates the cable's design for connecting to a power source and the Lxlu spin scrubber.

Operating

Once connected, the cable facilitates the charging of your Lxlu RX05/RX05-A Electric Spin Scrubber's 3000mAh battery.

- The cable is designed to provide the correct power specifications for your device.
- Charging times may vary depending on the battery's current charge level and the output of your USB power source.
- It is recommended to charge the device fully before its first use and whenever the battery level is low.
- The cable includes short circuit protection for safe charging.

Maintenance

Proper care will extend the life of your charging cable:

- **Cleaning:** Wipe the cable with a dry, soft cloth. Do not use liquid cleaners.
- **Storage:** Store the cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply.
- **Inspection:** Periodically inspect the cable and connectors for any signs of wear, fraying, or damage.

Troubleshooting

Problem	Possible Cause	Solution
Device not charging.	Cable not properly connected.	Ensure both ends of the cable are securely plugged in.
Device not charging.	Faulty power source.	Try a different USB power adapter or USB port.
Device not charging.	Damaged cable.	Inspect the cable for visible damage. If damaged, replace it.
Slow charging.	Low power output from USB source.	Use a USB power adapter with higher amperage (e.g., 5V/2A).

Specifications

Brand: Onerbl

Connector Type: USB Connector

Compatible Devices: Lxlu RX05, Lxlu RX05-A Electric Spin Scrubber Cordless Cleaning Brush (3000mAh Battery)

Special Feature: Short Circuit Protection

Color: Black

Manufacturer: Shenzhen Waweis Technology Co., Ltd

Warranty and Support

This Onerbl product is manufactured to high-quality standards. For any issues or support inquiries, please refer to the retailer's return policy or contact the manufacturer directly. Please retain your proof of purchase for warranty claims.

© 2024 Onerbl. All rights reserved.