

[Manuals.plus](#) /

› [APD APETDOLA](#) /

› APD APETDOLA FDV40 Automatic Pet Feeder User Manual

APD APETDOLA FDV40

APD APETDOLA FDV40 Automatic Pet Feeder User Manual

Model: FDV40 | Brand: APD APETDOLA

1. INTRODUCTION

Thank you for choosing the APD APETDOLA FDV40 Automatic Pet Feeder. This device is designed to provide reliable and scheduled feeding for your beloved cats and small to medium-sized dogs, ensuring they receive their meals consistently. With programmable meal times and portion control, you can customize a diet plan tailored to your pet's needs. The integrated video camera allows for remote monitoring and interaction, enhancing your pet care experience.

2. SAFETY INSTRUCTIONS

- Read all instructions carefully before use.
- Keep the feeder away from children and pets when not in use or during assembly.
- Use only dry pet food with this feeder. Do not use wet food, canned food, or treats.
- Ensure the power adapter and cable are not damaged. Do not use if damaged.
- Place the feeder on a stable, level surface to prevent tipping.
- Do not immerse the main unit in water or any other liquid.
- This product is intended for indoor use only.
- Unplug the feeder before cleaning or if it will not be used for an extended period.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Automatic Pet Feeder Main Unit
- Food Bowl (Stainless Steel)
- Power Adapter

- USB Cable
- User Manual

El paquete incluye



Figure 3.1: Package Contents. The image displays the automatic pet feeder, its stainless steel food bowl, power adapter, USB cable, and the instruction manual, all neatly arranged next to the product box.

4. PRODUCT OVERVIEW

The APD APETDOLA FDV40 features a large 5-liter capacity food hopper, suitable for extended feeding periods for both cats and dogs. The transparent hopper allows for easy monitoring of food levels. The unit includes a control panel for basic operations and an integrated camera for remote monitoring.

Gran capacidad de 5L, satisface
fácilmente las necesidades alimentarias de su
mascota.



Figure 4.1: Product Overview and Capacity. This image demonstrates the 5-liter capacity of the feeder, showing it can hold enough food for approximately 10 days for a dog or 30 days for a cat, catering to the needs of various pets.

5. SETUP

5.1 Power Supply

1. Connect the USB cable to the feeder's power input port.
2. Plug the power adapter into a standard wall outlet.
3. The feeder will power on, indicated by an LED light.

5.2 Food Loading

1. Open the lid of the food hopper.
2. Pour dry pet food into the hopper. Ensure the food size is appropriate for the dispenser mechanism (typically 5-15mm diameter).
3. Close the lid securely to maintain food freshness.

5.3 App Installation and Wi-Fi Connection

To unlock the full features of your feeder, download the dedicated mobile application.

1. Scan the QR code on the packaging or manual, or search for the 'APD APETDOLA' app in your device's app store.
2. Install and open the app, then register an account.
3. Follow the in-app instructions to add your device. Ensure your phone is connected to a 2.4 GHz Wi-Fi network (5 GHz is also supported for this model).
4. The app will guide you through connecting the feeder to your home Wi-Fi network.

Fácil de usar con la aplicación

Personaliza el plan de alimentación

Alimentación extra con un clic



Soporte
2,4 GHz y 5 GHz



Figure 5.1: App Interface for Easy Setup and Customization. The image illustrates the user-friendly mobile application, allowing for personalized feeding plans and additional feeding with a single click. It also highlights support for both 2.4 GHz and 5 GHz Wi-Fi networks.

6. OPERATING INSTRUCTIONS

6.1 Setting Feeding Schedule

Use the mobile app to program your pet's feeding schedule:

- Open the app and select your feeder.
- Navigate to the 'Schedule' or 'Feeding Plan' section.
- You can set 1 to 6 meals per day. For each meal, specify the time and the number of portions (0 to 20 portions).
- Save your settings. The feeder will automatically dispense food at the programmed times.

6.2 Manual Feeding

To dispense food instantly:

- **Via App:** On the app's main screen, locate the 'Feed Now' or 'Extra Feed' button to dispense a single portion.
- **Via Feeder Button:** Press the manual feed button on the feeder's control panel (refer to product diagram for location) to dispense one portion.

6.3 Two-Way Audio Communication

The feeder allows you to interact with your pet remotely:

- **Voice Recording:** Record a short voice message (e.g., "Time to eat!") through the app. This message will play automatically when food is dispensed.
- **Live Talk:** Use the 'Talk' function in the app to speak to your pet in real-time through the feeder's speaker.

Primero llama, luego alimenta **Fortalece el vínculo** *Mediante un sistema de audio bidireccional*



Figure 6.1: Two-Way Audio Interaction. This image illustrates how the two-way audio system allows you to call your pet first, then feed them, strengthening the bond. A message bubble shows "Darling! Time to eat!" in Spanish.

6.4 Video Monitoring

Monitor your pet and their feeding habits:

- **Live View:** Access the live video feed from the feeder's camera through the app at any time.
- **Night Vision:** The camera is equipped with night vision, allowing clear monitoring even in low-light conditions or complete darkness.

***Ver con claridad incluso de noche.
¿Qué hacen las mascotas por la noche?***



Figure 6.2: Clear Night Vision Monitoring. This image demonstrates the feeder's ability to provide a clear view of your pet even at night, allowing you to see what your pets are doing in the dark.

***En cualquier momento y lugar
Una vista clara de tu mascota***



Figure 6.3: Anytime, Anywhere Pet Monitoring. This image highlights the ability to have a clear view of your pet at any time and from any location, ensuring you can always check on them.

7. MAINTENANCE

7.1 Cleaning the Feeder

Regular cleaning ensures hygiene and extends the life of your feeder.

1. Unplug the feeder from the power outlet.
2. Remove any remaining food from the hopper.
3. Detach the food bowl and the food hopper from the main unit.
4. Wash the food bowl and hopper with mild soap and water. Rinse thoroughly and dry completely before reassembling.
5. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
6. Ensure all parts are completely dry before reassembling and plugging the feeder back in.

Fácil de limpiar

Mantiene el ambiente de alimentación limpio



Figure 7.1: Easy Cleaning. This image illustrates how easy it is to clean the feeder, helping to maintain a clean feeding environment for your pet.

8. TROUBLESHOOTING

- **Feeder not dispensing food:** Check if the food hopper is empty. Ensure the food is not jammed. Verify power connection.
- **App not connecting to feeder:** Ensure your Wi-Fi network is 2.4 GHz or 5 GHz. Restart your router and the feeder. Re-attempt the pairing process in the app.
- **Food portions are incorrect:** Adjust the portion settings in the app. Ensure the food size is compatible with the feeder.
- **Video feed is unclear or unavailable:** Check your Wi-Fi signal strength. Ensure the camera lens is clean.
- **Feeder offline:** This device relies on a stable Wi-Fi connection. If the connection drops, the device may not function correctly until reconnected.

9. SPECIFICATIONS

Feature	Specification
Model Number	FDV40
Dimensions (L x W x H)	18 x 24 x 24 cm (7.1 x 9.4 x 9.4 inches)
Weight	1.37 kg (3.02 lbs)
Material	Plastic
Capacity	5 Liters
Target Species	Cats, Small to Medium Dogs
Operating Mode	Automatic
Recommended Use	Indoor Use
Connectivity	Wi-Fi (2.4 GHz & 5 GHz supported)



Figure 9.1: Product Dimensions. This image provides a visual representation of the feeder's dimensions, with measurements clearly indicated.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official APD APETDOLA website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2026 APD APETDOLA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question