ULTIMEA U422A

ULTIMEA Skywave X50 U422A 5.1.4ch Dolby Atmos Sound Bar System User Manual

Your guide to setting up, operating, and maintaining your ULTIMEA Skywave X50 U422A Sound Bar System.

1. Setup Guide

1.1 Unpacking and Components

Carefully unpack all components and ensure the following items are present:

- 1 x Soundbar
- 1 x 10″ Subwoofer
- 2 x Surround Speakers
- 1 x Soundbar Power Adaptor
- 1 x Subwoofer Power Cord
- 2 x Surround Power Adaptor
- 1 x HDMI Cable
- 1 x Digital Optical Cable
- 1 x Remote Control (Battery not included)
- 1 x User Manual (This document)
- 1 x Wall Mounting Guide
- 12 x Bracket Screw
- 6 x Bracket
- 6 x Wall Anchors



Image: All components of the ULTIMEA Skywave X50 U422A Sound Bar System, including the soundbar, subwoofer, and two surround speakers.

1.2 Placement

Optimal placement of your soundbar, subwoofer, and surround speakers is crucial for an immersive audio experience.

- **Soundbar:** Place the soundbar centrally below your television. Ensure no objects obstruct the front or top-firing speakers.
- **Subwoofer:** Position the wireless subwoofer on the floor, ideally in the front corner of the room or near the soundbar for optimal bass response. Experiment with placement to find the best sound for your room.
- **Surround Speakers:** Place the two wireless surround speakers behind your primary listening position, to the left and right. Ensure they are at ear level or slightly above for the best surround effect.



Image: A diagram illustrating the recommended placement for the soundbar, subwoofer, and two surround speakers in a 5.1.4 channel Dolby Atmos setup, with sound waves indicating immersive audio.




Image: A modern living room setup demonstrating the placement of the soundbar below a TV, the subwoofer to the side, and the two surround speakers positioned behind the seating area.

1.3 Connections

Connect your soundbar to your television and other devices using the appropriate cables.

1. **HDMI eARC (Recommended):** Connect the HDMI eARC port on the soundbar to the HDMI eARC/ARC port on your TV using the provided HDMI cable. This connection supports Dolby Atmos and allows TV remote control of the soundbar volume.
2. **Optical:** If your TV does not have an HDMI eARC/ARC port, connect the OPTICAL port on the soundbar to the Optical Digital Audio Out port on your TV using the provided optical cable.
3. **Other Devices:** Use the HDMI IN port for connecting external devices like gaming consoles or Blu-ray players to the soundbar, then connect the soundbar's HDMI eARC to your TV.
4. **Power:** Connect the power adaptors to the soundbar, subwoofer, and surround speakers, then plug them into power outlets.



Image: A detailed diagram showing the various input and output ports on the soundbar, including HDMI eARC, HDMI IN, Optical, USB, and DC IN, with icons for compatible devices.

1.4 Initial Power On and Pairing

After connecting all components and power, turn on the soundbar system. The subwoofer and surround speakers are pre-paired at the factory. They should automatically connect to the soundbar when powered on. A solid indicator light on each

component confirms a successful connection.

2. Operation

2.1 Remote Control Functions

The included remote control provides full command over your sound system.



Image: The ULTIMEA soundbar remote control, displaying buttons for power, volume, input selection, sound modes, and individual channel adjustments.

- **Power:** Turns the system on or off.
- **Input Selection:** Cycle through HDMI eARC, HDMI IN, Optical, Bluetooth, and USB inputs.
- **Volume Control:** Adjust the master volume.
- **Bass/Treble:** Adjust bass and treble levels.
- **Sound Modes:** Select from various preset sound modes (e.g., Movie, Music, Voice).
- **Channel Level Adjustment:** Independently adjust the volume of the subwoofer and surround speakers.

2.2 Input Selection

Press the 'Input' button on the remote control or the soundbar to switch between available audio sources: HDMI eARC, HDMI IN, Optical, Bluetooth, and USB.

2.3 Sound Modes and Adjustments

Utilize the remote control to select different sound modes tailored for various content types. For advanced customization, download the ULTIMEA app on your smartphone.



Image: Screenshots of the ULTIMEA mobile application interface, showing options for equalizer adjustments and custom sound profiles.

2.4 Bluetooth Pairing

To connect a Bluetooth device:

1. Press the Bluetooth button on the remote or soundbar to enter Bluetooth pairing mode. The soundbar display will show "BT".
2. On your device, search for "ULTIMEA Skywave X50" in the Bluetooth settings and select it to connect.
3. A confirmation tone will sound when pairing is successful.



Image: A person holding a smartphone displaying the ULTIMEA app, controlling the soundbar system via Bluetooth 5.4, with the soundbar visible in the background.

3. Maintenance

Proper maintenance ensures the longevity and performance of your sound system.

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofer, and speakers. Avoid using liquid cleaners or abrasive materials.
- **Ventilation:** Ensure adequate airflow around all components to prevent overheating. Do not block ventilation openings.
- **Storage:** If storing the system for an extended period, disconnect power and store in a cool, dry place away from

direct sunlight and extreme temperatures.

4. Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Check all power connections. Ensure outlets are functional.
No sound	Verify correct input selection. Check volume levels on both soundbar and TV. Ensure cables are securely connected.
Surround speakers not connecting	Ensure surround speakers are powered on. If issues persist, refer to the manual's pairing section for manual re-pairing instructions.
Poor sound quality	Check audio source quality. Adjust sound modes or EQ settings via remote or app. Ensure speaker placement is optimal.
Remote control not working	Replace batteries. Ensure no obstructions between remote and soundbar.

5. Technical Specifications

Detailed specifications for the ULTIMEA Skywave X50 U422A Sound Bar System.




Image: A technical diagram illustrating the dimensions (length, width, height) of the soundbar, subwoofer, and surround speakers in millimeters.

Feature	Specification
Model Name	Skywave X50
Model Number	U422A

Feature	Specification
Surround Sound Channel Configuration	5.1.4
Speaker Type	Surround Sound
Special Feature	Dolby Enabled
Connectivity Technology	HDMI eARC / Optical / Bluetooth / USB
Wireless Communication Technology	Bluetooth 5.4
Subwoofer Connectivity Technology	Wireless (Dual 5GHz)
Subwoofer Diameter	8 Inches
Speaker Maximum Output Power	760 Watts (Peak)
Frequency Response	28 Hz
Signal-to-Noise Ratio	100 dB
Product Dimensions (Soundbar)	43.31"D x 2.76"W x 3.94"H (1100mm x 70mm x 100mm)
Item Weight	22.05 Pounds
Control Method	App, Remote
Color	Black & Gold

6. Warranty and Support

6.1 Warranty Information

The ULTIMEA Skywave X50 U422A Sound Bar System comes with a**Limited Warranty**. Please refer to the warranty card included in your packaging for specific terms and conditions, including coverage duration and claim procedures.

6.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact ULTIMEA customer support. Contact details can typically be found on the official ULTIMEA website or on the product packaging.

© 2025 ULTIMEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question