

[Manuals.plus](#) /

› [iZEEKER](#) /

› iZEEKER iG440 2-in-1 4G Cloud and Standard Trail Camera User Manual

iZEEKER iG440

iZEEKER iG440 2-in-1 4G Cloud and Standard Trail Camera User Manual

Model: iG440 | Brand: iZEEKER

INTRODUCTION

The iZEEKER iG440 Trail Camera is a versatile 2-in-1 device designed for wildlife observation and property surveillance. It offers both standard local recording and advanced 4G cloud connectivity, capturing high-resolution 2K videos and 48MP photos. Equipped with infrared night vision and a rapid 0.2-second motion detection trigger, it ensures comprehensive coverage in various outdoor conditions, protected by an IP66 waterproof casing.

WHAT'S IN THE BOX

Contenu de l'emballage



Image: All components included in the iZEEKER iG440 trail camera package.

- iZEEKER iG440 Trail Camera
- Antenna
- USB Cable
- Mounting Strap
- Mounting Bracket
- Screws and Wall Plugs
- Tweezers (for SIM/SD card handling)
- User Manual

SETUP



Image: Step-by-step guide for inserting batteries, MicroSD, and SIM card, and using the power switch.

1. **Battery Installation:** Open the camera casing. Insert 8 AA batteries (not included) into the battery compartment, ensuring correct polarity.
2. **MicroSD Card Installation:** Insert a MicroSD card (up to 128GB, not included) into the designated slot. Ensure it is correctly oriented.
3. **SIM Card Installation (for 4G Cloud Mode):** If using 4G Cloud mode, insert a Nano-SIM card into the SIM card slot.
4. **Power On:** Switch the camera to "SETUP" mode to access the menu and configure settings. After configuration, switch to "ON" mode to begin surveillance.

OPERATING MODES

Mise à Niveau à Double Fonction

Mode Caméra 4G Cloud en Option



Image: The iG440 camera demonstrating its 4G LTE connectivity in an outdoor setting.

The iG440 offers two operational modes:

- **Standard Camera Mode:** Operates without a SIM card. Photos and videos are stored locally on the MicroSD card. Files can be accessed by removing the card, connecting the camera via USB to a computer, or viewing directly on the camera's 2-inch screen.
- **4G Cloud Camera Mode:** Requires a SIM card and MicroSD card. Connects to the "TrailCam Go" application via a stable 4G signal, allowing remote control, settings adjustment, and file viewing/transfer to the cloud. A data plan is required for this mode; new users may receive a promotional offer for the first month.



Plans Cloud flexibles

Choisissez le plan adapté à vos besoins – Basic, Advanced ou Unlimited

Basique	Avancé (Recommandé)	Illimité
300 fichiers Pas de vidéos HD	1000 fichiers 10 vidéos HD	Fichiers illimités 50 vidéos HD
4,99 €/mois Or 49,99 €/an	7,99 €/mois Or 79,99 €/an	11,99 €/mois Or 119,99 €/an

* Offre spéciale : Les nouveaux utilisateurs bénéficient du plan Advanced (1000 fichiers) pour seulement 0,01 € le premier mois (vérification coulante).



Remarque :
Les plans de stockage Cloud sont optionnels et facturés mensuellement. Le stockage local via carte micro SD est gratuit.
Plans d'application = Stockage Cloud + données 4G.
Si vous utilisez votre propre SIM, un plan cloud est toujours nécessaire pour la visualisation à distance.

Image: Overview of available cloud storage plans for 4G Cloud Camera Mode.

KEY FEATURES

- **2K HD Video & 48MP Photos:** Captures clear 2K resolution videos and detailed 48-megapixel still images, ensuring high-quality recordings day and night.

**Rapprochez la nature, de jour
comme de nuit**



Image: Comparison of day (color) and night (black and white) footage, highlighting 2K 48MP resolution.

- **Clear Night Vision:** Equipped with 850nm infrared LEDs, providing clear images up to 20 meters in complete darkness without disturbing wildlife.



Image: Example of clear night vision capture, showing a wolf in its natural habitat.

- **Rapid Motion Detection:** A highly sensitive PIR motion sensor with a 0.2-second trigger speed ensures no movement is missed.

Contrôle à distance via l'app

- ✓ Visualisez, lisez et téléchargez vos fichiers
- ✓ Ajustez les paramètres de la caméra
- ✓ Partagez vos moments sauvages



Image: A deer captured mid-run, illustrating the camera's fast 0.2-second trigger speed.

- **IP66 Waterproof Design:** The robust IP66-rated casing protects the camera from rain, dust, and extreme temperatures (-20°C to +60°C), making it suitable for all outdoor environments.



Image: The iG440 camera operating reliably in rainy conditions, showcasing its IP66 waterproof rating.

- **Loop Recording:** Supports MicroSD cards up to 128GB. When the card is full, the camera automatically overwrites the oldest files to continue recording.



Montage sur Arbre

Fixez solidement la caméra à un arbre pour une installation rapide en pleine nature.



Montage avec Support

Utilisez le support ou un trépied (non inclus) pour un positionnement stable et flexible.

Image: Visual representation of how loop recording manages storage by overwriting old files.

- **Advanced Functions:** Includes practical features such as a timer, time-lapse photography, and scheduled shooting for customized surveillance.

Personnalisez les Horaires de Fonctionnement

Fonctionne uniquement pendant les périodes que vous avez choisies



6:00



15:00



22:00



Time Lapse

Enregistre automatiquement les changements lents de l'environnement et l'activité à long terme de la faune.

Image: Illustration of customizable operating schedules and time-lapse capabilities.

APP CONTROL & REMOTE ACCESS

Manage your iZEEKER iG440 camera remotely using the "TrailCam Go" application.

Ne Manquez Aucun Mouvement




0.2s Déclenchement



Image: Remote viewing of wildlife footage via the smartphone app.

- **Remote Viewing & Download:** Access and download photos and videos from the cloud anytime, anywhere.
- **Settings Adjustment:** Modify camera settings directly from your smartphone.
- **Location Tracking:** The app allows you to mark and view the camera's location (note: no built-in GPS; location is app-based).
- **Share Moments:** Easily share captured photos and videos with others.

Contrôlez & Localisez Facilement



Ajustez facilement les paramètres de la caméra
Modifiez les paramètres depuis votre téléphone en
quelques secondes.



Marquez l'emplacement de la caméra directement dans l'application TrailCam Go.
Sachez exactement où se trouve votre appareil.

Image: Screenshots of the TrailCam Go app showing camera settings and location tracking.

INSTALLATION

The iG440 camera is designed for flexible and discreet installation.



Image: Examples of tree mounting and bracket mounting for the trail camera.

- **Tree Mounting:** Use the provided mounting strap to securely attach the camera to a tree.
- **Bracket Mounting:** Utilize the 1/4-inch threaded insert for mounting on a tripod or the included adjustable mounting bracket for stable and flexible positioning.

TROUBLESHOOTING

- **Camera Not Powering On:**
 - Ensure 8 AA batteries are correctly inserted with proper polarity.
 - Check if an external 6V 2A power adapter (not included) is connected correctly, if used.
 - Verify the power switch is in the "SETUP" or "ON" position.
- **No Photos/Videos Captured:**
 - Confirm a MicroSD card is inserted and not full. Format the card if necessary.
 - Check motion sensor (PIR) sensitivity settings.

- Verify that the camera is not in Time-Lapse mode if expecting motion-triggered captures.
- Ensure the camera is in "ON" mode, not "SETUP".

• **4G Connectivity Issues:**

- Ensure a valid Nano-SIM card is inserted and has an active data plan.
- Check the signal strength displayed on the camera or in the app.
- Confirm the "TrailCam Go" app is correctly installed and linked to your camera.
- Restart the camera and try again.

• **Poor Image/Video Quality:**

- Clean the camera lens.
- Ensure the camera is securely mounted to prevent shaking.
- For night vision, ensure no obstructions are blocking the IR LEDs.

SPECIFICATIONS

Feature	Detail
Brand	iZEEKER
Model Name	iG440
Connectivity Technology	Wireless (4G, Bluetooth)
Special Feature	2-in-1 (Standard & 4G Cloud), HD Resolution
Indoor/Outdoor Use	Outdoor
Mounting Type	Tree Mount
Video Recording Resolution	2K (1440p)
Photo Resolution	48MP (Max 8MP with cellular settings active)
Color	Green
Batteries Required	Yes (8 AA, not included)
Video Capture Format	MP4
Item Dimensions	50 x 50 x 100 mm
Country of Origin	China
UPC/GTIN	850039826764

WARRANTY & SUPPORT

iZEEKER is committed to providing high-quality products and excellent customer service.




Image: iZEEKER customer service commitments.

- **24-Hour Support:** Expect quick responses to your inquiries within 24 hours.
- **30-Day Returns & Exchange:** Enjoy a hassle-free return and exchange policy within 30 days of purchase.
- **Lifetime Service:** Benefit from continuous lifetime support for your iZEEKER product.

For any questions or assistance, please contact iZEEKER customer support through their official channels or the "TrailCam Go" application.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question