

LVSOMT 71-inch Arched Storage Cabinet

LVSOMT 71-inch Arched Storage Cabinet with LED Lighting User Manual

Model: 71-inch Arched Storage Cabinet

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your LVSOMT 71-inch Arched Storage Cabinet. Please read these instructions thoroughly before beginning assembly or use to ensure proper function and longevity of your product.

The LVSOMT Arched Storage Cabinet is designed to enhance your living space with its elegant arched top, glass doors, and integrated LED lighting. It features four tiers of shelving for display and two spacious drawers for concealed storage, making it suitable for various rooms such as living rooms, studies, kitchens, or dining areas.



Image: The LVSOMT 71-inch Arched Storage Cabinet in a living room, showcasing its design and illuminated interior.

2. SAFETY INFORMATION

Adherence to the following safety guidelines is crucial for preventing injury and damage to the product.

- **Assembly:** Always assemble the cabinet on a soft, clean surface to prevent scratches. Ensure all parts are correctly aligned and securely fastened according to the assembly instructions.
- **Stability:** This cabinet is designed with reinforced solid wood legs for stability. For added safety, especially in homes with children or pets, it is highly recommended to secure the cabinet to a wall using an anti-tipping kit (if included or purchased separately).
- **Weight Capacity:** Do not exceed the maximum weight capacity for each shelf. The top shelf supports up to 55 lbs, middle shelves support up to 40 lbs each, and the bottom shelf supports up to 55 lbs. The overall weight limit for the cabinet is 180 lbs. Distribute weight evenly.
- **Glass Components:** Handle glass doors and shelves with care. Tempered glass is used for durability, but it can still break if subjected to severe impact.
- **Electrical Components:** The LED lighting system should only be operated as described in this manual. Do not attempt to modify the electrical components. Ensure the power source meets the specified

requirements.

- **Placement:** Place the cabinet on a level surface. Avoid placing it in areas with excessive moisture or direct sunlight, which can affect the wood finish and electrical components.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed in the included assembly guide are present and undamaged. The package typically includes:

- Cabinet panels (top, bottom, sides, back)
- Glass doors and shelves
- Drawer components
- LED lighting kit with human sensor
- Hardware (screws, dowels, hinges, handles, drawer slides, magnetic closures)
- Assembly instructions

If any parts are missing or damaged, please contact LVSOMT customer support immediately.

4. ASSEMBLY INSTRUCTIONS

Assembly of the LVSOMT Arched Storage Cabinet requires two people and typically takes under 2 hours. Follow the detailed, step-by-step instructions provided in the separate assembly guide included with your product. All parts are numbered, and holes are pre-drilled for ease of assembly.

Key Assembly Tips:

- **Preparation:** Clear a spacious area and lay out all components on a soft blanket or carpet to prevent damage.
- **Hardware:** Separate and identify all hardware components before starting.
- **Sequence:** Adhere strictly to the assembly sequence outlined in the guide.
- **Tightening:** Ensure all screws and fasteners are tightened securely, but do not overtighten to avoid stripping or damaging the wood.
- **LED Installation:** Carefully follow the instructions for installing the LED lighting strips and connecting the human sensor.



Image: Product dimensions and individual shelf weight capacities for assembly planning.

5. OPERATING INSTRUCTIONS

5.1 LED Lighting System

The cabinet features built-in LED lights with adjustable colors and brightness, controlled by a touch-activated panel.

- **Changing Colors:** Short press the touch button on the control panel to cycle through the three available light colors: White, Warm Light (Yellow), and Blue Light.
- **Adjusting Brightness:** Long press the touch button to adjust the brightness level of the selected color. Release the button when the desired brightness is achieved.

3 COLORS LIGHTING DIMMING LIGHT

Short press the button to change the light color. Long press to adjust light brightness.



White Light



Warm Light



Blue Light

Image: Visual guide for operating the 3-color dimming LED lights and touch control panel.

5.2 Smart Human Sensor Mode

The cabinet is equipped with a smart human sensor that automatically activates the LED lights.

- **Activation:** The LED lights will automatically turn on when a person approaches within 2 meters (approximately 6.5 feet) of the sensor.
- **Deactivation:** The lights will automatically turn off when no motion is detected within the sensor's range for a set period.
- **Sensor Placement:** Ensure the sensor is not obstructed to allow for optimal detection.



Image: Illustration of the smart human sensor activating the cabinet lights when a person approaches.

5.3 Magnetic Doors and Drawers

- **Doors:** The glass doors feature magnetic closures for easy opening and secure closing, helping to protect contents from dust.
- **Drawers:** The two bottom drawers operate on smooth guide rails, ensuring effortless opening and closing for convenient storage access.



Double Drawers

Two large capacity drawers at the bottom with rails on both sides for added push and pull smoothness.

Image: Detail of the double drawers, highlighting the smooth guide rails for easy operation.



Magnetic Closure

Easy to open and close to prevent dust and the gold handle looks very stylish

Image: Detail of the magnetic closure, ensuring doors remain securely shut.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your LVSOMT storage cabinet.

- **Cleaning Wood Surfaces:** Wipe wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that can damage the finish. Dry immediately with a clean cloth.
- **Cleaning Glass Doors:** Use a standard glass cleaner and a soft, lint-free cloth to clean the glass doors. Spray cleaner onto the cloth, not directly onto the glass, to prevent overspray onto wood components.
- **Dusting:** Regularly dust all surfaces with a soft, dry cloth.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **LED Lights:** The LED lights are designed for long-term use and generally do not require maintenance. If issues arise, refer to the troubleshooting section.

7. TROUBLESHOOTING

If you encounter any issues with your LVSOMT Arched Storage Cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED lights do not turn on.	Power connection issue, sensor obstruction, faulty component.	<ul style="list-style-type: none">• Check if the power adapter is securely plugged into both the cabinet and a working wall outlet.• Ensure the human sensor is not obstructed and is clean.• Try a short press on the touch button to activate the lights manually.
Doors do not align or close properly.	Improper assembly, loose hinges, uneven floor.	<ul style="list-style-type: none">• Review the assembly instructions for correct hinge installation and adjustment.• Tighten hinge screws.• Ensure the cabinet is placed on a level surface. Use shims if necessary.
Drawers are stiff or do not slide smoothly.	Misaligned drawer slides, obstruction, loose screws.	<ul style="list-style-type: none">• Check that the drawer slides are correctly installed and aligned.• Ensure no objects are obstructing the drawer's path.• Tighten any loose screws on the drawer slides.
Cabinet wobbles.	Uneven floor, loose connections.	<ul style="list-style-type: none">• Relocate the cabinet to a level surface or use shims under the legs.• Check and tighten all assembly screws.

If the problem persists after attempting these solutions, please contact LVSOMT customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	LVSOMT
Model	71-inch Arched Storage Cabinet
Color	Wood
Product Dimensions	15.7"D x 31.5"W x 70.8"H
Material	Engineered Wood, MDF, Tempered Glass
Number of Shelves	4
Weight Limit (Overall)	180 Pounds
Special Features	Adjustable 3-Color LED Lighting, Human Sensor, Magnetic Doors

Feature	Detail
Assembly Required	Yes
Room Type	Bedroom, Dining Room, Kitchen, Living Room, Study Room

9. WARRANTY AND SUPPORT

LVSOMT is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, LVSOMT offers responsive customer support.

If you encounter any problems during assembly or use, or if you have questions about your product, please contact LVSOMT customer support. The seller aims to provide a satisfactory solution within 24 hours of your inquiry.

For support, please refer to the contact information provided with your purchase documentation or visit the official LVSOMT store page on Amazon.