

GYMAX GM2287

GYMAX 60-inch Kids Trampoline with Basketball Hoop Instruction Manual

Model: GM2287

1. IMPORTANT SAFETY INFORMATION

Read all instructions before assembling and using this trampoline. Failure to follow these instructions may result in serious injury or property damage. Keep this manual for future reference.

- **Age Recommendation:** This trampoline is designed for children aged 3-6 years old.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 330 lbs (150 kg).
- **Supervision:** Adult supervision is required at all times. Never leave children unattended on or near the trampoline.
- **One Jumper at a Time:** Only one child should use the trampoline at a time to prevent collisions.
- **Clearance:** Ensure adequate overhead and surrounding clearance. Keep the area around the trampoline free from obstacles.
- **Footwear:** Jump barefoot or in appropriate athletic shoes. Avoid shoes with hard soles or sharp edges.
- **No Somersaults:** Do not attempt somersaults or other dangerous maneuvers. Landing on the head or neck can cause serious injury.
- **Inspection:** Regularly inspect the trampoline for damaged, worn, or missing parts. Do not use if any components are compromised.
- **Weather Conditions:** Do not use the trampoline in wet, windy, or icy conditions. Secure the trampoline during strong winds.
- **Assembly:** Ensure all components are correctly assembled and securely fastened before use.



Image 1.1: The GYMAX 60-inch Kids Trampoline with Basketball Hoop. This image shows the fully assembled trampoline with its pink and blue frame, safety enclosure net, and integrated basketball hoop.

2. PRODUCT OVERVIEW

The GYMAX 60-inch Kids Trampoline with Basketball Hoop offers a safe and engaging play experience for children. It combines bouncing and shooting activities, featuring a robust design for durability and safety.

2.1 Key Features

- **High Bounce Performance:** Equipped with 36 sturdy springs and a highly elastic jumping mat for consistent and stable bounces.
- **Enhanced Safety:** Features a tear-resistant safety enclosure net, anti-collision foam pad, and a gap-free design to protect users.
- **Robust Stability:** Supported by 6 firm curved legs with anti-slip foot pads and reinforced connections for a solid

foundation.

- **2-in-1 Multi-functional Design:** Includes a wide backboard, inflatable basketball, air pump, and a foldable hoop for both jumping and shooting activities.
- **User-Friendly:** Designed with an easy-to-clean surface and child-safe zippers for convenience and low maintenance.

2.2 Components List

Before assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, contact customer support.


- Trampoline Frame (Metal components)
- Jumping Mat
- Safety Enclosure Net
- Springs (36 pieces)
- Spring Cover Pad (Anti-collision foam pad)
- Support Poles for Enclosure Net
- Basketball Backboard
- Basketball Hoop (Foldable)
- Inflatable Basketball
- Basketball Pump
- Hardware Kit (Bolts, nuts, washers, tools)
- Instruction Manual

2-in-1 Multi-functional Trampoline

Jumping



Shooting



Inflatable Basketball

Image 2.1: The 2-in-1 functionality of the trampoline, showing a child jumping on one side and another child shooting a basketball into the hoop on the other. This highlights the dual play options.

3. SETUP INSTRUCTIONS

Assembly requires at least two adults. Follow these steps carefully to ensure proper and safe setup.

3.1 Site Selection

- Choose a flat, level surface for the trampoline.
- Ensure sufficient overhead clearance (at least 8 feet) and lateral clearance (at least 2 feet around the perimeter).
- Avoid placing near walls, fences, trees, or other obstacles.
- For outdoor use, consider anchoring the trampoline to prevent movement in windy conditions.

3.2 Assembly Steps

1. **Unpack Components:** Carefully unpack all parts and verify against the components list. Place them on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Connect the metal frame sections according to the diagrams in the included instruction manual. Ensure all connections are reinforced and securely fastened with the provided hardware.
3. **Attach Jumping Mat:** Lay the jumping mat in the center of the frame. Attach the springs evenly around the frame and to the mat's V-rings using the spring tool (if provided). This step requires careful attention to ensure even tension.
4. **Install Spring Cover Pad:** Place the anti-collision foam pad over the springs and frame to cover all exposed metal parts and springs. Secure it in place.
5. **Erect Enclosure Net Poles:** Attach the support poles for the enclosure net to the trampoline frame. Ensure they are upright and stable.
6. **Install Enclosure Net:** Drape the safety enclosure net over the support poles and secure it to the jumping mat or frame as per the specific instructions. Ensure the child-safe zippers are functional.
7. **Attach Basketball Hoop:** Mount the basketball backboard and foldable hoop to the designated support pole or frame section.
8. **Inflate Basketball:** Use the provided air pump to inflate the basketball.
9. **Final Inspection:** Before first use, double-check all bolts, nuts, and connections to ensure they are tight and secure. Verify the enclosure net is properly installed and free of gaps.



Image 3.1: Illustration of the trampoline's sturdy construction, showing the metal frame, reinforced connections, firm curved legs, and anti-slip foot pads. These components are crucial for stable setup.

4. OPERATING INSTRUCTIONS

Proper use ensures safety and maximizes enjoyment of the trampoline.

4.1 General Use

- Ensure the safety enclosure net zipper is fully closed before jumping.
- Always enter and exit the trampoline through the designated zippered opening.
- Jump in the center of the mat for optimal balance and bounce.
- Maintain control while jumping. Avoid erratic or uncontrolled movements.
- Do not bounce off the enclosure net or frame pads.

4.2 Using the Basketball Hoop

- Use only the provided inflatable basketball or a similar soft, lightweight ball.
- Do not hang on the basketball hoop or backboard. This can damage the trampoline and cause injury.
- The hoop can be folded down when not in use for flexible storage or to provide more jumping space.



Image 4.1: A child enjoying bouncing on the trampoline, illustrating the high bounce performance provided by the 36 sturdy springs and highly elastic jumping mat.

Reliable Sturdiness



Reinforced Connections



Firm Curved Legs



Anti-slip Foot Pads

Image 4.2: A child jumping on the trampoline, demonstrating active use. This image emphasizes the fun aspect of the trampoline while reinforcing the need for supervision.

5. MAINTENANCE

Regular maintenance ensures the longevity and safety of your trampoline.

5.1 Cleaning

- Wipe down the jumping mat, frame pads, and enclosure net with a damp cloth and mild soap.
- Rinse thoroughly and allow to air dry completely before use.
- Avoid harsh chemicals or abrasive cleaners, as they can damage the materials.

5.2 Inspection

- **Before Each Use:** Visually inspect the trampoline for any loose, damaged, or missing parts. Check the integrity of the enclosure net, jumping mat, springs, and frame.

- **Monthly:** Check all bolts and nuts for tightness. Re-tighten if necessary. Inspect the spring cover pad for tears or deterioration.
- **Seasonal:** For outdoor trampolines, consider disassembling and storing indoors during harsh weather conditions to prolong its lifespan.

5.3 Storage

- If storing for an extended period, clean the trampoline thoroughly.
- Disassemble the trampoline if possible and store components in a dry, protected area away from direct sunlight and extreme temperatures.




Image 5.1: Detailed view of the trampoline's features, including the easy-to-clean surface, convenient child-safe zippers on the enclosure net, and tight sewing for durability. These aspects contribute to ease of maintenance.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your trampoline.

Problem	Possible Cause	Solution
Trampoline feels unstable.	Uneven ground; loose frame connections; damaged legs.	Move to a flat, level surface. Check and tighten all frame bolts. Inspect legs for damage and replace if necessary.
Poor bounce performance.	Damaged or stretched springs; worn jumping mat.	Inspect all 36 springs for damage or stretching. Replace any faulty springs. Check the jumping mat for tears or excessive wear.
Enclosure net has gaps or tears.	Improper installation; wear and tear; damage.	Ensure the net is correctly attached to all poles and the frame, with no gaps. Repair small tears with a patch kit or replace the net if damage is extensive.
Basketball hoop is loose.	Mounting hardware is loose.	Tighten all bolts securing the basketball backboard and hoop to the support pole.

If you encounter issues not listed here or require further assistance, please contact GYMAX customer support.

7. SPECIFICATIONS

Detailed technical specifications for the GYMAX 60-inch Kids Trampoline.

Feature	Detail
Model Name	Kids Trampoline with Basketball Hoop
Model Number	GM2287
Brand	GYMAX
Overall Product Dimensions	60"L x 60"W x 65.5"H (152.4 cm L x 152.4 cm W x 166.37 cm H)
Diameter of Jumping Area	48" (121.92 cm)
Diameter of Jumping Mat	34.5" (87.63 cm)
Height of Jumping Mat from Ground	15.5" (39.37 cm)
Basketball Backboard Dimensions	24.5"L x 12.5"W (62.23 cm L x 31.75 cm W)
Inner Diameter of Basketball Hoop	8" (20.32 cm)
Door Opening Dimensions	17"W x 25"H (43.18 cm W x 63.5 cm H)
Total Net Weight	41 lbs (18.6 kg)
Weight Capacity	330 lbs (150 kg)
Recommended Age	3-6 Years Old

Feature	Detail
Materials	PP, PVC, EPE Foam, Metal, PE, Sponge, Mesh Fabric
Frame Material	Metal
Color	Pink



Image 7.1: A detailed diagram illustrating the product dimensions, including overall height, diameter, jumping area, and basketball hoop measurements. It also indicates the weight capacity and recommended age.

8. WARRANTY & SUPPORT

8.1 Product Warranty

The GYMAX 60-inch Kids Trampoline (Model GM2287) comes with a **90-day warranty** from the date of purchase. This

warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, improper assembly, lack of maintenance, or normal wear and tear.

For specific warranty claims or to inquire about extended protection plans, please refer to your purchase documentation or contact the seller directly.

8.2 Customer Support

If you have any questions regarding the assembly, operation, maintenance, or troubleshooting of your GYMAX trampoline, please contact our customer support team. Have your model number (GM2287) and purchase information ready when you call or email.

- **Contact Information:** Please refer to the contact details provided with your purchase or on the GYMAX official website.
- **Online Resources:** Visit the GYMAX store on Amazon for additional product information and support:[GYMAX Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question