

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CaDA](#) /

› [CaDA C56044W NASA SLS Rocket Building Block Model Instruction Manual](#)

CaDA C56044W

CaDA C56044W NASA SLS Rocket Building Block Model Instruction Manual

This manual provides detailed instructions for the assembly, operation, and maintenance of your CaDA C56044W NASA SLS Rocket Building Block Model.



Image: The fully assembled CaDA C56044W NASA SLS Rocket Building Block Model, standing tall on its launch pad, ready for display.

1. SETUP AND ASSEMBLY

The CaDA C56044W model consists of 197 high-precision building blocks. Follow the included step-by-step pictorial instructions to ensure correct assembly. Organize all parts before beginning construction.

- **Part Identification:** Carefully identify all 197 pieces using the provided parts list in the separate assembly guide.
- **Rocket Body Construction:** Assemble the main rocket body, including the orange and white sections and the solid boosters. Pay attention to the detailed connections.
- **Launch Pad Assembly:** Construct the dedicated launch pad, ensuring all structural elements are securely connected.
- **Final Integration:** Carefully attach the assembled rocket to the launch pad. The reinforced design of the launch pad ensures the model stands firmly.
- **Detailing:** Add the white smoke effects around the base and the black NASA signage to complete the Kennedy Space Center launch scene.



Image: The CaDA C56044W model showcasing its detachable main rocket body, allowing for interactive display or closer inspection of internal components.

2. OPERATING THE MODEL

This building block model is primarily designed for display and collection. The main rocket body can be detached from the launch pad for closer examination or for imaginative play scenarios. Ensure careful handling when detaching or reattaching components to prevent damage.

3. MAINTENANCE

To maintain the appearance and integrity of your CaDA C56044W model, follow these guidelines:

- **Cleaning:** Use a soft, dry cloth or a small, soft brush to gently remove dust. Avoid using abrasive cleaners or solvents, as these can damage the plastic.
- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration and material degradation. Keep it away from extreme temperatures.
- **Handling:** Handle the model with care, especially when moving it, to prevent accidental detachment of parts.

4. TROUBLESHOOTING

If you encounter any issues during assembly or with the completed model, consider the following:

- **Missing Parts:** If you find any missing pieces, refer to the parts list in your assembly guide. Contact CaDA customer support for assistance with replacement parts.
- **Assembly Difficulties:** Double-check the assembly guide for the specific step causing difficulty. Ensure all pieces are oriented correctly and fully pressed into place. Sometimes, a small adjustment can resolve connection issues.
- **Stability Issues:** Verify that the launch pad is correctly assembled and placed on a flat, stable surface. Ensure the rocket is securely attached to the launch pad.

5. SPECIFICATIONS

Feature	Detail
Product Dimensions	3.78 x 2.91 x 7.91 inches (9.6 x 7.4 x 20.1 cm)
Item Weight	7.4 ounces
Item Model Number	C56044W
Manufacturer Recommended Age	14 years and up
Number of Pieces	197



Image: A visual representation of the CaDA C56044W model with its key dimensions (height, width, depth) clearly indicated.

6. SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years. Adult supervision is recommended during assembly and play for users under the recommended age.

7. WARRANTY AND SUPPORT

For information regarding product warranty, replacement parts, or additional support, please visit the official CaDA brand store or contact their customer service. Keep your purchase receipt as proof of purchase.

Visit the [CaDA Store](#) for more products and support.