

[manuals.plus](#) /› [Lenovo](#) /› [Lenovo ThinkVision T24-40 23.8-inch Monitor Instruction Manual](#)

## Lenovo T24-40

# Lenovo ThinkVision T24-40 23.8-inch Monitor Instruction Manual

Model: T24-40

## 1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Lenovo ThinkVision T24-40 23.8-inch Monitor. Please read this manual thoroughly before using your monitor to ensure proper functionality and to prevent damage.

### Key Features:

- 23.8" viewable screen size for enhanced clarity.
- WLED backlight technology for uniform illumination.
- 4 ms response time for smooth transitions.
- Designed to meet Eye Comfort standards with a 5-Star Eye Comfort Rating.
- 16:9 widescreen aspect ratio.
- 250 Nit brightness levels for clear visuals.
- Anti-glare matte screen finish.
- 1920 x 1080 maximum resolution.

## 2. WHAT'S IN THE Box

Verify that all items are present in the packaging:

- ThinkVision T24-40 Widescreen LED Monitor
- DP Cable
- USB-A to USB-B Cable

## 3. SETUP

### 3.1. Monitor Assembly

To assemble the monitor stand:

1. Carefully remove the monitor and stand components from the packaging.
2. Attach the stand neck to the back of the monitor. Align the tabs and push firmly until it clicks into place. Secure it with the captive thumb screw.
3. Attach the base to the stand neck. Align the base with the bottom of the neck and secure it with the captive thumb screw.



Figure 1: Rear view of the monitor with the stand attachment area.



Figure 2: Side view illustrating the monitor with its stand assembled.

### 3.2. Connecting the Monitor

Connect the monitor to your computer using the provided cables:

- **Power Connection:** Connect the power cable to the monitor's power input port and then to a power outlet.
- **Video Connection:** Connect the DisplayPort (DP) cable from your computer's DP output to the monitor's DP input. Alternatively, use an HDMI cable if your computer supports it.
- **USB Connection:** Connect the USB-A to USB-B cable from your computer to the monitor to enable the monitor's USB hub functionality.



Figure 3: Rear view of the monitor showing various input ports and connected cables.



Figure 4: Close-up of the monitor's side ports, including HDMI and VGA.

## 4. OPERATING INSTRUCTIONS

---

### 4.1. Power On/Off

Press the power button located on the bottom right bezel of the monitor to turn it on or off. The power indicator light will illuminate when the monitor is on.

### 4.2. On-Screen Display (OSD) Controls

The monitor features several buttons on the bottom bezel to access and navigate the On-Screen Display (OSD) menu. These controls allow you to adjust various display settings.



Figure 5: Control buttons located on the lower right side of the monitor bezel.

### 4.3. Adjusting Display Settings

Use the OSD buttons to navigate through the menu options. Common adjustments include:

- **Brightness/Contrast:** Adjust the overall luminance and contrast levels of the display.
- **Input Source:** Select between available input sources (e.g., HDMI, DisplayPort, VGA).
- **Color Settings:** Customize color temperature, gamma, and other color-related parameters.
- **Display Mode:** Choose from preset display modes optimized for different content types (e.g., Standard, Movie, Game).

### 4.4. Physical Adjustments

The monitor stand allows for ergonomic adjustments:

- **Height Adjustment:** Gently push or pull the monitor up or down to achieve the desired viewing height.
- **Tilt Adjustment:** Tilt the screen forward or backward to optimize your viewing angle.
- **Swivel Adjustment:** Rotate the monitor left or right on its base.

## 5. MAINTENANCE

To ensure the longevity and optimal performance of your ThinkVision T24-40 monitor, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth lightly dampened with water or a non-ammonia, non-alcohol-based screen cleaner. Do not spray liquid directly onto the screen.
- **Cleaning the Casing:** Use a soft, dry cloth to wipe the monitor casing. Avoid abrasive cleaners.
- **Ventilation:** Ensure the ventilation openings on the monitor are not blocked to prevent overheating.
- **Storage:** When not in use for extended periods, store the monitor in a cool, dry place, ideally in its original packaging.

## 6. TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common problems and solutions:

Problem	Possible Solution
No image on screen	Ensure power cable is securely connected. Verify video cable is connected to both monitor and computer. Select correct input source via OSD.
Image is dim or too bright	Adjust brightness and contrast settings using the OSD menu.
Colors appear incorrect	Adjust color settings in the OSD menu. Ensure graphics drivers are up to date.
Monitor flickers	Check video cable connections. Ensure refresh rate is set correctly in your computer's display settings.
No sound	If using monitor speakers, ensure volume is not muted and is turned up. Check audio output settings on your computer.

## 7. SPECIFICATIONS

Feature	Detail
Standing screen display size	23.8 Inches
Screen Resolution	1920x1080
Max Screen Resolution	1920 x 1080 Pixels
Brand	Lenovo
Series	ThinkVision
Item model number	T24-40
Item Weight	6.61 pounds
Product Dimensions	1.8 x 21.3 x 12.4 inches
Color	Eclipse Black, Black
Aspect Ratio	16:9
Screen Surface Description	Matte

## 8. WARRANTY AND SUPPORT

For warranty information, technical support, or to download the latest drivers and user manuals, please visit the official Lenovo support website. Keep your purchase receipt for warranty claims.

**Lenovo Support Website:** [pcsupport.lenovo.com](http://pcsupport.lenovo.com)

