



Manuals.plus /

› PINDOWS /

› PINDOWS Minimalist Quartz Analog Watch (Model PDS-G652) User Manual

PINDOWS PDS-G652

PINDOWS Minimalist Quartz Analog Watch (Model PDS-G652) User Manual

Your guide to setup, operation, and care.

INTRODUCTION

Thank you for choosing the PINDOWS Minimalist Quartz Analog Watch, Model PDS-G652. This watch combines a sleek gold-tone case with a minimalist white dial and a comfortable black leather strap, designed for daily wear. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your watch to ensure its longevity and accurate performance.





Front view of the PINDOWS Minimalist Quartz Analog Watch, Model PDS-G652. The watch features a round gold-tone case, a clean white dial with black Arabic numerals, and a black leather strap. The PINDOWS logo is visible below the 12 o'clock position.

SETUP

Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) outwards to the

first position.

2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position. This will start the watch movement.

Adjusting the Strap

The black leather strap is designed for comfort and adjustability. To adjust the strap:

1. **Unbuckle the strap:** Open the buckle of the leather strap.
2. **Position on wrist:** Place the watch on your wrist.
3. **Select hole:** Insert the pin of the buckle into the strap hole that provides a comfortable and secure fit. The watch should not be too tight or too loose.



The PINDOWS watch comfortably worn on a wrist, demonstrating the fit of the black leather strap and the elegant appearance of the gold-tone case.

OPERATING INSTRUCTIONS

Timekeeping

Your PINDOWS watch is equipped with a precise Japanese quartz movement, ensuring accurate timekeeping. Once the time is set, the watch will continuously display the current time.

Water Resistance (30 Meters / 3 ATM)

This watch is designed with a water resistance rating of 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in water, such as when washing hands. **It is not suitable for showering, bathing, swimming, diving, or any water sports.** Avoid operating the crown while the watch is wet to prevent water ingress.

Luminous Dial

The watch features a full luminous dial that ensures clear visibility in low-light conditions. After exposure to light, the dial will glow, allowing you to read the time in the dark.

FULL LUMINOUS DIAL



FULL LUMINOUS DIAL ENSURES CLEAR VISIBILITY
IN LOW-LIGHT CONDITIONS

The watch dial illuminated in a green glow, demonstrating its luminous feature for easy time reading in dark environments.

MAINTENANCE

Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and strap regularly with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals, which can damage the material.

Battery Replacement

The quartz movement is powered by a watch battery. When the watch stops running, it indicates that the battery needs to be replaced. It is recommended to have the battery replaced by a qualified watch technician to ensure the watch's water resistance is maintained and to prevent damage to the internal components.

Storage

When not wearing your watch for extended periods, store it in a cool, dry place away from direct sunlight and extreme temperatures. Keeping it in its original packaging or a watch box can help protect it from dust and scratches.



Stainless Steel Back Cover

corrosion-resistant and tightly sealed

The stainless steel back cover of the PINDOWS watch, indicating its corrosion-resistant properties and the model number PDS-G652.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch is not running	Battery depleted or crown not pushed in	Push the crown fully into the case. If it still doesn't run, the battery may need replacement. Contact a professional watch technician.
Time is inaccurate	Magnetic interference or low battery	Keep the watch away from strong magnetic fields. If the issue persists, the battery may be low and require replacement.
Condensation inside the watch	Exposure to extreme temperature changes or water ingress	Avoid sudden temperature changes. If condensation appears, have the watch inspected by a technician immediately to prevent damage.

SPECIFICATIONS

- **Model Number:** PDS-G652
- **Movement:** Japanese Quartz
- **Case Material:** Gold-Tone Metal
- **Strap Material:** Black Leather
- **Water Resistance:** 30 Meters (3 ATM) - Splash resistant, not for swimming or showering.
- **Dial:** Minimalist White Dial with Luminous Numerals
- **Case Thickness:** Approximately 8 mm
- **Manufacturer:** PINDOWS
- **Department:** Women

Thinner than the Phone

8MM



3.15 in

Side profile of the PINDOWS watch, highlighting its slim 8mm case thickness.

WARRANTY INFORMATION

PINDOWS watches are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official PINDOWS website. The warranty typically covers manufacturing defects under normal use.

CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your PINDOWS watch, please do not hesitate to contact our customer support team. You can find contact details, including email and phone numbers, on the official PINDOWS website or through your retailer.

We are committed to providing professional service and ensuring your satisfaction.