COLORROOM A30L1 EVA

COLORROOM Kids Tablet A30L1 EVA

10.1-inch HD Android 16 User Manual

Model: A30L1 EVA | Brand: COLORROOM

1. INTRODUCTION

Welcome to the COLORROOM Kids Tablet A30L1 EVA user manual. This guide provides essential information to help you set up, operate, and maintain your new tablet. Designed for children aged 3-12, this tablet offers a safe and engaging digital environment for learning and entertainment, featuring robust parental controls and a durable design.

2. SAFETY INFORMATION

- **Supervision:** Always supervise children during tablet use.
- **Charging:** Use only the provided charger and cable. Do not use the tablet while charging.
- **Water Exposure:** Keep the tablet away from water and moisture.
- **Temperature:** Avoid extreme temperatures.
- **Cleaning:** Clean the tablet with a soft, dry cloth. Do not use liquid cleaners.
- **Screen Time:** Utilize parental controls to manage screen time and prevent excessive use.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- COLORROOM Kids Tablet A30L1 EVA (with EVA Protective Case)

- USB-C Cable
- Power Adapter
- User Guide (this document)

Video Description: This video demonstrates the unboxing process of the COLORROOM Kids Tablet, showcasing the tablet, its protective EVA case, and included accessories like the charging cable and adapter.

4. SETUP

4.1 Initial Power On

1. Press and hold the power button (located on the side) until the screen lights up.
2. Follow the on-screen prompts to select your language and region.

4.2 Connecting to Wi-Fi

1. From the home screen, tap the 'Settings' icon.
2. Select 'Network & internet' then 'Wi-Fi'.
3. Choose your Wi-Fi network from the list and enter the password.
4. Tap 'Connect'.

4.3 Setting up Google Kids Space and Parental Controls

The tablet comes with Google Kids Space pre-installed, offering a curated selection of apps, books, and videos for children. Parental controls are managed through Google Family Link.

1. Open the 'Google Kids Space' app.
2. Follow the instructions to set up a child profile and link it to your Google Family Link account on your smartphone.
3. On your smartphone, download and install the Google Family Link app.
4. Use the Family Link app to manage your child's device, including app usage, screen time limits, and content restrictions.

Image Description: A close-up of the COLORROOM Kids Tablet screen displaying the Google Kids Space interface with various child-friendly app icons for playing, reading, watching, and creating.

Video Description: This video demonstrates how to use Google Family Link on a parent's smartphone to manage app restrictions and usage time for the child's tablet, ensuring a safe digital experience.

5. OPERATING THE TABLET

5.1 Basic Navigation

- **Touch Screen:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access all installed apps and widgets.
- **Notifications:** Swipe down from the top of the screen to view notifications and quick settings.

5.2 Using Educational Apps and Content

The tablet provides access to thousands of high-quality educational content, including picture books, educational comics, children's books, early learning apps for alphabet and numbers, programming tools, and

interactive games.

Android 16 世界で初登場

24(4+20)GB RAM+64GB ROM

Image Description: The COLORROOM Kids Tablet in its purple EVA case, displaying a vibrant home screen with various educational and entertainment app icons, including STEM, ABC, and drawing applications.

Video Description: This video highlights the diverse range of educational apps available on the tablet, covering subjects like English, Kanji, and arithmetic, along with learning manga, children's books, games, and videos.

5.3 Accessing YouTube Kids

YouTube Kids is designed for children, offering a safe and easy way to enjoy videos. Filters can be flexibly adjusted according to your child's growth.

Image Description: An image comparing the interfaces of standard YouTube and YouTube Kids, emphasizing the child-friendly design and content filtering of YouTube Kids.

5.4 Using the Camera

The tablet features a 5MP front camera and an 8MP rear camera for capturing photos and videos.

5.5 AR Zoo Application

Explore augmented reality with the pre-installed AR Zoo app. Scan animal pictures to bring them to life on your tablet screen.

6. PARENTAL CONTROLS

The tablet is equipped with comprehensive parental controls to ensure a safe and educational experience for your child. These features are primarily managed through the Google Family Link app on your smartphone.

- **Custom Child Profiles:** Create individual profiles for each child.
- **Time Limits:** Set precise daily usage limits in 15-minute increments to prevent overuse.
- **App Approval:** Individually approve safe apps and websites.
- **Content Monitoring:** Easily check your child's device usage and content viewed.
- **Learning Goals:** Set learning objectives, and restrict entertainment content until goals are met.
- **GPS Functionality:** Monitor the tablet's location through the Family Link app.

6000mAh大容量バッテリー

アニメ鑑賞、2D ゲーム、ネットサーフィンなどを、快適に楽しめる環境をご提供します。

7. FEATURES OVERVIEW

7.1 Display

- **Size:** 10.1 inches
- **Resolution:** 1280x800 HD IPS

- **Widevine L1 Support:** Ensures high-quality streaming for services like Netflix and YouTube.

Image Description: The tablet screen showing a comparison between L1 (1080P) and L3 (720P) Widevine levels, indicating support for high-definition content streaming.

Video Description: This video showcases the 10.1-inch large screen of the tablet, highlighting its visual quality for children's content.

7.2 Performance

- **Operating System:** Android 16 (personalized, secure, user-friendly)
- **CPU:** 2.0GHz Octa-Core
- **RAM:** 24GB (4GB physical + 20GB virtual expansion)
- **Internal Storage:** 64GB ROM
- **Expandable Storage:** Supports microSD cards up to 1TB

Android 16 **10.1インチ** **6000mAh** **WiFi 5** **1280*800** **24(4+20)+64GB**

Image Description: The tablet screen displaying the Android 16 operating system, emphasizing enhanced privacy, improved operability, and AI features for a smart daily experience.

7.3 Battery

- **Capacity:** 6000mAh
- **Battery Life:** Up to 8 hours of continuous use
- Supports fast charging and features low power consumption.

Image Description: The tablet screen showing a charging battery icon, alongside images of children using the tablet for studying, playing games, and watching videos, illustrating its long battery life.

7.4 Protection

- **EVA Protective Case:** Lightweight and shock-absorbing, providing excellent protection against drops.
- **360-degree Rotating Handle/Stand:** Allows for vertical or horizontal viewing and easy portability.

6000mAh大容量バッテリー

アニメ鑑賞、2D ゲーム、ネットサーフィンなどを、快適に楽しめる
環境をご提供します。

10.1インチ 1280*800 FHD IPS

大画面でのビジュアル体験を最大化するために設計
されており、高解像度のデイスプレイは映画や動画,
写真を鮮やかに映し出します

Widevine L1対応

L3 720P   L1 1080P

耐久性のある保護には、
EVA を選ぼう!

かさばる心配なし! EVA はシリコンより軽く、
衝撃吸収性にも優れます。

Image Description: The tablet in its EVA case, highlighting its shock-absorbing properties with illustrations of drops and the versatile 360-degree rotating handle that doubles as a stand.

Video Description: This video demonstrates the 360-degree rotating handle/stand and the durable, shock-resistant case of a 7-inch kids tablet. Note: This product is a 10.1-inch tablet, but features similar case design.

8. MAINTENANCE

8.1 Cleaning the Tablet

To clean the tablet screen and body, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.

8.2 Battery Care

- Avoid fully discharging the battery frequently.
- Do not leave the tablet connected to the charger for extended periods after it's fully charged.
- Store the tablet in a cool, dry place when not in use for long periods.

8.3 Software Updates

Periodically check for system updates to ensure optimal performance and security. Go to 'Settings' > 'System' > 'System update' to check for and install available updates.

9. TROUBLESHOOTING

- **Tablet not turning on:** Ensure the battery is charged. Connect the charger and try again.
- **Screen frozen:** Press and hold the power button for about 10 seconds to force a restart.
- **Wi-Fi connection issues:** Check if your Wi-Fi router is working correctly. Restart the tablet and try reconnecting.
- **Apps crashing:** Clear the app's cache in 'Settings' > 'Apps' > [App Name] > 'Storage' > 'Clear cache'. If the issue persists, reinstall the app.
- **Slow performance:** Close unnecessary background apps. Clear cache and temporary files. Consider a factory reset if problems continue (back up data first).

10. SPECIFICATIONS

Feature	Specification
Brand	COLORROOM
Model Name	A30L1 EVA
Operating System	Android 16
CPU	2.0 GHz Octa-Core (Unisoc)
RAM	24 GB (4GB + 20GB virtual)
Storage	64 GB (expandable up to 1TB via microSD)
Screen Size	10.1 inches
Display Resolution	1280x800 pixels HD IPS
Front Camera	5 MP
Rear Camera	8 MP
Battery Capacity	6000 mAh
Battery Life	Up to 8 Hours
Connectivity	Wi-Fi (802.11ac), Bluetooth
Dimensions	32 x 22.4 x 3.6 cm

Weight	500 g

11. WARRANTY AND SUPPORT

The COLORROOM Kids Tablet A30L1 EVA comes with a **1-year quality assurance service**. If you encounter any issues with the product, please contact our specialized after-sales service team promptly. We are committed to providing efficient support to resolve your concerns and exceed your expectations.
For support, please refer to the contact information provided with your purchase or visit the COLORROOM brand store on Amazon.