

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Glocusent](#) /

› [Glocusent White Noise Sound Machine N16 Instruction Manual](#)

Glocusent N16

Glocusent White Noise Sound Machine N16 Instruction Manual

Brand: Glocusent | Model: N16

INTRODUCTION

The Glocusent White Noise Sound Machine N16 is designed to enhance your sleep and relaxation experience with a wide array of soothing sounds and customizable lighting. This manual will guide you through the features and operation of your new device.

WHAT'S IN THE Box

- 1 x Glocusent White Noise Sound Machine N16
- 1 x Type-C Charging Cable
- 1 x User Manual

PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your sound machine.

Customizable Sound Mix



Figure 1: Top view of the Glocusent N16 Sound Machine, highlighting the intuitive control panel with clearly labeled buttons for power, mode, sound selection, volume, timer, and light settings.

Controls and Ports:

- **Power/Mode Button:** Turns the device on/off and cycles through main sound categories.
- **Sound Selection Buttons (Previous/Next):** Navigates through the available sound tracks.
- **Volume Buttons (V-/V+):** Adjusts the sound volume.
- **Timer Button:** Sets the auto-off timer.
- **Light Mode Button:** Cycles through different light colors and modes.
- **Brightness Button:** Adjusts the brightness of the night light.
- **USB-C Port:** For power input.
- **TF Card Slot:** For playing personalized audio files.

SETUP

- Connect Power:** Insert the Type-C cable into the USB-C port on the device and connect the other end to a compatible USB power adapter (not included) or a USB port.
- Power On:** Press and hold the Power/Mode button for a few seconds to turn on the device. The default sound and light settings will activate.

OPERATING INSTRUCTIONS

Sound Selection

The device offers 44 soothing sounds across various categories:

- 10 White Noise tracks
- 10 Pink Noise tracks
- 11 Brown Noise tracks
- 9 Alpha Brainwave tracks
- 4 Piano Music tracks

- Change Sound Category:** Press the Power/Mode button briefly to cycle through the main sound categories (White Noise, Pink Noise, Brown Noise, Alpha Brainwaves, Piano Music).
- Select Specific Sound:** Use the Sound Selection buttons (Previous/Next) to choose a specific track within the current category.



Figure 2: The Glocusent N16 offers 44 distinct sounds, including various white, pink, and brown noises, alpha brainwaves, and piano music, designed to create a calming environment for sleep.

Volume Control

Press the **V-** button to decrease the volume or the **V+** button to increase the volume. The volume range is 20-65dB.

Customizable Sound Mix

The sound machine allows you to combine primary sound tracks with secondary piano pieces for a personalized audio experience. You can also play your own sounds via a TF card.

- Combining Sounds:** Select a primary sound, then activate the piano music track to layer them.
- TF Card Playback:** Insert a TF card with your preferred audio files into the TF card slot. The device will automatically detect and play the files.



Figure 3: The customizable sound mix feature allows users to combine primary sounds with piano tracks or play personal audio from a TF card.

Adjustable Night Light

The device features 12 lighting modes to create a calming ambiance.

- 1. Change Light Mode:** Press the Light Mode button briefly to cycle through 2 gradient modes, 2 breathing light modes, and 8 static-color lights.
- 2. Adjust Brightness:** Press the Brightness button to adjust the intensity of the selected light mode.




Figure 4: The Glocusent N16 offers versatile light modes, including gradient, breathing, and static colors, with adjustable brightness to suit your preference.

Timer Settings

Set an auto-off timer to conserve energy or match your sleep cycle.

- **Timer Options:** Choose from 0.5 hours, 1 hour, 1.5 hours, 6 hours, or infinite mode.
- **Set Timer:** Press the Timer button repeatedly to cycle through the available timer durations. An indicator light will confirm your selection.



Figure 5: The sound machine features four timer settings (0.5h, 1h, 1.5h, 6h) and an infinite mode for flexible use.

MEDIA INTEGRATION

Watch this official product video for a visual guide on the Glocusent 4-in-1 Sleep Sound Machine.

Your browser does not support the video tag.

Video 1: An official overview of the Glocusent 4-in-1 Sleep Sound Machine, demonstrating its features and benefits.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place when not in use.
- **Avoid Water:** Keep the device away from water and high humidity.

TROUBLESHOOTING

Problem	Possible Solution
Device does not power on.	Ensure the Type-C cable is securely connected to both the device and a working power source. Try a different power adapter or USB port.
No sound or low volume.	Check the volume level using the V+ button. Ensure the device is not muted.

Problem	Possible Solution
Light is not working.	Press the Light Mode button to cycle through modes. Adjust brightness using the Brightness button.
TF card audio not playing.	Ensure the TF card is inserted correctly and contains compatible audio files.

SPECIFICATIONS

- **Product Dimensions:** 3.54 x 3.54 x 2.17 inches
- **Item Weight:** 11.04 ounces (313 Grams)
- **Model Name:** GLCSNTN1601
- **Item Model Number:** N16
- **Brand:** Glocusent
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Color:** White
- **Manufacturer:** Glocusent

WARRANTY AND SUPPORT

Glocusent offers comprehensive customer support for your product.

- **Warranty:** Enjoy a 24-month warranty from the date of purchase.
- **Returns:** 30-day returns are available.
- **Customer Support:** 24/7 customer support is available for any inquiries or assistance.