

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LINSY HOME](#) /

> [LINSY HOME Rattan Dresser \(Model HC818E\) - 5-Drawer Assembly and Care Manual](#)

LINSY HOME HC818E

LINSY HOME Rattan Dresser (Model HC818E)

5-Drawer Assembly and Care Manual

1. INTRODUCTION

Thank you for choosing the LINSY HOME Rattan Dresser. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new 5-drawer dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

- This dresser meets stringent ASTM 2057-2023 safety standards.
- Always use the provided anti-tip device to secure the dresser to a wall. This prevents accidental tipping and serious injury.
- Keep small parts and packaging materials away from children during assembly.
- The dresser features rounded edges for enhanced child safety.
- Do not allow children to climb on or play with the dresser.

2. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. All parts are labeled with numbers or letters for easy identification.

- Dresser Frame Components
- 5 Rattan Drawers
- Metal Handles
- Assembly Hardware (screws, bolts, anti-tip kit)
- Allen Wrench (included for assembly)

Product Dimension



Image: Detailed product dimensions, showing the overall height of 46.4 inches, width of 31.4 inches, and depth of 15.7 inches, along with individual drawer dimensions.

3. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. It is recommended to have a clear, spacious area for assembly. Do not fully tighten screws until all components are in place to allow for minor adjustments.

- 1. Unpack and Identify:** Carefully unpack all components and lay them out. Match each part to the corresponding label in the instruction diagram.
- 2. Assemble the Frame:** Begin by connecting the main frame pieces according to the numbered steps in your included manual. Ensure all pieces are correctly oriented before securing.
- 3. Install Cross Braces:** Attach the cross braces to the back of the frame. These provide structural stability.
- 4. Attach Leveling Feet:** Screw the adjustable leveling feet into the bottom of the dresser legs. Adjust them as needed to ensure the dresser is stable and level on any surface.
- 5. Prepare Drawers:** Fold and assemble the fabric drawers. Insert the bottom panel to create a sturdy base for each drawer.

6. **Attach Handles:** Secure the metal handles to the front of each drawer using the provided screws.
7. **Insert Drawers:** Slide the assembled drawers into their respective slots in the dresser frame.
8. **Install Anti-Tip Kit:** Securely attach the anti-tip device to the back of the dresser and to a wall stud, following the specific instructions provided with the kit. This step is crucial for safety.



Sturdy Solid Wood Legs

Durable craftsmanship for lasting stability.

Durable Metal Handles

Strong, stylish, and built to last



Premium Slide Rail

Drawers open easily and smoothly for everyday convenience

Image: Details highlighting the sturdy solid wood legs, durable metal handles, and the smooth operation of the premium slide rails for the drawers.

4. OPERATING INSTRUCTIONS

The LINSY HOME Rattan Dresser is designed for versatile storage in various rooms.

- **Drawer Usage:** Gently pull and push the drawers to open and close. Avoid forcing them to prevent damage to the slide rails.
- **Weight Distribution:** Distribute items evenly within the drawers. Avoid placing excessively heavy items in a single drawer or on the tabletop to maintain stability and prevent damage.

- **Versatile Placement:** This dresser is suitable for bedrooms, living rooms, entryways, closets, and kids' rooms. Its thickened tabletop can hold decorative items, lamps, or small electronics.

Ample Storage Space



Image: An illustration demonstrating the ample storage capacity of the dresser, indicating it can hold over 10 tissues, 40 socks, 20 underwear, 20 snacks, 10 toys, and 10 shirts.

5. MAINTENANCE

Proper care will extend the life and appearance of your dresser.


- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish or rattan panels.
- **Rattan Care:** The elegant rattan panels can be gently dusted with a soft brush or cloth. Avoid excessive moisture.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or damage to the wood finish and rattan.

6. TROUBLESHOOTING

- **Dresser is Wobbly:** Ensure all assembly screws are fully tightened. Adjust the leveling feet on the bottom of the legs to stabilize the unit on uneven floors. Verify the anti-tip device is securely installed.
- **Drawers Do Not Slide Smoothly:** Check that the drawer slides are correctly aligned and free from obstructions. Ensure the drawers are assembled correctly and not overloaded.
- **Missing Parts:** If any parts are missing or damaged upon arrival, please contact LINSY HOME customer support for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	LINSY HOME
Model Name	Dresser (Model HC818E)
Product Dimensions	15.7"D x 31.4"W x 46.4"H
Color	Walnut
Room Type	Bedroom, Closet, Entryway, Home Office, Living Room
Assembly Required	Yes
Item Weight	110 Pounds
Number of Drawers	5
Material	Engineered Wood
UPC	810199833897



Elegant Rattan Panels
Adds texture and a naturally inspired look



Sturdy Solid Wood Legs
Durable craftsmanship for lasting stability



Reinforced "Water Cube" Frame
Upgraded stability for everyday use



Durable Metal Handles
Strong, stylish, and built to last

Image: Illustration of P2 Grade Plate material and a chart indicating low formaldehyde emission levels, meeting safety standards.

8. WARRANTY AND SUPPORT

LINSY HOME is committed to providing high-quality products. While specific warranty details are not included in this manual, we stand by the craftsmanship and durability of our dresser.

If you encounter any issues during assembly or use, or if you have questions about your product, please do not hesitate to contact our friendly support team. We are always ready to assist you.

For support, please refer to the contact information provided at the point of purchase or visit the official LINSY HOME website.

