

[Manuals.plus](#) /

> [VEKJ](#) /

> VEKJ L8 Pro Bluetooth Wireless Earbuds User Manual

VEKJ L8pro

VEKJ L8 Pro Bluetooth Wireless Earbuds User Manual

Model: L8pro

INTRODUCTION

Thank you for choosing the VEKJ L8 Pro Bluetooth Wireless Earbuds. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before use.

The L8 Pro earbuds are designed for comfort, especially for side sleepers, weighing only 3.0g per earbud. They deliver Hi-Fi audio with a 14.2mm dynamic driver and feature passive noise cancellation for an immersive listening experience.

PACKAGE CONTENTS

Ensure all items are present in the package:

- L8 Pro Wireless Earbuds (Left/Right)
- Portable Charging Case
- USB Type-C Charging Cable
- User Manual
- Silicone Eartips (S/M/L sizes)


SETUP

1. Initial Charging

Before first use, fully charge the earbuds and charging case. Connect the provided USB Type-C cable to the charging port on the case and a power source. The LED display on the case will indicate charging status.

48時間の長いバッテリー寿命

ポータブル充電ケースで一日中音楽を自由に楽しめます



40時間
充電ボックス



6-8時間
1回の充電



1.5時間
1回の充電

Image: The charging case with earbuds inside, connected via a Type-C cable for charging. The display shows battery levels.


A full charge takes approximately 1.5 hours for the earbuds, providing 6-8 hours of playback. The charging case provides additional charges for a total playback time of up to 48 hours.

2. Pairing with Your Device

The L8 Pro earbuds feature Hall Technology for easy one-step pairing using Bluetooth 5.4.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your smartphone or other Bluetooth-enabled device, go to Bluetooth settings.
3. Select "L8 Pro" from the list of available devices.
4. Once connected, you will hear a confirmation tone, and your device will show "Connected."

自動ペアリングとスマート タッチコントロール



15M



電話



音楽



音量



スリープモード 音声アシスタント



Image: A smartphone screen displaying Bluetooth settings with "L8 Pro" connected, alongside the earbuds and charging case.

The earbuds will automatically reconnect to the last paired device when the case is opened, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Touch Controls

The L8 Pro earbuds feature a multi-function touch screen on the charging case and touch controls on the earbuds themselves. This allows for easy management of music, calls, and settings.

多機能タッチスクリーン スリープイヤホン

豊富な機能と簡単な操作



Image: A diagram illustrating various functions accessible via the touch screen on the charging case, including screen lock, language switching, finding earbuds, brightness adjustment, music playback controls, timer, sound equalizer, and sleep mode.

Earbud Touch Control Functions

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Right)	Volume Up
Triple Tap (Left)	Volume Down
Long Press (2s) (L/R)	Activate Voice Assistant / Reject Call

Sleep Mode

The L8 Pro features a dedicated sleep mode designed for undisturbed rest. When activated, this mode automatically blocks incoming calls and disables touch controls on the earbuds to prevent accidental operations. It also eliminates power-off beeps or low battery alerts during sleep.



スリープモード

電源オフ
アラームなし

低電池アラームなし

タッチ無効

睡眠をパーソナライズ

より早く眠りにつき、より長く眠り続ける

Image: A person sleeping comfortably with the earbuds, illustrating features like sleep mode, no power-off alarm, no low battery alarm, and touch disablement.

To activate sleep mode, use the touch screen on the charging case. This mode is supported only when both earbuds are in use.

EQ Modes

Customize your audio experience with 5 equalizer (EQ) modes available through the charging case touch screen:

- **Standard:** Balanced audio for general listening.
- **Pop:** Enhanced vocals and bass for pop music.
- **Rock:** Boosted bass and treble for rock genres.

- **Classic:** Optimized for classical music with clear instrument separation.
- **Jazz:** Warm and smooth tones for jazz music.



究極のサウンド
コントロール
を実現する
5つのEQモード

- ノーマル
- ジャズ
- ロック
- ポップス
- クラシック

Image: A person smiling while wearing the earbuds, with an illustration of the five EQ modes: Normal, Jazz, Rock, Pop, and Classic.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Eartips:** Remove and clean the silicone eartips periodically with mild soap and water. Ensure they are completely dry before reattaching.
- **Charging Port:** Keep the Type-C charging port free of dust and debris.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.

- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand sweat and rain. However, they are not designed for swimming or submersion in water. Ensure the charging port is dry before charging.



Image: A person wearing the earbuds, highlighting features such as ergonomic design, ultra-lightweight (3.0g), 42dB noise isolation, and IPX7 waterproofing.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Solution
---------	----------

Problem	Solution
Earbuds not pairing	<ul style="list-style-type: none"> ◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Place earbuds back in the case, close, then reopen to re-enter pairing mode. ◦ Forget "L8 Pro" from your device's Bluetooth list and try pairing again.
No sound from one earbud	<ul style="list-style-type: none"> ◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again. ◦ Check device audio settings to ensure balance is centered.
Earbuds not charging	<ul style="list-style-type: none"> ◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Check if the charging contacts on the earbuds and inside the case are clean and free of debris. ◦ Try a different charging cable or power adapter.
Poor sound quality	<ul style="list-style-type: none"> ◦ Ensure earbuds are properly seated in your ears for a good seal. ◦ Try different sized eartips. ◦ Check the audio source quality. ◦ Ensure there are no obstructions between the earbuds and your device.

SPECIFICATIONS

Feature	Detail
Model Name	L8pro
Brand	VEKJ
Connectivity Technology	Wireless (Bluetooth 5.4)
Noise Control	Passive Noise Cancelling, Sound Isolation
Driver Size	14.2mm Dynamic Driver
Playback Time	6-8 hours (earbuds), up to 48 hours with charging case
Charging Time	Approx. 1.5 hours (earbuds)

Feature	Detail
Charging Port	Type-C
Water Resistance	IPX7
Control Type	Touch Control
Ear Placement	In-Ear
Headphone Form Factor	In-Ear
Impedance	32 Ohm
Material	Silicone
Product Dimensions	8.9 x 7.9 x 3.4 cm; 80 g
Compatible Devices	iPhone 17/16/15/14/13/12/11/XS/XR/X/8/7 series, Apple Watch, iPad Pro/Air/mini; Samsung Galaxy S8/S6, Note5/4/3; Moto X/G/E, DROID Turbo 2/Maxx 2; SONY Xperia X/Z5/C4/M4/Z3/Z2 series; Xiaomi 6/5s/5; Huawei mate9/8/P10/P8/mate30/mate40. Compatible with almost all Bluetooth devices.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official VEKJ website. Keep your proof of purchase for warranty claims.