

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aiwa](#) /

› [Aiwa AW-SJ215 Portable Bluetooth Speaker User Manual](#)

## Aiwa AW-SJ215

# Aiwa AW-SJ215 Portable Bluetooth Speaker User Manual

Model: AW-SJ215

## 1. INTRODUCTION

Welcome to the user manual for your Aiwa AW-SJ215 Portable Bluetooth Speaker. This speaker is designed for versatile audio playback, featuring Bluetooth 5.3 connectivity, FM radio, and multiple input options. Its IPX5 rating ensures splash resistance, making it suitable for various environments. Please read this manual carefully to ensure proper use and maintenance of your device.



Image 1.1: The Aiwa AW-SJ215 Portable Bluetooth Speaker, showcasing its compact design and vibrant LED lights.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- Aiwa AW-SJ215 Portable Bluetooth Speaker
- USB Charging Cable
- User Manual (This document)

## 3. PRODUCT OVERVIEW

### 3.1 Controls and Indicators



Image 3.1: Top panel of the Aiwa AW-SJ215, highlighting the control buttons.

1. **- (Volume Down / Previous Track):** Short press for previous track, long press for volume down.
2. **M (Mode):** Short press to switch between Bluetooth, FM Radio, AUX, and TF Card modes.
3. **Light Button:** Short press to cycle through LED light modes or turn them off.
4. **Play/Pause / Call:** Short press to play/pause music. Short press to answer/end a call. Long press to reject a call.
5. **+ (Volume Up / Next Track):** Short press for next track, long press for volume up.

### 3.2 Ports



Image 3.2: Side panel of the Aiwa AW-SJ215, showing the various input ports.

- **AUX Input:** For connecting external audio devices via a 3.5mm audio cable.
- **TF Card Slot:** For playing music directly from a microSD card.
- **USB Port:** For charging the speaker (DC 5V input).
- **DC5V Input:** Main charging port for the speaker.

## 4. SETUP

---

### 4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the DC5V port on the speaker and to a compatible USB power adapter (5V/1A, not included). The LED indicator will illuminate during charging and turn off or change color when fully charged. A full charge typically takes several hours.

### 4.2 Powering On/Off

To power on the speaker, press and hold the **Play/Pause** button for approximately 3 seconds. You will hear an audible prompt. To power off, press and hold the **Play/Pause** button again for 3 seconds.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Bluetooth Pairing

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for "Aiwa AW-SJ215" in the list of available devices and select it.
4. Once successfully paired, you will hear a confirmation tone, and the LED light will stop flashing.

### 5.2 FM Radio Mode

1. Press the **M (Mode)** button repeatedly until you enter FM Radio mode.
2. To auto-scan and save available stations, press and hold the **Play/Pause** button. The speaker will scan and store stations automatically.
3. Use the - and + buttons to navigate between the saved FM stations.

### 5.3 AUX Mode

1. Connect an external audio device (e.g., MP3 player, computer) to the speaker's AUX input port using a 3.5mm audio cable (not included).
2. Press the **M (Mode)** button repeatedly until you enter AUX mode.
3. Control audio playback directly from your connected external device.

### 5.4 TF Card Mode

1. Insert a TF (microSD) card containing MP3 audio files into the TF card slot.
2. The speaker will automatically detect the card and switch to TF Card mode, beginning playback.
3. Use the **Play/Pause**, -, and + buttons to control playback.

### 5.5 Hands-Free Calling

When your speaker is connected to a smartphone via Bluetooth:

- **Answer Call:** Short press the **Play/Pause / Call** button when an incoming call rings.
- **End Call:** Short press the **Play/Pause / Call** button during a call.
- **Reject Call:** Long press the **Play/Pause / Call** button when an incoming call rings.

## 5.6 LED Light Control

Press the **Light** button (often indicated by a sun or lightbulb icon) to cycle through different LED light modes or to turn the lights off.

## 6. MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or high humidity for extended periods.
- To maintain the IPX5 splash resistance, ensure all port covers are securely closed when using the speaker near water.
- Store the speaker in a cool, dry place when not in use.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; incorrect mode selected; device not connected.	Increase volume on both speaker and connected device. Press 'M' to select correct mode. Ensure Bluetooth is paired or AUX/TF card is properly connected.
Bluetooth connection unstable or disconnects.	Devices out of range; interference.	Ensure devices are within 10 meters. Move away from other wireless devices. Re-pair the Bluetooth device.
Poor FM radio reception.	Weak signal.	Reposition the speaker to improve signal reception.

## 8. SPECIFICATIONS

**Model:** AW-SJ215

**Bluetooth Version:** 5.3

**Output Power:** 20W RMS

**Frequency**

**Response:** 65Hz - 18kHz

**Signal-to-Noise**

**Ratio:** >80dB

**Battery:** 3000 mAh (18650 type)

**Battery Life:** Up to 5.5 hours (volume and usage dependent)

**Charging Input:** DC 5V 1A

**Water Resistance:** IPX5 (splash resistant)

**Dimensions (L x W x**

**H):** 200 x 67 x 81 mm

**Weight:** 1.3 kg

**Connectivity:** Bluetooth, AUX, TF Card



**Special Features:** FM Radio, LED Lights, Hands-free calling

## 9. WARRANTY AND SUPPORT

This product comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, service inquiries, or additional information, please contact Aiwa customer service through their official website or the contact details provided in your warranty documentation.

© 2025 Aiwa. All rights reserved.

### Related Documents - AW-SJ215

	<p><a href="#">AIWA AI6016 Wireless Party Speaker User Manual</a></p> <p>User manual for the AIWA AI6016 Wireless Party Speaker with Trolley Handle, covering features, operation, safety precautions, and warranty information.</p>
	<p><a href="#">Aiwa SB-X100 User Manual: Features, Operation, and Specifications</a></p> <p>Comprehensive user manual for the Aiwa SB-X100 Bluetooth speaker, covering product features, setup instructions, TWS pairing, LED indicators, and technical specifications.</p>
	<p><a href="#">Aiwa AI5000 Bone Conduction Wireless Headphones User Manual</a></p> <p>Comprehensive guide to the Aiwa AI5000 Bone Conduction Wireless Headphones, covering features, setup, usage, maintenance, and troubleshooting. Learn about bone conduction technology, IPX5 water resistance, and Bluetooth connectivity.</p>
	<p><a href="#">Aiwa CA-DW540 Compact Component System Service Manual</a></p> <p>This service manual provides comprehensive technical information for the Aiwa CA-DW540 Compact Disc Carry Component System, including detailed specifications, electrical and mechanical parts lists, schematics, diagrams, and adjustment procedures.</p>
	<p><a href="#">Aiwa EBTW-150 True Wireless Earbuds Quick Guide</a></p> <p>Concise guide to setting up and using Aiwa EBTW-150 True Wireless Stereo Earbuds, covering pairing, playback, calls, charging, and reset procedures.</p>



## [AIWA KF-H23 Wireless Headset User Manual](#)

Comprehensive user manual for the AIWA KF-H23 Wireless Headset, covering product overview, safety instructions, specifications, operation, AUX-in mode, TF card playback, LED indicators, and battery charging.